—— Product Director of Flydigi

NOT JUST ABOUT CONTROL ——
IT'S ABOUT MASTERING VICTORY.

BORN FOR COMPETITION,
EVERY DETAIL FORGED INTO A WEAPON.

MORE THAN A CONTROLLER ——
IT'S CONTROL TURNED INTO VICTORY.

CONTROL EVOLVED

Shortcut Functions

Function	Operation
Switch Onboard Profile	Press ⟲ + ABXY to switch Profile 1/2/3/4.The controller vibrates twice after switching.
Set Button Remapping	Hold ⟲ + Extra Button + Target for 1.5 seconds to set remapping. Extra Button: C/Z/M1/M2/LM/RM;Target: supported controller button.
Clear Button Remapping	Hold ⟲ + Extra Button for 1.5 seconds to clear that expansion button. Extra Button: C/Z/M1/M2/LM/RM.
Enable/Disable Button Remapping	Hold ⟲ for 1.5 seconds to enable/disable all remapping. The controller vibrates twice after switching.
Calibration	Hold LB + RB + ⟲ for 3 seconds to enter calibration. Calibration tutorials are available in detail by scanning the QR code on the product card.
Restore Factory Settings	Hold ⟲ + ⧉ + ☰ for 5 seconds. The controller vibrates after restore.
Quick Grip Vibration Adjustment	Hold ⟲ + Right Stick ↑/↓ to adjust grip vibration. 6 shortcut levels.
Quick Impulse Trigger Adjustment	Hold ⟲ + Left Stick ↑/↓ to adjust impulse trigger vibration. 6 shortcut levels.
Microphone mute/unmute	Press 🔇 to mute Headset mic. Red light on = muted; light off = active.
Quick Output Volume Adjustment	Hold 🔇 + Left Stick ↑/↓ to adjust Headset volume. Up = higher; down = lower. 0-10 levels. Requires headphones to be connected.
Quick Headset Chat Mixer Adjustment	Hold 🔇 + Right Stick ↑/↓ to adjust Headset chat mixer. Up = higher; down = lower. 0-10 levels. Requires headphones to be connected.
Bluetooth Pairing	Hold Pairing Button for 3 seconds to clear the bluetooth pairing history and enter Bluetooth pairing mode.

封面 封底

Appearance

Dongle Connection



1. Slide the switch on the back to the “Dongle” position. Connect the dongle to the computer’s USB port.

2. Press the XBOX button. Once the controller is successfully connected, the indicator light will stay solid white, and the controller will briefly vibrate to confirm the connection.

Wired Connection



1. In any switch position, connect the controller using the included data cable.

2. Press the XBOX button. Once the controller is successfully connected, the indicator light will stay solid white, and the controller will briefly vibrate to confirm the connection.

Bluetooth Connection

1. Slide the switch on the back to the Bluetooth position.

2. Press the XBOX button to enter pairing mode. In the Bluetooth list, select “Vader 5S Pro.” Once the connection is successful, the indicator light will stay solid white, and the controller will briefly vibrate to confirm the connection. When reconnecting to a previously paired device, switch to the Bluetooth position and press the XBOX button briefly — the controller will automatically reconnect.

*To pair with a new device, press and hold the pairing button located on the left side of the top USB port for 3 seconds. The indicator light will flash rapidly, and the controller will clear saved devices and re-enter pairing mode.

Search for ‘Flydigi Space Station’ in the Microsoft Store or visit www.flydigi.com to download

Scan the QR Code for User Guide

CONTROL EVOLVED

内页