

Amy sen Smart Bluetooth Mesh Plug Works with Alexa Devices Only	• Safety Instructions Read and follow all the safety instructions .The plug is recommended for using indoors and in a dry location only The smart plug should only be used within issued outlet rating that stated in the instructions Please correctly plug in the socket and keep away from children. • Please make sure to plug in the socket fully before using • Please do not disassemble the plug.Otherwise the plug may get damaged or become a safety hazard • Please contact with us for a replacement if any damage caused by transportation	• Instruction Our Smart Bluetooth Mesh Plug offer an easy solution to having voice-controllable smart devices in your home The plugs enable you to control your appliance through the Alexa app on your phones or simply voice commands Note. The Alexa devices that supports BLE Mesh connection includes Echo 2nd Gen, Echo 3rd Gen Echo Dot 2nd Gen Echo Dot 3rd Gen, Echo Dot 3rd Gen with clock Echo Plus 1st Gen Echo Plus 2nd Gen, Echo Show 1st Gen Echo Show 5, Echo Show 8 Echo Show 10, Echo Spot, Echo Input Echo Flex, Echo Studio • Note: If you cannot control the smart plug with above Alexa devices lease update the smart plug The way of update: search "Smart Life" n APP store and download it, update the smart plug through the Smart Life APP.	Specifications Power Supply:AC125V-60Hz Load Current:10A Max. Resistive load Compatible Device. Alexa only • Operation Temperature:-20° to60° C/-4° to 122° Design:Compact Design • Installing your plug Note:Please ensure your Amazon Alexa device s setup before adding the smart plug t needs to have the latest software upgrade You can try"Alexa, is your software up to date?" to trigger software update, then add the plug Plug in the plug and power it • Say"Alexa, discovery devices"to Alexa device When the plug get discovered and connected with the Echo device, you will receive a notification from Alexa app You may also receive a voice prompt from your Echo device	Mesh Network Setup If you want to have multiple plugs setup for different rooms, especially the rooms out o the range of the Alexa device Bluetooth signal you can utiize Mesh Network setup to extend he range Setup the smart plug near the Alexa device .Turn off the plug and move it away from the Alexa device and make sure it is in the range of another smart plug Bluetooth signal which s connected on the network as a node This will form a Bluetooth Mesh network. Each connected plug will connect with other olugs in the network Reset nstructions •Power the smart plug,then press and hold the ON/OFF button for 5 second5. If the reset success he LED light on the plug will flash at a uniform speed.If it not, you will have to try it again • Once success,please try to pair it with your Alexa device again	• Operation :On/off :“Alexa, turn on plug 1” • “Alexa, turn off plug 1” • “Alexa, turn on all the plugs Customer Service Warranty:24 months Support: Lifetime Technical Support FCC Statement This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.	This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: —Reorient or relocate the receiving antenna. —Increase the separation between the equipment and receiver. —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. —Consult the dealer or an experienced radio/TV technician for help.
---	--	--	--	--	---	---