


RokBlok Controls

1. Play/Pause Lever
2. Track Indicator Dot
3. Power/Speed Switch
4. Needle
5. Power Light
6. Bluetooth
7. Bluetooth Light
8. Volume
9. USB Charging Port




1

Before Using RokBlok

Lock + Unlock Needle:


Before use, **Unlock** needle by pushing it to the **right**, until you hear a click.



After use, **Lock** needle in place by pushing it to the **left**, until you hear a click.

Select Record Speed:


Use the **Speed Switch** to select the speed of your record.




RokBlok can play **33 1/2 & 45 RPM** records.
(You can find a record's speed on it's label)

2

How to Place and Play RokBlok




1. Turn RokBlok over, and slide the needle to left side.




2. Place RokBlok on record, with the lever facing the record's center.

3

How to Place and Play RokBlok



3. Pull lever up to begin playing record.



4. Hold hand over player and let lever run into your hand, to stop playing.

Tips and Best Practices

Tips:

- Line the "Track Indicator Dot" up with the track you want to hear.
- For the best battery life, power off RokBlok with the "Power/Speed Switch" when not in use.
- To protect needle, lock needle in place when RokBlok is not in use.
- When pairing, be sure that your Bluetooth speaker is in "Discoverable Mode".

IMPORTANT:

We spent a tremendous amount of time designing RokBlok so it will not easily damage records with use. However, if used improperly, marking and scratching can occur.

To prevent damage to your records when using RokBlok, **ALWAYS** be sure to:

- Only use RokBlok on a flat, level surface
- Ensure record & surface is clean and free of dust and debris before using RokBlok
- Slide needle to the left before placing and playing
- **NEVER** grab RokBlok while in motion

5

Connect to Bluetooth Device

Pairing Device for the First Time

1. Put your Bluetooth device in "Discoverable Mode".
2. Hold  on RokBlok, until Bluetooth light begins blinking.
3. Release Bluetooth button once light stops blinking.
4. That's it! RokBlok will now send it's music to your Bluetooth device.

Reconnecting to Paired Bluetooth Device

1. RokBlok will remember your paired Bluetooth device. For future pairings, simply press Bluetooth button.



Confused? Watch instructional videos at www.RokBlok.co/HowTo

6

Legal & Additional Information

"RokBlok" is a registered trademark of Pink Donut, LLC. Bluetooth and the Bluetooth logo are registered trademarks of Bluetooth SIG, Inc.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference and
2. this device must accept any interference received, including interference that may cause undesired operation.

Warning:

Please read these safety warnings carefully to ensure your personal safety and prevent property damage.

- Do not expose RokBlok to liquid, moisture, humidity, or rain. Exposure could result in electric shock.
- Do not attempt to disassemble RokBlok. Doing so can result in electric shock.
- Do not touch the needle's tip. Only handle the needle by it's plastic cartridge.
- User assumes all risk associated with use of RokBlok.
- Using RokBlok to play Milli Vanilli instantly voids warranty.

7

Legal & Additional Continued

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

RF Exposure warning statements:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must be at least 20 cm from the user and must not be co-located or operating in conjunction with any other antenna or transmitter. The information in this guide may change without notice. The manufacturer assumes no responsibility for any errors that may appear in this guide.

This device complies with Industry Canada license-exempt RSS standard(s).

Operation is subject to the following two conditions:

1. This device may not cause harmful interference;
2. This device must accept any interference received, including interference that may cause undesired operation of the device.

Cet appareil est conforme à Industrie Canada une licence standard RSS exonérés (s). Son fonctionnement est soumis aux deux conditions suivantes:

1. Cet appareil ne doit pas provoquer d'interférences
2. Cet appareil doit accepter toute interférence reçue, y compris les interférences pouvant provoquer un fonctionnement indésirable de l'appareil.