

120 mm

LED SOUNG BAR

Model: SP-504

OPERATION INSTRUCTIONS

Before assembling and using the product: read this instruction carefully

SPECIFICATIONS
PORT (USB CHARGE) INPUT: 5 V
Internal rechargeable lithium battery:3.7V


Precautions:

- 1.Do not place in areas with high temperature, humidity, or where it may be subject to impact.
- 2.Do not open the back cover or any part of the speaker to avoid damage and other accidents.
- 3.For repairs, it should be taken to professional technical personnel.
- 4.The speaker must not be exposed to dripping or splashing of water or other liquids.
- 5.To avoid charging failures, please use the original USB charging cable.
- 6.The speaker should not be placed near high-temperature devices or exposed to fire to prevent battery explosion and other hazards!

IMPORTANT INFORMATION REGARDING BATTERY CHARGING

- 1.When you first purchase the product, charge the speaker's internal battery.
- 2.Before inserting the charging cable, check the port and insert the connector carefully. Incorrect insertion may severely damage your speaker.
- 3.Use a USB charger with an output specification of 5V DC 2A. If you use an adapter with lower specifications, the battery may not fully charge and this will shorten the lifespan of your product.
- 4.Charge it without interruption or using it at the same time, for a minimum of 4 hours.
- 5.Once the initial battery charge is complete, you can start using your product.

FEATURES AND FUNCTIONS



- 1.Long press to power on (start) / Short press to pause/play
- 2.Long press to change LED lights / Short press for FM radio
- 3.Long press to increase volume / Short press to skip to the next track
- 4.Long press to decrease volume / Short press to go to the previous track
- 5.USB charging cable input (5V DC)
- 6.Charging indicator light
- 7.USB device input
8. TF Card input

USER INSTRUCTIONS

BLUETOOTH MODE

- 1.When entering Bluetooth Mode, the LED indicator will light up blue, indicating it is ready to pair. (Pairing mode)
 - 2.On your mobile device, go to the Bluetooth menu and begin searching for available Bluetooth devices. "MSR MSB555" will appear on your phone or device. Select and pair it.
 - 3.Once pairing is complete, You can now open your music player on your phone or mobile device and start playing songs.
- Note: Mobile phone brands and settings use different Bluetooth versions, so the search and pairing time may vary. The difference is usually just about 30 seconds.
- 4.Press and hold the "+" button to increase the speaker volume.
 - 5.Press and hold the "-" button to decrease the speaker volume.
 - 6.Briefly press the "+" button to skip to the next song.
 - 7.Briefly press the "-" button to go back to the previous song.
 - 8.Press the "■" button to pause or play the song.

FM RADIO PLAYBACK

- 1.Turn on the speaker and press the "M" button briefly to switch to radio mode.
- 2.Press the power button briefly to start automatic channel scanning.

USB MODE OPERATION

- 1.Insert the USB drive with music files into the USB port.
 - 2.Press and hold the "■" button on the speaker for about 3-5 seconds.
- You will hear a tone, the LED light will turn on, and the speaker will power on automatically.

To switch to USB mode:

- Note: If the speaker is on and operating in another mode, simply press the "M" button after powering on to switch to USB mode.
- 3.Press and hold the "+" button to increase the speaker volume.
 - 4.Press and hold the "-" button to decrease the speaker volume.
 - 5.Briefly press the "+" button to skip to the next song.
 - 6.Briefly press the "-" button to go back to the previous song.
 - 7.Press the "■" button to pause or play the song.

LED LIGHTS:

There are seven LED light modes. Press and hold the "M" light button to switch to a different light mode.
On the eighth press and hold, the lights will turn off, returning from the first light mode.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

80 mm