

Model:SP-003

PRODUCT MANUAL

Please consult your local or network dealer for specific functions.

(实物具体功能请咨询当地或网络经销商)

V 1.0

PRODUCT MANUAL 操作简介

BUTTON

Long press: Power On / Off
Chick : Play/Pause,Auswer/Hang up
Double-click: Remote Camera(First Open the phone's camera)
长按: 开机/关机
短按: 播放, 暂停, 接电话, 挂电话
快速按2下: 遥控自拍 (先打开手机的相机软件)



RESET

复位开关

CHARGE USB/5V
音箱充电口

AUX LINE IN
3.5mm音频输入口

USB 5V/1A OUT (USB PLAY)
移动电源输出口/U盘播放



Click: Previous song. Long press: Volume +
短按上一曲, 长按音量加大

Click: Next song. Long press: Volume -
短按下一曲, 长按音量减小

请仔细阅读本说明书！

- + 在使用本产品之前, 请注意以下事项, 否则可能会损坏您的数码产品并产生危险。
- + 本产品初次使用前或长期未使用时, 主机可能已自动逐渐放电, 故初次使用或再使用前应先充满电。
- + 请使用经认可的电源充电器及配件, 包括电源线及转接头。否则可能会损坏您的设备和音箱主机。
- + 应在通风的位置充电, 过高或过低的温度将影响电池的性能。
- + 不要把本产品置于水中, 或受潮淋雨。(防水音箱除外)
- + 请勿扔掷, 强烈摔打、震动或摇晃本产品, 否则可能会破坏内部精密的零件和完好的结构。
- + 请妥善保存本产品及相关配件、避免置于儿童容易触及的地方。
- + 充电或播放时, 音箱可能会微微发热, 这属于正常现象。
- + 请勿将音箱接近火源或其他热源, 以免发生危险。
- + 避免让金属物品接触主机的充电/音频等插口, 以免产生短路而损坏主机。
- + 未经授权的产品改动和自行修理可能会使您无法正常使用本产品及令保修失效。
- + 请您根据当地的法律、章程及限制, 适当使用本产品。当遇到未经许可的情况, 如飞机升降或位于医疗仪器附近时, 应停止使用, 并立即关闭您的手机或其他电子设备, 以免造成干扰。

开机/关机
长按大按键: 开机/关机

蓝牙播放
开启手机蓝牙, 搜索到本机的配对码, 点击配对, 连接成功会发出提示音, 即可用手机播放音乐。

充电功能 (移动电源)
使用充电线给手机充电。USB端连接音箱的USB口, 另一端连接手机的充电口, 即可给手机充电。

遥控自拍功能
手机打开蓝牙, 连接音箱, 打开手机的摄像机功能, 快速按2下播放键 (大按键), 可远程遥控拍摄。

U盘播放
插入U盘, 音箱发出提示音, 即可播放内部歌曲。支持格式: WAV/WMA/MP3等。

语音通话
手机与音箱蓝牙连接状态下, 手机来电时, 音箱会有铃声提示, 短按“播放”键接听电话, 再短按挂断电话。

FM收音机模式
1、同时按住背面的两个“O”键, 几秒后切换到“收音模式”;
2、将USB MICRO线插头插入音箱充电口当外置天线;
3、短按“播放>”键, 进入自动搜台, 搜台完毕后自动进入第一个电台播放;
4、短按“+”“-”键控制上、下选台;
(FM电台数量跟效果: 取决于周围环境跟当地的网络信号)
5、再次同时按住背面的两个“O”键, 几秒后切换到“蓝牙模式”;

AUX(LINE IN) 模式
将3.5MM音频插头插入手机的耳机孔, 另一端连接音箱的AUX圆孔接口, 音箱发出提示音, 即可用外接音频播放音乐。

充电
将USB MICRO连接线插入音箱充电口, 连接5V充电器或电脑即可对音箱充电。

指示灯
白灯慢闪: 工作状态
白灯快闪: 蓝牙等待连接/搜索电台
充电中, 红灯闪烁; 充满电, 红灯常亮。

Power ON/OFF
Long press the button: switch ON/OFF

Bluetooth Play
Open the phone Bluetooth function, search the speaker matching ID, click on the matching, the prompt voice after connection, then you can play music by your phone.

Charging function (Power bank)
Use the charging cable and connect with the phone USB port, the other side connected with the speaker, so that the mobile phone can be charged.

Remote selfie timer function
open the Bluetooth function and connect speakers, when take the photo press the 2 times play button (big key), then can remote control the shooting.

U disk card playback
insert the U disk card, and the speaker have the prompt voice and then can to play the internal songs. Support formats: WAV/WMA/MP3, etc.

Voice call
When have the calls, the speaker will have a bell mentioned, press the "play" button to answer the phone, press again hung up.

FM radio mode
1.Press the two "O" keys at the same time and switch to the radio mode after a few seconds";
2.Insert the USB MICRO line plug into the speaker charging port as an external antenna;
3.Press the "play >" button, enter the automatic search channel, after the search is completed, automatically enter the first channel broadcast;
4.Short press "+" - "-" key to control the channels;
(The amount channels and effects: depending on the environment and the local network signals)
5.press the two "O" button on the back again and switch to Bluetooth mode in a few seconds";

AUX (LIN IN) mode
Connect the 3.5MM audio line with the cell phone, and the other side to speaker AUX port, then you can play the music.

Charging
the USB MICRO cable connect with the speaker port and other side connect with the 5V charger or computer.

Indicator light
White light slow flashing: working state
White light fast flash: Bluetooth connection / search channel.
In charging : red light flashing ; full of power, the red light is always on.

- + Please pay attention to the following items before using this product, otherwise it may damage your digital products and cause danger.
- + When the product is first use or unused for a long time, the battery may discharge gradually and automatically so please charged full before use or re-use.
- + Please use approved power charger and accessories, including the power cord and the adapter. Otherwise, the device and speaker may be damaged.
- + Please charge the battery in the ventilated position, too high or too low temperature will affect the performance of the battery.
- + Do not put this product in water or get wet (except waterproof speakers)
- + Do not drop, beat, or shake this product strongly, otherwise it may damage the internal parts and the product.
- + Please keep this product and the accessories safely and avoid the children touched.
- + It is a normal phenomenon while the speaker charging or playing may be slightly hot.
- + Please do not close the speaker to fire or other heat products to avoid danger.
- + Please avoid any metal items touching the speaker charging / audio sockets, so as to avoid damage to the speaker due to short circuits.
- + Unauthorized change and self-repair products may cause the speaker unable working and the warranty invalidate.
- + Please use this product in accordance with local laws, regulations and restrictions. When under unauthorized situation, please stop using it and turn off your cell phone or other electronic equipment immediately e.g. the airplane takeoff/ landing or near a medical instrument.

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.