

智能门禁

K3W/K3FW/K3QW


使用说明

智能门禁 K3W/K3FW/K3QW


产品型号:	K3WK3FWK3QW
尺寸:	W80mm x H126mm x T19mm
材质:	ABS/亚克力
支持系统:	Android 4.3/IOS7.0 above
网络标准:	无线 WiFi 2.4G (支持WiFi6)
IEEE 标准:	802.11b/g/n/ax
网络加密:	WPA/WPA2/WPA3
待机电流:	20mA (背光不点亮) 50mA (背光点亮)
动作电流:	≈1A
供电方式:	DC 12~24V
防水等级:	IP67
工作温度:	-20~70°C
卡片容量:	2000
密码数量:	500
指纹容量:	100(K3FW only)

	APP	卡	密码	指纹	二维码
K3W	●	●	●	●	●
K3FW	●	●	●	●	●
K3QW	●	●	●	●	●

包装清单



安装步骤



1. 开孔


在合适的位置上,打通门禁线缆连接电源的线槽。

2. 安装固定支架

将固定支架从门禁上取下,然后在门禁线槽位置,用自攻螺丝将固定支架固定

接线

用剪刀在门禁线缆合适位置将接头剪去,然后将门禁线缆分别接通到电源及对应线束上。



安装主机

将主机装入到固定支架后,用螺丝刀固定。



重置门禁

门禁通电情况下:

1. 短接蓝色开关线 (SW) 和紫色门磁线 (IN)



3. 听到滴一声后与黑色地线 (GND) 分开




2. 短接后的线与黑色地线 (GND) 短接 3 秒



4. 步骤 2、3 重复 3 次操作, 听到滴滴两声后重置成功

添加门禁(绑定管理员)

1. 点按触摸屏任意数字激活门锁



2. 打开 App 软件



3. 点击左上角“≡”进入“添加锁”，选择门锁（门禁）类型



4. 点击发现的锁设备名称，等待几秒钟，直至锁添加成功



配置网络，选择正确的网络并输入密码



* 不支持 5GWIFI 网络，请选择 2.4GWIFI 网络进行配置

● 注意:如果通过以上步骤未能成功添加锁,请关闭手机APP,关闭手机蓝牙后再重新打开APP与蓝牙,重复以上步骤。

修改门禁背光

- 背光常亮:*49#管理员密码#1#
- 背光熄灭:*49#管理员密码#0#

产品保修说明

- 1、自购买产品之日起7日内,若产品出现非人为损坏的质量问题,可以选择按购买价格退货或更换同型号产品;
- 2、自购买产品之日起至第十五日内,若产品出现非人为损坏的质量问题,可以选择免费更换同型号的产品;
- 3、自购买产品之日起12个月内,若产品出现非人为损坏的性能故障,提供免费维修服务。

免责声明:
本公司保留因改进产品而变更设计的权利,届时恕不另行通知;所有资料经过仔细核对力求精准但仍可能产生误差,本公司不承担由此产生的后果。

SMART ACCESS CONTROLLER

K3W/K3FW/K3QW


Manual

Smart Access Controller K3W/K3FW/K3QW


Model:	K3WK3FWK3QW
Dimensions:	W80mm x H126mm x T19mm
Material:	ABS/Acrylic
Supporting systems:	Android 4.3/IOS7.0 above
Network:	WiFi 2.4G (support WiFi6)
IEEE standard:	802.11b/g/n/ax
Network encryption:	WPA/WPA2/WPA3
Stand-by current:	20mA&50mA(Activate back lighting)
Operating current:	≈1A
Power supply:	DC 12~24V
Waterproof level:	IP67
Working Temperature:	-20~70°C
Card capacity:	2000
Number of Passwords :	500
Fingerprint capacity :	100(K3FW only)

	APP	IC Card	Pincode	Fingerprint	QR code
K3W	●	●	●	●	●
K3FW	●	●	●	●	●
K3QW	●	●	●	●	●


Accessories



Illustration




1. Drill a hole for the cable
2. Install the mounting plate



3. Wiring

Cut off the connector of the cable, strip and connect the leads to appropriate ports of the power supply according to the illustration.



4. Install the access controller

Fit the access controller into the hook and fix it on the mounting plate with a screw in the bottom.




Reset to default mode

When the power is on:

1. Connect blue wire(SW) to purple wire(IN)
2. Connect SW and IN to black wire(GND) for 3 seconds
3. Disconnect black wire(GND) on a beep
4. Repeat step 2 and step 3 twice till 2 short beeps are heard

Pair the access controller with app

1. Tap the panel to light it up and activate the lock.
2. Activate the APP.
3. Tap the “≡” icon on the upper left corner, tap “+Add Lock”, select “Door Lock”.
4. Tap the device shown on the screen. Wait a few seconds, and then add successfully.



5. Disposition, Select the network and input your WiFi password



*5G is not supported. Please select a WiFi of 2.4G

Notice: If fails, please shut off the APP and Bluetooth, turn them on and try the above process again.

Change back lighting

- Back lighting always on: *49#admin password#1#
- Back lighting always off: *49#admin password#0#

Limited Warranty

1. For any defect in material and/or workmanship, the original purchaser of the product can:
 - 1) Return or ask for a replacement within 7 days from the date of the Invoice.
 - 2) Ask for a replacement within 15 days from the date of the Invoice.
 - 3) Can ask for a free repair in 365 days from the date of the Invoice.
2. This warranty does not cover defects caused by modification, alteration, misuse or physical abuse of the product.

FCC WARNING
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
— Reorient or relocate the receiving antenna.
— Increase the separation between the equipment and receiver.
— Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
— Consult the dealer or an experienced radio/TV technician for help.
To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body. Use only the supplied antenna.

Disclaimer
We continuously optimize products as new technologies and features are developed. For this reason, we reserve the right to make alterations to the products, without prior notice.