

封面

8BitDo[®]

Instruction Manual


使用说明


封里

Pro 3 Bluetooth Gamepad	01
Pro 3 蓝牙手柄	08
Pro 3 Bluetooth コントローラー	15
Pro 3 블루투스 게임패드	19
Pro 3 Bluetooth-Joystick	25
Manette Bluetooth Pro 3	31
Controller Bluetooth Pro 3	37
Mando de Bluetooth Pro 3	43

Pro 3 Bluetooth Gamepad

English





- Press the **start button** to turn on the gamepad.
- Hold the **start button** for 3 seconds to turn off the gamepad.
- Hold the **start button** for 8 seconds to forced shutdown the gamepad.

① — L1 button	⑩ — Home button	⑲ — L4 button
② — D-pad	⑪ — R3 button	⑳ — L2 button
③ — Star button	⑫ — R4 button	㉑ — Trigger mode switch
④ — L3 button	⑬ — R2 button	㉒ — Mode switch
⑤ — - select button	⑭ — Trigger mode switch	㉓ — 2.4G Adapter/Adapter compartment
⑥ — Profile button	⑮ — Charging contacts	㉔ — Charging status LED
⑦ — + start button	⑯ — Power LED	
⑧ — Profile LED	⑰ — Status LED	
⑨ — R1 button	⑱ — Pair button	

Windows

- Windows 10(1903) or above is required.

Wireless Connection

1. Turn the **Mode switch** to **S/X** position.
2. Press the **start button** to turn on the gamepad.
3. Connect the 2.4G adapter to the USB port of your Windows device, the **Status LED** will remain solid to indicate a successful connection.

Wired Connection

1. Turn the **Mode switch** to **S/X** position.
 2. Connect the gamepad to your Windows device via a USB cable and wait till the gamepad is successfully recognized by the device.
-

Switch

- Switch system 3.0.0 or above is required.
- NFC scanning, IR camera, HD rumble and notification LED are not supported.

Bluetooth Connection

1. Turn the **Mode switch** to **S** position.
2. Press the **start button** to turn on the gamepad.
3. Hold the **Pair button** for 3 seconds to enter its pairing mode, the **Status LED** will start to roll side to side. (This is required for the very first time only)
4. Go to your Switch Home Page to click on [Controllers], then click on [Change Grip/Order], the **Status LED** will remain solid to indicate a successful connection.

Wireless Connection

- Please ensure the [Pro Controller Wired Communication] is enabled.
1. Turn the **Mode switch** to **S/X** position.
 2. Press the **start button** to turn on the gamepad.
 3. Connect the 2.4G adapter to your Switch device's USB port, the **Status LED** will remain solid to indicate a successful connection.

Wired Connection

- Please ensure the [Pro Controller Wired Communication] is enabled.
1. Turn the **Mode switch** to **S** position.
 2. Connect the gamepad to your Switch device via a USB cable and wait till the gamepad is successfully recognized by the device.

Android

- Android 9.0 or above is required.

Bluetooth Connection

1. Turn the **Mode switch** to **D** position.
2. Press the **start button** to turn on the gamepad.
3. Hold the **Pair button** for 3 seconds to enter its pairing mode, the **Status LED** will start to roll side to side. (This is required for the very first time only)
4. Go to your Android device's [Bluetooth Setting] and turn it on, pair with [**8BitDo Pro 3**], the **Status LED** will remain solid to indicate a successful connection.

Wired Connection

- OTG support is required on your Android device, please contact your manufacturer for more information.
1. Turn the **Mode switch** to **D** position.
 2. Connect the gamepad to your Android device via a USB cable and wait till the gamepad is successfully recognized by the device.


Turbo Function

- **D-pad, Home button, L3/L4 buttons, L4/R4 buttons, and PL/PR buttons** are not supported for turbo.
- The turbo settings will not be saved permanently and will revert to default settings after the gamepad is powered off or disconnected.



L4/R4/PL/PR Buttons Configuration


- Single or multiple buttons on the gamepad can be mapped to the **L4/R4/PL/PR buttons**.
- **L3/R3 buttons** are not supported.
- The **Home LED** will blink continuously when the mapped button is pressed.



Battery

Status

Low battery
Battery charging
Fully charged



Power LED

Power LED blinks
Power LED stays solid
Power LED turns off

- Built-in 1000mAh battery pack, 20 hours of usage time and rechargeable with 4 hours charging time.
 - The gamepad will automatically shut down if it fails to connect within 1 minute of startup, or if there are no operations within 1 minute after establishing a connection.
 - The gamepad will not shut down during wired connection.
 - Charging and battery life depend on variations in settings or environmental factors, and actual results may vary.
-

Safety Warnings

- Please always use batteries, chargers, and accessories provided by the manufacturer.
 - The manufacturer is not liable for any safety issues arising from the use of non-manufacturer-approved accessories.
 - Do not attempt to disassemble, modify, or repair the device yourself. Unauthorized actions may result in serious injury.
 - Avoid crushing, disassembling, puncturing, or attempting to modify the device or its battery, as these actions can be dangerous.
 - Any unauthorized changes or modifications to the device will void the manufacturer's warranty.
-

Ultimate Software


Please visit app.8bitdo.com to download the **Ultimate Software** to get the latest firmware & additional support.


Support

Please visit support.8bitdo.com for further information & additional support.

Pro 3 蓝牙手柄

中文





* 开机:按下 **start** 键。

* 关机:按住 **start** 键 3 秒。

* 强制关机:按住 **start** 键 8 秒。

① — L1

② — 方向键

③ — 星号键

④ — L3

⑤ — -select 键

⑥ — 配置键

⑦ — + start 键

⑧ — 配置指示灯

⑨ — R1

⑩ — Home 键

⑪ — R3

⑫ — R4

⑬ — R2

⑭ — 扳机模式开关

⑮ — 充电触点

⑯ — 电源指示灯

⑰ — 状态指示灯

⑱ — 配对键

⑲ — L4

⑳ — L2

㉑ — 扳机模式开关

㉒ — 模式开关

㉓ — 接收器 / 接收器收纳仓

㉔ — 充电指示灯

Windows

* 要求 Windows 设备系统版本为 Windows 10 (1903) 或更高版本。

无线连接

1. 将 **模式开关** 移动到 **S/X** 位置。
2. 按下 **start** 键 开启手柄。
3. 将配备的 2.4G 接收器或装有 2.4G 接收器的底座连接到 Windows 设备的 USB 端口, 连接完成后 **状态指示灯** 常亮。

有线连接

1. 将 **模式开关** 移动到 **S/X** 位置。
2. 使用 USB 线将手柄连接到 Windows 设备的 USB 端口, 等待系统识别完成后即可使用。

Switch

- * 要求 Switch 主机系统版本为 3.0.0 或更高版本。
- * 不支持 NFC 扫描、红外摄像头、HD 振动、通知灯等功能。

蓝牙连接

1. 将 **模式开关** 移动到 **S** 位置。
2. 按下 **start** 键 开启手柄。
3. 按住 **配对键** 约 3 秒至 **状态指示灯** 左右滚动闪烁, 进入配对状态。(仅首次连接时需要配对)
4. 打开 Switch 主机“手柄”选项, 选择“更改握法 / 顺序”, 等待手柄连接; 连接完成后 **状态指示灯** 常亮。

无线连接

* 请确保“设置”-“手柄与感应器”-“Pro 手柄的有线连接”功能已开启。

1. 将 **模式开关** 移动到 **S/X** 位置。
2. 按下 **start** 键 开启手柄。
3. 将配备的 2.4G 接收器或装有 2.4G 接收器的底座连接到 Switch 主机的 USB 端口, 连接完成后 **状态指示灯** 常亮。

有线连接

* 请确保“设置”-“手柄与感应器”-“Pro 手柄的有线连接”功能已开启。

1. 将 **模式开关** 移动到 **S** 位置。
2. 使用 USB 线将手柄连接到 Switch 主机的 USB 端口, 等待系统识别完成后即可使用。

Android

* 要求 Android 设备系统版本为 9.0 或更高版本。

蓝牙连接

1. 将 **模式开关** 移动到 **D** 位置。
2. 按下 **start** 键 开启手柄。
3. 按住 **配对键** 约 3 秒至 **状态指示灯** 左右滚动闪烁, 进入配对状态。(仅首次连接时需要配对)
4. 打开 Android 设备“蓝牙”, 搜索 **8BitDo Pro 3** 手柄连接; 连接完成后 **状态指示灯** 常亮。

有线连接

* 需要设备支持 OTG 功能, 详情请咨询设备制造商。

1. 将 **模式开关** 移动到 **D** 位置。
2. 使用 USB 线将手柄连接到 Android 设备的 USB 端口, 等待系统识别完成后即可使用。

连发

- * 方向键、Home 键、左 / 右摇杆、L4 / R4 键、PL / PR 键 不支持连发。
- * 连发功能不会保存, 关机或断开连接后恢复默认。




配置 L4 / R4 / PL / PR 键

- * 可将手柄上的单个或多个按键复制到 L4 / R4 / PL / PR 键。
- * 左 / 右摇杆 不支持配置。
- * 已配置的按键使用时 Home 指示灯 会持续闪烁。



电源

电源状态
电量不足
正在充电
充电完成



电源指示灯状态
电源指示灯闪烁
电源指示灯常亮
电源指示灯熄灭

- * 配备 1000mAh 可充电式锂电池, 可持续使用约 20 小时, 充电时间约 4 小时。
 - * 开机后 1 分钟内未连接, 或连接后 15 分钟无操作会自动休眠。
 - * 使用有线连接时不会自动休眠。
 - * 充电和续航时间取决于设置或环境因素差异, 实际结果可能有所不同。
-

安全警示

- * 请使用制造商的电池、充电器、配件。
 - * 在用户使用第三方的配件时, 制造商不能对用户的安全负责。
 - * 请勿自行拆卸、改装或修理设备。
 - * 请勿挤压、拆解、刺穿或尝试改装设备及电池。
 - * 对设备的任意变动或改装, 将导致制造商对设备不予保修。
-

自定义配置

请访问 app.8bitdo.cn 获取 **精英软件** 使用。

技术支持

请访问 support.8bitdo.cn 了解详细信息。

封底里



Manual



使用说明

封底



FCC regulatory conformance:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a **Class B** digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

RF Exposure

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

IC regulatory conformance

This device complies with CAN ICES-003 (B)/NMB-003(B).

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Cet appareil est conforme à la norme CAN ICES-003 (B)/NMB-003 (B).

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

(1) l'appareil ne doit pas produire de brouillage, et

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

RF Exposure

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment.

Cet équipement est conforme aux limites d'exposition aux radiations de la IC définies pour un environnement non contrôlé.