



 x1
 x1
 x1
 x1

- | | | | | | |
|------------|----------|----------|--------|----------------|------------|
| Fn+F1 | Fn+F2 | Fn+F3 | Fn+F4 | Fn+F5 | Fn+F6 |
| Player | Volume - | Volume + | Mute | Previous Track | Next Track |
| Fn+F7 | Fn+F8 | Fn+F9 | Fn+F10 | Fn+F11 | Fn+F11 |
| Play/Pause | Stop | Homepage | Email | My Computer | Favorite |

-01-

-02-

 x1
 x1
 x1
 x1

- | | | | | | |
|-------------------|-----------|--------------|--------|----------------|----------------|
| Fn+F1 | Fn+F2 | Fn+F3 | Fn+F4 | Fn+F5 | Fn+F6 |
| Spieler | Volumen - | Lautstärke + | Stumm | Vorherige Spur | Nächster Titel |
| FN+F7 | FN+F8 | Fn+F9 | Fn+F10 | Fn+F11 | Fn+F11 |
| Wiedergabe/ Pause | Stopp | Homepage | E-Mail | Arbeitsplatz | Favorit |

-03-

- 04-

 x1
 x1
 x1
 x1

- | | | | | | |
|-----------------|----------|----------------|----------|------------------|----------------|
| Fn+F1 | Fn+F2 | Fn+F3 | Fn+F4 | Fn+F5 | Fn+F6 |
| Joueur | Volume - | Volume + | Muet | Piste précédente | Piste suivante |
| FN+F7 | FN+F8 | Fn+F9 | Fn+F10 | Fn+F11 | Fn+F11 |
| Lecture / Pause | Arrêter | Page d'accueil | Courriel | Mon ordinateur | Favorites |

-05-

- 06-

-07-