

MODEL 5340117

TY 11LB PREC HUB NUTRDIG SCALE APP

Thank you for purchasing a Taylor® Kitchen Scale. This digital scale works with the **Taylor Precision Hub App** to combine precise weighing with smart tracking. Use the app to monitor calories, fats, carbohydrates, and protein on any compatible mobile device. Your Taylor® Kitchen Scale is an example of superior design and craftsmanship. Please read this instruction manual carefully before use. Keep these instructions handy for future reference.

Battery Information

1. Uses 3 AAA (1.5 V) batteries (included).
2. Remove the battery compartment cover on the bottom of the scale. Remove any wrapping from the batteries and insert into the compartment according to the "+" and "-" polarity symbols.
3. Replace battery compartment cover and press to snap closed. Turn the scale on.
4. When batteries need replacement, remove the old batteries and place new batteries into the battery compartment following the same steps.

BATTERY WARNINGS


- ☒ Always purchase the correct size and grade of battery most suitable for the intended use.
- ☒ **NOTE:** Please recycle or dispose of batteries per local regulations.
- ☒ **WARNING:** Batteries may pose a choking hazard. As with all small items, do not let children handle batteries. If swallowed, seek medical attention immediately.
- ☒ **PRECAUTION:** Do not dispose of batteries in fire. Batteries may explode or leak.
- ☒ Remove the batteries if the product will not be used for a long period of time. Remove used batteries promptly.
- ☒ Clean battery contacts and also those of the device prior to battery installation.
- ☒ Non-rechargeable batteries are not to be recharged.
- ☒ Do not force discharge, recharge, disassemble, heat or incinerate. Doing so may result in injury due to venting, leakage, or explosion resulting in chemical burns.
- ☒ Always replace all batteries at the same time; do not combine old and new batteries. Do not mix alkaline, standard (carbon-zinc) or rechargeable (ni-cad, ni-mh, etc.) batteries.
- ☒ When batteries of different brand or type are used together, or new and old batteries are used together, some batteries may be over-discharged due to a difference of voltage or capacity. This can result in venting, leakage, and rupture and may cause personal injury.

Low Battery

Your Taylor® scale is equipped with a low battery indicator. "Lo" will appear on the screen or readings will grow dim or become irregular if the batteries need replacement.

APP NAME

Precision Hub available on iOS and Android devices.



General Operation & Scale Pairing

1. Place the scale on a hard, level surface.
2. Press  /TARE button to turn the scale on. The display will turn on and show 88:88:88 across the display then zero when it is ready for use. If the display does not show zero, press the  /TARE button to reset the scale to zero.
3. Open the APP on your device and enable Bluetooth. Next, select the Food Scales category.
4. Select device "5340117 Nutrition Scale". Once connected, weight is synced from the scale to the APP and food macros will be calculated.
5. Your scale is set at the factory to weigh in pounds/ounces. To switch to other units of measurement, grams, fluid ounces (milk/water) and milliliters (milk/water). press **UNIT** button.

6. Place the item to be weighed on the center of the platform. The weight will display. As you add weight, the weight displayed increases.
7. The scale will turn off automatically within 3 minutes when disconnected from the APP and 9 minutes when paired to accommodate longer recipe or meal building functions or if there is no change in weight. To turn the scale off manually, press and hold  until the scale turns off.

Tare Operations

You may wish to weigh ingredients in a bowl or other container (not included). In this case, you will need to tare, or offset, the weight of the bowl so that only the weight of the ingredients is displayed.

1. Choose a container that will safely balance on the platform without tipping or falling. Do not use a heavy container, as this might reduce the maximum capacity of the scale.
2. While the scale is off, place the empty container on the scale platform. Turn the scale on. The display will show "88:88:888" then show zero. The weight of the container has been zeroed out.
3. Add the ingredient to be weighed. The weight of the ingredient alone will display.
4. The weight of additional ingredients may be tared out as well. For example, if a recipe calls for ½ lb rice and ½ lb beans, place the rice into the bowl. Once the correct amount of rice is weighed, press **TARE** button to reset the display to zero. Add the ½ lb of beans. Both ingredients have been accurately weighed in the same bowl.
5. When weights have been tared out, the display will show a negative number when the items are removed from the scale. To reset the scale back to zero for a new measurement, press **TARE** button to reset the display to zero.

Important Information

1. Clean exposed parts with a soft, slightly damp cloth. To remove stains, use a mild soap. Never use detergents, excess water, treated cloths, harsh cleaning agents, or sprays. Avoid contact with acids, such as citrus juices. DO NOT immerse the electronic scale in water or wash in a dishwasher.
2. Do not tamper with the scale's internal components. Doing so will invalidate the warranty and may cause damage. The scale contains no user-serviceable parts.
3. Although the scale is designed to be maintenance-free, it contains sensitive electronic parts. Avoid rough treatment. Treat it with care to ensure the best performance.
4. This scale is intended for home/consumer use only. It is not intended for commercial or medical use.
5. This scale is designed to read weights up to 11lb x 0.1 oz / 5000g x 1 g / 176 fl oz x 0.1 fl oz / 5000 mL x 1 mL. To prevent damage, do not place more than the above-mentioned weights on each of the platforms.
6. Do not store the scale where you store cleaning chemicals. The vapors from some household products may affect the electronic components of the scale. Do not store the scale on its side.
7. This scale is an extremely sensitive weighing device. In order to prevent depletion of the batteries, do not store anything on the scale.
8. Do not dispose of batteries in fire. Batteries may explode or leak. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc) or rechargeable (Ni-Cd, Ni-MH, etc.). Remove the batteries if the scale will not be used for a long time.
9. "Err" = Overload Warning: If "Err" appears on the display while weighing, the maximum weight capacity of the scale has been exceeded. Remove the weight immediately; otherwise, permanent damage to the scale could occur.

Party issuing Supplier's Declaration of Conformity & Responsible party – U.S. Contact information:

Taylor Precision Products
2311 W. 22nd Street, Suite 200
Oak Brook, IL 60523

Equipment:

Product Name: Kitchen Scale

Model No.: 5340117

Trade Name: Taylor

We declare under our sole responsibility that the above referenced product has been tested according to FCC requirements and this device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC RF Exposure Warning Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment can be used in portable exposure conditions.

FCC ID: 2AP3Q - 5340117

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

For additional product information and troubleshooting assistance, please call 866-843-3905 (8-5pm, M-F)

One (1) Year Limited Warranty

Taylor® warrants this product to be free from defects in material or workmanship (excluding battery/ies) for one (1) year from the date of retail purchase for the original purchaser. It does not cover damages to wear resulting from accident, misuse, abuse, commercial use, or unauthorized adjustment and/or repair. If help or troubleshooting is required, do not return to retailer. Should this product require service (or replacement at our option), while under warranty, contact Taylor for return authorization and troubleshooting assistance.

Phone: 866-843-3905 (8-5pm MST, M-F)

Email: taylorusa@lifetimebrands.com

Web: taylorusa.com

There are no express warranties except as listed above. This warranty gives you specific legal rights, and you may have other rights which vary from state to state. For additional product information, or warranty information outside the USA, please contact us through www.taylorusa.com.

©2026 Taylor Precision Products, a Division of Lifetime Brands, Inc. All rights reserved.
Made in China.