


8cm

Smart Jump Rope




Please read the instructions carefully before using the jump rope.

Product Specification


Product Size	Φ23 x169mm /Rope size 3000mm
Product Weight	0.29 kg
LCD Display	19.6 x 8.1mm
Power	2 x 1.5V AAA
Max. Jumps	9999 times
Max. Time	99 Mins 59 Seconds
Min. Jump	1 time
Min. Time	1 second
Auto off Time	60 seconds

Product Feature




- 1.LCD display
- 2.Power on/Power off/Reset/Mode Button
- 3.Battery compartment
- 4.PU steel rope
- 5.Hanging rope

Product LCD Display



1. BT icon indicates connected
2. Battery indicator, it will flash when low power to remind you to charge.
3. Free jumping mode: jump without time or repetition limit.
4. Time countdown mode: jump with a time limit. You can choose from 30 seconds, 1 minute, 5 minutes, 10 minutes, and customized time on the Skipjoy App. Without the app, the device will record the last selected period of time.
5. Jump countdown mode: set a limit of jump ropes. You can choose from 50,100,500,1000, and customized jump ropes on the Skipjoy App. Without the App, the rope will record the last completed set of reps.
6. Number of jumps
7. Jumping time



Display in Different Modes




Installation of the Jump Rope

The jump handle and the rope are packed separately in the box, please follow the below steps to install the rope and adjust the length accordingly.


Important Note: To avoid inaccurate, please make sure the longer rope is installed in the inside part of the handle.



Instruction for install of hanging rope.



Battery installation:



Note:Please pay attention to the correct installation direction of the battery positive and negative electrodes, otherwise the product cannot be used normally.


Operation

1.Before starting using the jump rope, please download the App: **Skipjoy** from App store or Google play. Or you can scan below QR code to download the App.



2.When you install the App, please accept the permission requirement on Bluetooth, GPS & Location if your phone is operated under Android system;


Note: It is required by Google that all the smart phones operated with Android Ver. 6.0 or above must ask for the permission of location if any BLE device could be scanned and linked through Bluetooth. Any private information would not be collected by the App. You can also refer to the official document of Google for more information: <https://source.android.com/devices/bluetooth/ble>



Smart Skipping Rope




3.Open Skipjoy App, fill in your personal info, and start the App.



4.Skipjoy will automatically pair the jump rope, you can check the main interface on the App to check the status of connection.

●"Connected" shown on the main interface means successful pairing.
●"Disconnected" shown on the main interface means unsuccessful pairing. In this condition,please press "Mine" --> "Device" --> "+" to add the device manually.

5.Click the mode you need on the main interface on the App to start your jumping;




Jump Modes

Free Jumping / Time countdown Jumping / Numbers countdown Jumping

- 1.Keep pressing the button for about 3 seconds to shift the mode you need.
- 2.You can also choose the mode from App.


Free Jumping:

Jump the rope freely and there is no limit on time and number of jumps.




Time countdown Jumping:

- set the total jumping time.
- options for time can be set on App: 30 sec, 1 min, 5 min, 10 min, and customized time;
- Without the App, the rope will use the last countdown setting of time from the App.



Numbers countdown Jumping:

- set the total jumps;
- options for number of jumps can be set on App: 50, 100, 500, 1000 and customized number of jumps.



Offline storage function

Without the running of App, the data of your jumping will be recorded temporarily by the rope and synchronized with the App after re-connection.

Reset the rope

Press the button on the back of the LCD display for 8 seconds, the rope will be reset. The LCD will show all the signals for 2 seconds and then shut down. Press the button again to enter the normal use.

Caution and Maintenance

- Do not put the rope in very wet or hot environment.
- Avoid hitting or dropping the rope violently, otherwise damage may occur.
- Treat the rope with care as it is an electronic instrument.
- Do not immerse the handle into water or use it while raining, because it is not waterproof and damage may occur to the built-in electronic device.
- The rope is only used for the purpose of physical exercise. Do not use it for other purposes.
- Be careful when using the rope to avoid any injuries, and children under 10 are suggested to use the rope under the watch of parents.

Battery and recharge

Battery: The rope has a built-in Lithium-ion battery which could sustain normal use of about 25 days (calculated based on a daily use of 15 minutes, actual using time varies according to the environment and time of use). The typical stand-by time is 33 days (experimental data of the manufacturer under the temperature 25°C and humidity 65%RH).

Recharge: If the signal shows on the screen, please recharge the rope using a normal mobile phone charger with a standard Type-C USB plug. During the charging process, the battery signal of the LCD will flash until the battery is full.

Tips for battery:

- For the better life span of the battery, do not leave the rope with no battery for a long time. It is suggested to charge the rope when the battery is low. When you do not use the rope for a long time, it is suggested to charge the rope once a month.
- Do not open the handle lest any damage would happen to the rope.
- Do not burn the handle with batteries to avoid explosion of the battery.
- The rope should not be disposed of with household waste. Please check with your local authority for battery recycling advice.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1)This device may not cause harmful interference.
- (2)This device must accept any interference received, including interference that may cause undesired operation.



Dispose of the device in an environmentally friendly manner
Dispose of it at a recycling center for used electrical and electronic devices.
You can obtain more information from your local authorities.



The packaging material is recyclablePlease dispose of it in an environmentally friendly manner and take it to a recycling center.

风琴式折法

157g 铜版纸



Made in China
Model:RS1949LB