


Desktop Setup

01 Connect network cable to blue port on Amber.


1. If using a standalone modem, connect the other end to Network port.



Desktop Setup

02 Connect power cable, then power on.

2. If using a combination modem/router, connect the other end to LAN port.




- The color of the WAN and LAN ports are not necessarily as shown – please read the label on your modem device.

Desktop Setup

02 Connect power cable, then power on.


- Wait for LED ring to turn yellow and go to next step.




Desktop Setup

03 Connect Desktop to Amber Network with one of the following methods.

1. Connect Desktop/Laptop LAN cable to Amber LAN port.




2. Find WiFi SSID (Network Name) and connect to the Amber WiFi.



- WiFi SSID and password.
- Use the preset WiFi SSID and password on the label to connect to Amber WiFi network.


Desktop Setup

04 Go to <https://latticerouter.local> and follow the guide to complete setup.



- Different PC platforms may cause trouble of using above URL. Please connect 192.168.0.1 if you cannot access Amber. For more details, please see www.myamberlife.com/support/setup/.

SPEC Overview



Amber LED Ring Indicators

- White Blinking: Amber is booting up.
- Cyan Solid: Amber is working well.
- Amber Blinking: Amber is shutting down.
- Red Related: System errors.

- Cyan Blinking: Amber lost Internet connection.
- Blue Solid: Amber is in network only mode.

For more information, please see <https://www.myamberlife.com/support/>.