



Part # 900923

- 1. My mobile phone can't find any new Bluetooth devices?**
Make sure the Bluetooth speaker has entered pairing mode; and is within the effective working range.
- 2. Bluetooth devices can't pair up**
 - a) Make sure your mobile phone allows a new connection, and did not reach the maximum allowed connections, please refer to your mobile device manual.
 - b) Make sure you click the right Bluetooth pairing name.

- a) Make sure your mobile phone supports A2DP and HSP (hands-free) profile.
- b) Ensure your mobile phone is within effective working range.

The Bluetooth A2DP/HSF drivers may be required to play via Bluetooth Connection. But the driver is actually needed for the Bluetooth module on your PC, and not the speaker. Different Bluetooth modules may require different drivers. Please contact your PC or Bluetooth module's manufacturer for driver updates.

a) When you are using 3.5mm AUX audio in connection, you can't pause, change volume or skip tracks with the buttons on the speaker.

The speaker also features 1x AUX audio in port, simply connect the speaker to your non-Bluetooth mobile phone/MP3 player/PC/laptop with the 3.5mm audio cable. The green light turns on, and you can play via wired connection.

LED indicator light will RED flash to remind you to charge if battery is low (battery only 10% battery power remains).

Connect the micro USB charging cable to a computer or USB charger, a red LED indicates charging status. The Red LED turns off when fully charged. (4-5 hours for charging)

Charging interface: Micro USB; Input 5V

- a) Keep it dry and avoid damp places to avoid the product's internal circuit being affected.
- b) Keep the product away from direct sunlight or hot places. High temperatures will shorten the life of electronic devices, destroy the battery or distort certain plastic parts.
- c) Don't expose the product to extreme cold. It may damage the internal circuit board.
- d) Don't try to disassemble the product, any evidence of tampering will void the warranty.
- e) Don't use intensive chemical products or detergent to clean the product.
- g) Don't scratch the surface with sharp tips.

Length: 77.8mm $\pm$ 0.2mm
Width: 74.7mm $\pm$ 0.2mm
Height: 190.8mm $\pm$ 0.2mm
Material: ABS + Fabric
Weight: 560g $\pm$ 5g



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

09

Diagram illustrating the controls and features of the Sony WH-1000XM3 headphones:

- Slide Next/Previous:** Control for navigating between tracks.
- USB Charging / LINE IN:** Ports for charging and audio input.
- Mode Change Button (OUTDOOR / INDOOR):** Button for switching between outdoor and indoor modes.
- Power ON/OFF Play / Pause & Handsfree Calling:** Multifunction button for power, play/pause, and calls.
- Rotary Volume +/-:** Rotary control for adjusting volume.
- Swappable Fabric Cover:** Feature showing the interchangeable fabric cover on the side of the headphones.

- **Bluetooth Compatibility:** It is compatible with Bluetooth 4.1 Class II and supports A2DP V1.2, AVRCP V1.4 profiles.

AUDIO **SOUNDTUBE**
BT WIRELESS PREMIUM HI FI SPEAKER **PRO**

USER MANUAL



Note:

1. Under Bluetooth mode when the 3.5mm audio plug is inserted, the speaker will switch to line in status automatically;
2. When not in use, turn off the device to save power.

Note:

1. Under Bluetooth mode when the 3.5mm audio plug is inserted, the speaker will switch to line in status automatically;
2. When not in use, turn off the device to save power.

WORKING TEMPERATURE	STORAGE CONDITION
Temperature: 0° C ~ 40° C Humidity: 0% ~ 85% RH	Temperature: -30° C ~ 60° C Humidity: 0% ~ 90% RH

WORKING TEMPERATURE	STORAGE CONDITION
Temperature: 0° C ~ 40° C Humidity: 0% ~ 85% RH	Temperature: -30° C ~ 60° C Humidity: 0% ~ 90% RH

Power ON / OFF	Press & Hold  to power on/off.
Volume – or +	 Turn Rotary Dial clockwise to turn the Volume up, counterclockwise to turn the Volume down.
Next/Previous	In the Bluetooth mode, slide to the right to get to the next track and to the left to get to the previous track <<< >>>.
Play/Pause	When playing music, tap  to Pause/Play

WORKING TEMPERATURE	STORAGE CONDITION
Temperature: 0° C ~ 40° C Humidity: 0% ~ 85% RH	Temperature: -30° C ~ 60° C Humidity: 0% ~ 90% RH