


Diagram of the back of the device showing the volume and power buttons. The volume buttons are represented by a '+' sign and a '-' sign. The power button is represented by a circle with a vertical line through it. Below the power button is a small square icon with a diagonal line. At the bottom, there is a small oval containing the text 'NO SIM CARD'.

BASIC OPERATIONS



Power On/Off - Long press the "O" button for 2-3sec
Incoming Call - Short press "O" to answer
 double press "O" to refuse
Call/Hang Up - During a call, short press "O" to hang up
Pause/Play Music - Short press "O" when playing music to Pause or Play

Short press - to adjust the volume down, long press the - for the previous track
Short press + to adjust the volume up, long press + for the next track

Short press "🔊" to turn on/off TWS
Long press "🔊" for 2-3sec to disconnect from Bluetooth

LED Indicator

TWS Indicator

Micro USB Charging Port

Aux Input

POWER ON	LED indicator flashes Blue
BLUETOOTH MODE	PLAY/PAUSE: LED indicator solid Blue
	LED indicator flashing Blue, connected device out of range (10m/30ft). If speaker is left in unconnected in pairing mode for over 10 minutes, the speaker will turn off to preserve battery.
AUX IN MODE	LED indicator solid Green
CHARGING STATUS	LED indicator solid Red
	LED indicator turns off when fully charged
LOW BATTERY INDICATOR	LED indicator flashes Red
TWS	TWS indicator flashes White when pairing
	TWS indicator solid White when paired

2

Indicator LED

Power Button (On/Off) / Multi-Function Button

Long press the "O" button for 2-3 seconds to power on the speaker. You will hear an alert tone. The speaker will enter Bluetooth pairing mode notated by the blue indicator LED blinking.

3

Bluetooth

My Device

SoundTube Pro V3

Find "Soundtube Pro V3" in your Bluetooth device list on your mobile phone, tablet or PC.

4

RoHS CE FCC  
MADE IN CHINA

LED Indicator

The LED indicator on the speaker will be a solid blue and you will hear a beep once the device is paired successfully. The device is now paired and you can start enjoying your SoundTube Pro V3.

5

Turn on two Pro V3 speakers and press the button on each speaker to begin the TWS pairing sequence. You will hear an alert tone and the TWS indicator on both speakers will flash white. Once the automatic pairing is complete, you will hear another alert tone and the TWS indicator on both speakers will be a solid white. Once pairing has been completed, open the Bluetooth settings on your device and select "SoundTube Pro V3" from the Bluetooth device list. This will sync your device to the paired Bluetooth speakers. To disconnect a speaker from the TWS link, simply press the button on the speaker you wish to disconnect. The TWS indicator of the speaker that is no longer paired and connected to your device will turn off.

NOTE: For TWS pairing, you must first pair two speakers together prior to connecting your smartphone or device.

6

PRODUCT NAME	SOUNDTUBE PRO V3
MODEL NAME	901454
BLUETOOTH VERSION	5.0
BATTERY CAPACITY	4000m Ah
WORKING TIME	7-8 HOURS (70% VOLUME)
CHARGING TIME	4-5 HOURS
CHARGING CURRENT	5V=1.8A
DRIVER UNIT	30W = 15Wx2
DIMENSION	211 x 84 x 82.8mm (8.3 x 3.3 x 3.2 inches)
WEIGHT	698.53g (1.54 lbs)
WATERPROOF	IPX7 RATING

7

*This speaker supports mobile phones, tablets, PC, etc. Images and steps provided are based on a mobile phone experience.

1 YEAR WARRANTY



8