

Size: 105(x2)mm x140mm

105mm

FCC Statement

This device complies with Part of the FCC Rules. Operation is subject to the following two conditions: 1) This device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception (which can be determined by turning the equipment off and on) the user is encouraged to try to correct the interference by one or more of the following measures;

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

IMPORTANT:

- Remove batteries if left unused for long periods.
- Do NOT use different types of batteries at the same time.
- Do NOT mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- Only recommended batteries are to be used.
- Alkaline batteries are recommended for best use.
- Do NOT use new and old batteries at the same time.
- Do NOT attempt to re-charge non-rechargeable batteries.
- Rechargeable batteries are only to be charged under adult supervision.
- Be sure to install batteries with the polarities aligned correctly.
- When batteries are exhausted, remove them to prevent damage or danger.
- Do NOT attempt to short circuit the terminals.
- Do NOT dispose of in a fire as batteries may explode or leak.



wireless remote control

WHEREVER LITE™

INSTRUCTIONS

KEEP INSTRUCTIONS FOR FUTURE REFERENCE

Model : 38918

READ CAREFULLY BEFORE FIRST USE

Unlike ordinary infrared battery operated lights, Wherever Lite operates on radio frequency. This means that the Wherever Lite remote works up to 50 feet away, through walls, doors, furniture, and more—without interference!

HOW TO INSTALL BATTERIES ON THE WIRELESS REMOTE CONTROL

1. Locate the battery compartment on the back of the remote.
2. Place 1 "23A" batteries inside, making sure the polarities are properly matched. Match "+" and "-" symbols that are on the battery ends to the marks inside the battery compartment.
3. Replace and close the cover.

HOW TO INSTALL BATTERIES ON WHEREVER LITE

1. Locate the battery compartment on the bottom of the light. Turn the cover counter-clockwise and remove.
2. Place 2 "AA" batteries inside, making sure the polarities are properly matched. Match "+" and "-" symbols that are on the battery ends to the marks inside the battery compartment.
4. Replace cover and turn clockwise to close.

ABOUT INDIVIDUAL AND GROUP LIGHTING

INDIVIDUAL: Your Wherever Lite comes all ready to use if you plan to use one Wireless Remote Control with one Wherever Lite!

GROUP: You can program the Wireless Remote Control to operate multiple Wherever Lites from the press of a button and set up is a breeze!

HOW TO INSTALL WIRELESS REMOTE CONTROL AND WHEREVER LITE

WIRELESS REMOTE CONTROL—Use the "keyhole" on the back of the remote to screw mount, OR, peel off the adhesive paper on the back and stick it to the desired location.

WHEREVER LITE—Remove the battery compartment on the back of the Wherever Lite and attach it to the desired location using screws, OR peel and stick on the back and stick it to the desired location.

HOW TO USE THE LIGHT

1. You can operate the Wherever Lites either by switching the remote to the "On" position, OR you can simply press the center of the Wherever Lite.
2. To use dim the light, simply press and hold the "On" position on the remote.
3. To turn light off, either switch the remote to the "Off" position, OR press the center of the light.