

工艺：70g书纸 +四色, 双面印刷, 扇形折 x 4,再对折
料号：98-01-2394A 折成形后尺寸:140mm*210mm



Wireless TV Headphones for Seniors



YouTube video

(APH100)

USER GUIDE

3. Check Your TV' s Output Ports

	AUX/3.5mm	RCA(Red/White) AUDIO OUT	Optical Output	Other RCA jacks
Jack Options				
Natively Supported?	✓	✓	✗	✗
Please refer to Point:	4.1	4.2	4.3	N/A

4. How To Use

4.1 AUX/ 3.5mm Audio Out

4.3 Optical Output

If your TV only supports optical output, you need an extra optical adapter for connection.

5. TV Setting

SONY TV:

Headphones or speakers

Options

Settings

Sound

Headphone/Audio Out

Headphone (3.5, RCA, Optical) ✓

Whether has sound at the same time

Options

Settings

Sound

Speakers

TV Speakers (TV and headphone have sound at the same time)

Audio System (Headphone has sound)

SAMSUNG TV:

connecting fiber optical method

MENU/ Press TV or remote control

Settings

Sound

Other Settings

S/PDIF Output (Fiber optical output)

TV Speaker (3.5, RCA)

Output setting 1:

MENU/ Press TV or remote control

Settings

Sound

Sound Output

External Speaker/ Audio Out (Sound or headphone have sound at the same time)

Output setting 2:

MENU/ Press TV or remote control

Settings

Sound

Speaker Settings

Speaker Select

External Speaker (internal device)

TV Speaker (TV speakers) (3.5, RCA, Optical)

Optical (Fiber optical output)

Optical (Headphone has sound at the same time)

1. What' s In The Box:

2. Charging:

Before use, please charging for 3 hours.

-1-

3. Check Your TV' s Output Ports

	AUX/3.5mm	RCA(Red/White) AUDIO OUT	Optical Output	Other RCA jacks
Jack Options				
Natively Supported?	✓	✓	✗	✗
Please refer to Point:	4.1	4.2	4.3	N/A

4. How To Use

4.1 AUX/ 3.5mm Audio Out

4.2 RCA AUDIO OUT (Red/White ports labeled "AUDIO OUT")

4.3 Optical Output

If your TV only supports optical output, you need an extra optical adapter for connection.

5. TV Setting

SONY TV:

Headphones or speakers

Options

Settings

Sound

Headphone/Audio Out

Headphone (3.5, RCA, Optical) ✓

Whether has sound at the same time

Options

Settings

Sound

Speakers

TV Speakers (TV and headphone have sound at the same time)

Audio System (Headphone has sound)

SAMSUNG TV:

connecting fiber optical method

MENU/ Press TV or remote control

Settings

Sound

Other Settings

S/PDIF Output (Fiber optical output)

TV Speaker (3.5, RCA)

Output setting 1:

MENU/ Press TV or remote control

Settings

Sound

Sound Output

External Speaker/ Audio Out (Sound or headphone have sound at the same time)

Output setting 2:

MENU/ Press TV or remote control

Settings

Sound

Speaker Settings

Speaker Select

External Speaker (internal device)

TV Speaker (TV speakers) (3.5, RCA, Optical)

Optical (Fiber optical output)

Optical (Headphone has sound at the same time)

-1-

-2-

-3-

-4-

LG TV:

Output setting 1:

MENU

Press smart by remote control or setting

SOUND

Sound Out

TV Speaker (TV has sound)

LG Sound Sync (Optical)

LG Sound Sync (Wireless)

External Speaker (Optical/HDMI/ARC)

Headphone (3.5, RCA, Optical, Headphone has sound)

Digital Sound Out <PCM> (Fiber optical output)

6. Phone-Test

If no sound although connect via 3 different ways, please follow "4.1 AUX/ 3.5mm Audio Out" to connect Smartphone via 3.5mm cable to test the item.

7. Re-Pair Step

8. Sound Balance

For people with hearing problem on only one side.

9. Hearing aids (Don' t need transmitter.)

This function is for daily hearing, help the elderly and the hearing impaired improve their hearing.

Note: In this mode, it will amplify all sound around you. Please do not press MIC when using to watch TV.

10. FEATURES:

30 meters wireless range
One transmitter can be connected to several headphones
Ultra clear stereo sound selectable
Adjustment of tone clarity

11. SPECIFICATIONS

Item	Specifications
Operating Voltage:	Transmitter 5V
Headphone:	3.7V 350mAh
Carrier Frequency:	2.4GHz
Frequency Response:	20Hz-20KHz
Operating Distance:	30 Meters
Distortion:	<0.5%
Charge Time:	4 hours
Working Time:	8 hours

12. TONE CLARITY

When necessary, Tone Clarity to Headset Receiver can be adjusted on the Transmitter, from orange LED of 1, 2 and 3. Simply press the Tone Clarity Button to select and match to your level of hearing aid capability.

The Tone Speech Intelligibility can be enhanced individually on the transmitter with the following settings.

13. CAUTION

To protect your hearing, please do not use the headphone at high volume for long time.
Wireless transmission will produce electromagnetic signal which may interfere the heart pacemaker or other medical instruments properly function. Please follow your doctor' s instruction.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

14. Troubleshooting

1. The sound is noisy, or no sound in the headphones.

Please see whether you plug the cable into AUDIO IN jack, and notice other wireless devices, such as routers, TVs, may interfere with the signal of the headset. Keep them away from the transmitter.

2. Surrounding sounds loudly, even heard my heartbeat.

In this case, you can see the headphone's LED lights RED. It' s hearing-aid mode that will amplify all sound even your heartbeat and breath. Please press MIC once, the LED changes to GREEN, headphone switches to watching TV mode.

3. Only one side can hear sound.

Please check the status of sound balance button. Turn to L, left sound will be louder and right sound will weaken. Turn to R, right sound louder. The normal reason for this problem is that the 3.5mm cable is connected to the Audio & Video jack on the TV, it can only output one channel. Then can connect with RCA cable.

4. This headset will automatically shut down.

with no audio input or audio sound is too weak for 5 minutes, the headset will automatically enter the power saving mode, you need to re-open the audio and restart the headset if use it again.

Any question? Please contact us.

ARTISTE TECHNOLOGY LTD.
The 6th Building, No. 173, Dunhe Road,
Haizhu District, Guangzhou, Guangdong, China
www.artiste-audio.com
Tel: 86-20-84138903
Made In China

-5-

-6-

-7-

-8-