

A02PRO_QSG_iONE

展開尺寸: W560X H100 MM

折疊尺寸: W80X H100 MM

材質：雙銅157g

顏色： 1C印刷

公差: $+/-0.5\text{mm}$ 裁切線: 折線:

料號:

正面



AQUARIUS-02PRO

WIRELESS ACTIVE NOISE CANCELLING HEADPHONES

QUICK START GUIDE

A02PRO

- 40mm Hi-Resolution drivers built with special tuning
- Aluminum diaphragm
- Advanced hybrid active noise cancellation Digital processor
- Support Sony LDAC Hi-Resolution Bluetooth Audio Codec
- Build-in Spatial Audio Technology
- Ambient and music balance control
- 5 Audio enhanced equalizer presets for Jazz / Classic / Dance / Rock / Pop music

PACKAGE CONTENT

- Headphone (Model Name: A02PRO)
- USB Type-C Charging Cable
- Headphone Jack Adapter
- 3.5mm Audio Cable
- Quick Start Guide

HARDWARE REQUIREMENTS


- Compatible with BT 5.0 device

APP REQUIREMENTS

- Android 6 / IOS 12

PRODUCT OVERVIEW

- Headset (40mm Hi-Resolution Dynamic Drivers)
- Self-adjusting Headband
- Protein Ear Cushion
- 1.2 Meter USB Charging Cable
- 1.8 Meter 3.5mm Audio Cable
- Airplane 3.5mm Headphone Jack Adapter
- Power/Pairing Button
- Play/Pause Button
- Normal/ANC/Ambient Mode Button
- Volume Up Button
- Volume Down Button
- Microphone
- Auxiliary Jack (AUX cannot be used at the same time while charging)
- USB Type C Jack



















START USING

WIRELESS MODE

RECHARGE

Plug the **[D. USB Charging Cable]** (TYPE C) into the earphone and the other end (TYPE A) into the computer USB port to start charging. Let the battery is fully charged before its first use.

- Low battery: Red light flashes every 5 minutes, and the voice prompt battery low
- Charging: Light will turn solid red
- Charging completed: Light will turn solid green
- Battery is too low: The red light flashes for 1 second and then shuts down

BLUETOOTH

- Turn on Bluetooth pairing mode (mobile phone): Press **[G. Power Button]** for 5 seconds, the red light and green light alternately flash for 60 seconds
- Pairing is complete: Blue light flashes for 2 seconds, voice prompt Connected

POWER ON/OFF

- Power on: Press **[G. Power Button]** for 2 seconds, the green light will be on for 2 seconds, and the voice prompt Power On
- Power off: Press **[G. Power Button]** for 2 seconds, the red light will be on for 1 second, and the voice prompt Power Off

PLAY

- Play/Pause: Press the **[H. Play/Pause Button]** once
- Volume +/-: Press **[J. Volume Up Button]** once / Press **[K. Volume Down Button]** once
- Previous song: Press and hold the **[J. Volume Up Button]** for 1 second
- Next song: Press and hold the **[K. Volume Down Button]** for 1 second

WIRED MODE

After powering on, plug **[E. 3.5mm Audio Cable]** into the headphone and the other end into the device to start using the earphone

- In use: steady green light
- Power off: Red light lasts for 1 second

⚠ In wired mode, but you need to use equipment to control the play such as a computer

FCC

Federal Communications Commission (FCC) Statement

You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation of the device.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

FCC RF Radiation Exposure Statement:

The product complies with the FCC portable RF exposure limit set forth for an uncontrolled environment and are safe for intended operation as described in this manual. The further RF exposure reduction can be achieved if the product can be kept as far as possible from the user body or set the device to lower output power if such function is available... This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

SRRC

不得擅自更改发射频率、增大发射功率(包括额外加装发射功率放大器)、不得擅自分割天线或改用其他发射天线。

使用时不得对合法设立的无线电通信业务产生有害干扰;一旦发现有干扰现象时,应立即停止使用,并采取措施消除干扰后方可继续使用。

使用低功耗无线电设备,必须避免造成各种无线电业务的干扰或工业、科学及医疗用途的设备干扰。

不得在 飞机和机场附近使用。

NCC

取寄書翰證明之低功率射頻器材、非經核准,公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。低功率射頻器材之使用不得影響飛航安全及干擾合法通信;經發現有干擾現象時,應立即停用,並改善至無干擾時方得繼續使用。前述合法通信,指依電信管理法規制定作業之無線電通信。低功率射頻器材須符合技術或工程、科學及醫療用電波輻射性電磁場之干擾。

WARNING

- To avoid hearing damage and damage to the earphones, use the earphone at a comfortable, moderate volume level. Turn the volume up gradually until you reach a comfortable level.
- Earphones should keep away from fire, or in the situation with high temperature or high pressure.
- Do not immerse the earphones into the water or place the earphones in high humidity situation for long time.
- Stop using the earphones if you find liquid leakage, overheating or other unusual conditions.
- Do not try to disassemble or short circuit the earphones.

Innovation In Life Style

01

02

03

04

05

06

反面

[illegible]