


 ALMIGHTY ONE  Model: MOCROX-5287 User Manual	1. Silicone ear cap assembly Before using the headset, choose a silicone cap that fits your ear-hole size so that the sound quality of the headset can be perfect.  Step 1: turn the silicone cap over  Step 2: the metal front with silica gel cap after face, about 45° degrees, with their thumb forefinger, holding the silica gel plug, Plug into the metal front slot  Step 3: turn the silicone back in place and you can wear it. 2. Start to use the neckline Bluetooth headphone  Step 1: slide the slider to the bottom, or the location where you want it.  Step 2: pull the wire out.  Step 3: after the neck is worn, the earphone is inserted into the ear hole to be used 3. Put the headphone away and collection  Step 1: gently press the slider in the direction of the earphone line, pull the slider back, and the earphone line will be accepted into the slot.  Step 2: press the cables will be sliding block into the slot, pull back to the middle of the position. After receiving exposure about 1.5 to 2 cm of earphone line.  Step 3: fold the headphones into the bag 4. key manual  (+) key: volume up; next song (-) key: volume down; last song - Multi-function key: power on/off, play/pause, answer the phone LED Mic 5. Operation instructions Power on: long press multifunction button to blue light. Power off: long press the multifunction button to red light. Pairing: long press the multifunction button 6-8 seconds to the red light and the blue light flashing alternately. Volume adjustment: music or mobile phone call state, short press volume (+) key volume increase, short press volume (-) button volume decrease. Track selection: music playback mode, long press the (+) key to select the next song, and the long press the (-) key to select the last song. Pause/skip: music playback mode. Short press multi-function button music pause, again short press multi-function button music play. Answer/call: short press multi-function button. Last call redial: double-click the multifunction button to dial the last number. Battery power check: the phone that needs to support the power display will display the current headphone battery. 6. Product specifications, LED light instructions <table><tr><td>Bluetooth version :4.1</td><td>Bluetooth chip :CSR8645</td></tr><tr><td>Call/music time :8H</td><td>Charging time :2.5h</td></tr><tr><td>Speaker Diameter :φ10mm</td><td>Sensitivity: 110 db +/- 3 db</td></tr><tr><td>Impedance : 32Ω±15%</td><td>Frequency range: 20Hz-20KHz</td></tr><tr><td>Microphone sensitivity: -42db</td><td>Battery capacity :160 mAH</td></tr><tr><td>Transmission distance :10M</td><td>Working voltage :3.2V-4.2V</td></tr><tr><td>Low power alarm: red light flashing</td><td></td></tr></table> Charging: when charging is done, the red light is on and the red light is extinguished when charging. Bluetooth connection: blue light slow flash. Bluetooth not connected: blue light flash. Bluetooth pairing: red light and blue light flashing alternately.	Bluetooth version :4.1	Bluetooth chip :CSR8645	Call/music time :8H	Charging time :2.5h	Speaker Diameter :φ10mm	Sensitivity: 110 db +/- 3 db	Impedance : 32Ω±15%	Frequency range: 20Hz-20KHz	Microphone sensitivity: -42db	Battery capacity :160 mAH	Transmission distance :10M	Working voltage :3.2V-4.2V	Low power alarm: red light flashing	
Bluetooth version :4.1	Bluetooth chip :CSR8645														
Call/music time :8H	Charging time :2.5h														
Speaker Diameter :φ10mm	Sensitivity: 110 db +/- 3 db														
Impedance : 32Ω±15%	Frequency range: 20Hz-20KHz														
Microphone sensitivity: -42db	Battery capacity :160 mAH														
Transmission distance :10M	Working voltage :3.2V-4.2V														
Low power alarm: red light flashing															
7. Charging and pairing 1: charge Follow these steps before using your bluetooth headset: 1.Make sure your bluetooth headset is fully charged. 2.Please match the bluetooth headset with bluetooth function, Before we try Bluetooth for the first time, we recommend charging the battery first. 3.Please insert the plug of the bluetooth headset charging, can choose connect AC power car charger, USB cable cable connected to the PC, when charging, the red light is lit, finished. 2: Pairing The first step: Long press the function button of the control box. Power on (don't let go for about 6-8 seconds) and then Pairing, blue light and red light flicker start bluetooth to search status. The second step: Turn on the bluetooth setup, search and connect mocrox-5287, and the device connection is successful. If the pairing is successful, the next time you open the bluetooth device, it will memorize and automatically connect. After connecting to the new device, if you want to connect to the old device, the device will not be supported or unable to connect. Please delete the matching number mocrox-5287 that was connected before, and re-search mocrox-5287. 8. Warm tips When listening to music, don't exceed 60% of the volume, and don't listen for more than 60 minutes. People who listen to music regularly should have a "60-60 principle", which is internationally recognized as a way to protect hearing. When listening to music, the volume should not exceed 60% of the maximum volume, and the continuous listening time should not exceed 60 minutes. It is healthier to use ear in such a case. When connecting to any device, the default volume of the headset is 30 percent. The IOS phone can add the headset and phone volume to the loudest. Android mobile: can only add the headset to the full frame, unable to add the android mobile phone to the full frame. (android phone if the phone volume set to 8 frames, the loudest volume of the headset only be 8 frames of phone, when add phone volume to full frame, then headsets volume can adjust to the full frame of phone). Troubleshooting If you are unable to connect the headset to the bluetooth device, please try the following steps: ★ Please confirm whether the bluetooth function of the device is opened, and confirm that the headset is paired with the device. ★ Please check whether the headset and equipment are more than 10 meters away, whether there are electronic products or power supply and other signal interference. ★ If the headset does not automatically connect or listen to music, please recharge or reconnect with the headset. 9. Maintenance ★ Please turn off the earphone before putting the earphone in the pocket or bag, so as to avoid accidentally pressing the function button. ★ Do not expose the headset to a liquid or damp place. ★ Don't place the headphones on cutting temperature is very high or very low, the best environment for -10 °C to 60 °C, otherwise it will affect the service life of the headphones. ★ Do not expose earphones to open fire to avoid explosion hazard. ★ Do not contact the earphones with sharp objects, causing scratches and damage. ★ Do not take the headphones apart, they will damage the internal components. ★ If you don't use earphones for a long time, make sure you place them in a dry place. If you place them for more than one month, charge them on time to ensure the performance of the battery and earphones. 10. FCC ID and FCC Warnings FCC ID: 2APL6-MOCROX-5287 FCC Warnings: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna, - Increase the separation between the equipment and receiver, - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected, - Consult the dealer or an experienced radio/TV technician for help. 10. Warranty About the product warranty Thank you very much for purchasing Mocrox bluetooth headset. From the date of purchase, in the case of normal use, there will be a free warranty for one year. Warranty is limited to repair or replacement of defective parts. Improper use or intentional damage is not covered by the free warranty. Model NO: _____ Purchase date: _____ Phone number: _____ Address: _____ Mocrox Technology Limited															

封底

成品尺寸:90*110mm/双面黑色印刷/需折叠