




CH26

Quick Installation Guide

Setup & Connection


1. Position the Base

- Set the base on a flat surface. To adjust the stand's height, simply press the button on the back, as shown in the image below.



2. Device Interfaces

- ① Power Port: Connect the included power adapter here
- ② Network Port: For wired internet/LAN connections.
- ③ USB Port: Connects to USB devices for charging or data transfer.



(1) Power Connection

- Plug the included power adapter (5V/3A) into the base's power port. When powered on, you'll hear a startup sound and see a steady indicator light.

Important: Always use the original adapter. Other adapters may cause damage.

(2) Wired Network Setup

- Insert an Ethernet cable into the network port while the base is powered on.


Note: Your router/switch must provide data connection only—do NOT use PoE.

(3) Base USB Function

- USB drives, controllers, and keyboards can be connected.

Device Controls & Connectivity

1. Base Buttons



- **Bluetooth:** Toggle Bluetooth on/off | Enter pairing mode | Switch connected devices.
- **Volume Up/Down:** 1) Standby mode: Adjust ringtone loudness.
2) During calls: Control handset/hands-free volume.
- **Mute:** Mute/unmute the microphone.
- **Home:** One-tap return to main screen.
- **Back:** Navigate to previous screen.
- **Hand-Free key:** Activate hands-free calling—talk without holding the handset.


2. Using with Tablet & Handset

(1) Docking Tablet

- Align the tablet (W638C/W638W) with the top of the base—magnets will snap it into place.

(2) Pairing Handset

- Place the handset in the handset slot of the powered-on base. When the indicator lights up, the device is paired and ready to use.



NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC RF Exposure Warning Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment shall be installed and operated with minimum distance 20cm between the radiator & body.

Fanvil Technology Co., Ltd

Website: www.fanvil.com

Email: sales@fanvil.com support@fanvil.com

Tel: +86-755-2640-2199 Fax: +86-755-2640-2618

Add: 10/F Block A, Dualshine Global Science Innovation Center, Honglang North 2nd
Road, Bao'an District, Shenzhen, China