


Power Button


1. Long press: Power on/off the headphones.
2. Single press: Play/Pause media. (If receiving phone call, answer call)
3. Double press: Enter **Bluetooth pairing** mode. (If receiving phone call, **decline call**)
4. Triple press: Enter **dongle pairing** mode.



DSP Button

Single press: Cycle AINR (Active Intelligent Noise Reduction) → On → Level select → Off.


Long press: Toggle Sidetone → On → Off → On.



Mute Switch

Slide up: Mic Mute ON.


Slide down: Mic Mute OFF.



Volume Dial

Single clicks: Speaker Volume → EQs → Speaker Volume

- Default (no press):
 1. Rotate up: Speaker volume up.
 2. Rotate down: Speaker volume down.
- After 1st press: (EQ presets)
 1. Rotate right: Preset EQ select up.
 2. Rotate left: Preset EQ select down.
- After 1st press or after 10 seconds back to volume adjustment.
- Double click for this button : Previous track when in BT / USB / Dongle with application.



Game/Chat Mix Dial

Single clicks: G/C Balance ➔ Mic Volume ➔ Sidetone ➔ G/C Balance

- Default (no press): (Game/Chat mix)
 1. Rotate up: Game volume up / Chat volume down.
 2. Rotate down: Game volume down / Chat volume up.
- After 1st press: (Mic level)
 1. Rotate up: Mic volume up.
 2. Rotate down: Mic volume down.
- After 1 press: (Sidetone level)
 1. Rotate up: Sidetone volume up.
 2. Rotate down: Sidetone volume down.
- After 1 press: back to G/C balance with VP.
- Double clicks for this button: Next track when in BT / USB / Dongle with application.

