

[illegible]

6

Diagram 6 illustrates the assembly of the rear roller and drive roller. The components shown include:

- Rear Roller Assembly:** GX216-75, GX216-42, GX216-31, GX216-70, GX216-77, GX216-42, GX216-41, GX216-11.
- Drive Roller Assembly:** GX216-67, GX216-81, GX216-63, GX216-61, GX216-60, GX216-30, GX216-71.

SPARE PART LIST-2			
GK1010-21 	GK1010-22 	GK1010-23 	GK1010-24
GK1010-25 	GK1010-26 	GK1010-27 	GK1010-28
GK1010-29 	GK1010-30 	GK1010-31 	GK1010-32
GK1010-33 	GK1010-34 	GK1010-35 	GK1010-36
GK1010-37 	GK1010-38 	GK1010-39 	GK1010-40

The parts and images are subject to change without prior notification.

13

866-167



866-168



866-169


