


UL Listed 10000 mAh 15W MagClick
Wireless Power Bank with AC Plug

Model: AB0605



Features:

1. Wireless Charging Surface
2. 18W USB-A Output
3. 20W Type-C Input & Output
4. LED Indicator
5. Switch Button
6. Lightning & Micro Output
7. Type-C Output
8. Phone Holder

What's included:

- 1 x 10000mAh Power bank with Wireless Charger
- 1 x USB-A to Type-C Cable
- 1 x Instruction Manual

Tech Specifications

WALL CHARGER:

INPUT: 100-240VAC 50/60HZ 0.5A OUTPUT: 5V 3A;

POWER BANK:

Type-c Input & Output: 5V 3A, 9V 2.2A, 12V 1.67A;

USB-A Output: 5V 2.4A, 9V 2A, 12V 1.5A;

Wireless Output: 5V 1A, 9V 1.1A, 9V 1.67A;

Cable Type-c Output: 5V 2A;

Cable Lightning Output: 5V 2A;

Total Output: 5V 3A;

Battery/Cell capacity: 37Wh, 3.7V/10000mAh;

Product capacity(Type-c): 27.5Wh, 5V/4700mAh;

Product capacity(USB-A): 27.5Wh, 5V/5000mAh;

Product capacity(Wireless): 20Wh, 5V/4000mAh;

INSTRUCTIONS:

1. Single click the switch to turn on; double click the switch to turn off wireless charging and mobile power supply;
2. The digital tube indicates the power level the mobile power supply; during charging, the digital tube goes from 0% to 100% to indicate full charge; during discharging, the tube goes from 100% to 0% to indicate the power is depleted;
3. The red LED is the indicator light for wireless charging it stays on during wireless charging; it blinks when there is a foreign object.

Warning: See Instruction Manual Before Use.

CAUTION: Risk of Fire and Burns. Do Not Open, Crush, Heat in high ambient temperature or Incinerate. Follow Manufacturer's Instructions

SAFETY PRECAUTIONS:

WARNING-When using this product, basic precautions should always be followed:

1. Read all the instructions before use.
2. Never store or use this product in temperatures below 32°F (0°C) or above 115°F (45°C).
3. Do not overcharge your phone. The unit may become hot under excessive use. Remove your phone once it is fully charged. Never charge your phone for more than 7 hours at a time.
4. To reduce the risk of injury, close supervision is required when the product is used near children.
5. Do not expose the device to moisture.
6. Do not use the device in excess of its output rating. Overload outputs above the rating may result in a risk of injury.
7. Do not use the device if damaged or modified.
8. Damaged or modified batteries may exhibit unpredictable behaviour resulting in fire, explosion or risk of injury.
9. Do not disassemble the device. For repairs, seek a qualified service professional. Incorrect reassembly may result in a risk of fire or injury.
10. Do not disassemble the device. For repairs, seek a qualified service professional. Incorrect reassembly may result in a risk of fire or injury.
11. Do not expose the device to fire or excessive temperatures. Exposure to fire or temperatures above 104°F (40°C) may result in explosion.
12. To ensure product safety, ensure that qualified service professionals use only identical replacement parts.
13. Attachments on the back of your phone can impede the effectiveness of the wireless charger, and lead to overheating. Please remove attachments from the phone before charging on this device.

FCC Statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: should always be followed:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Information and Copyright

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC RF warning statement: the device has been evaluated to meet general RF exposure requirement . The device can be used in portable exposure condition without restriction.