


**Don't
Panic!**

X1 Pro


User Manual

English


[Packing List]




X1 Pro Main Unit



Earbuds (L\R)



Type-C data cable



Ear tips - 3 Sets




Ear hooks - 1 Set



manual

[Know Our Product]



[Quick Start]

1.Startup/Shutdown/Restart

When the device is off, press and hold the Power button for 3s to turn on; When the device is on, a single click of the Power button can wake up or turn off the screen.
Press and hold the Power button for 3s to shut down or restart the device.

2.Charging

Charging the main unit: Connect the type-C data cable to a standard power adapter. The X1 model supports a 5V-1A and 5V-2A charger.

*Note: The earbud charging case may eject when the data cable is inserted. Push the earbuds back into place while inserting the data cable. Avoid using excessive force when removing the cable after charging.

3.Charging the earbuds

Tap the bottom of the main unit for the earbud charging case to eject. Once taken out, the earbuds will connect to the main unit automatically.

4.Wi-Fi Connection

The Online Translation function requires a WiFi Connection: A more stable WiFi connection will result in a more accurate translation.

5.Removing the Earbuds

Tap the bottom of the main unit for the earbud charging case to eject. Once taken out, the earbuds will connect to the main unit automatically.

6.Return to the previous menu

Click the Back button on the front of the main unit for the system to return to the previous menu;Adjust the main interface menu sequence.


* Description of the earbud microphone (L\R) recording channel

In Multi-person Translation and Listen & Play modes, the system uses only one earbud as the microphone.

- If you remove both earbuds at the same time, the first one taken out automatically becomes the recording earbud; the other is listen-only and cannot record.
- To switch the recording earbud, simply tap the touch area on either earbud—the mic instantly switches to that side.

7.Setting the Volume

Click the Volume button for the system to adjust the translation volume on the main unit. Set the earbud volume or the prompt tone on the main unit touch screen.



8.Simultaneous use of multiple devices

Multi-person Translation supports up to 5 X1 Pro devices in the same session, enabling flexible and efficient multilingual communication. (See feature details below.)

[Functions]

1. Multi-person Translation

Ideal for: meetings, training sessions, presentations


- The host creates a meeting room using their X1 Pro.
- Others join by scanning the QR code displayed on the X1 Pro screen with their smartphone or device.
- Supports real-time, two-way conversation with seamless translation.
- Additional X1 Pro users can join the same meeting by entering the meeting code.
- Up to 5 X1 Pro units can be connected simultaneously.



2. One-on-One

Ideal for: face-to-face conversations between two people

- Each person wears one earbud and selects their native language.
- Once started, speak freely—the system automatically detects who's talking and translates both sides in real time.



3. Listen & Play

Ideal for: attending lectures or meetings as a listener

- In settings, choose:
 - Source language (the speaker's language)
 - Target language (the language you want to hear)
- Place the X1 Pro near the speaker, put on your earbuds, and listen to live translations.
- To speak, tap the "Speak" button on the screen.



4. Media Translation

Ideal for: phone calls or video conferences

- In this mode, pair "Timekettle X1 Pro" via Bluetooth in your phone or computer settings.
- Set your source and target languages.
- The other person's speech is translated and played through your earbuds.
- Your speech is translated into their language and sent back in real time.

 **Tip:** If translation isn't working, check that your device's microphone and speaker are set to "Timekettle X1 Pro."



5. Ask & Go


Ideal for: quick interactions like asking directions or ordering food

- Select both languages from the list.
- Hold the Back button to speak—the system auto-detects your language.
- Release to play the translation aloud.



Quick Start

Long-press the Back button on the home screen to launch Ask & Go instantly—no menus required.



6. Translation Settings

Available in all modes

Tap the Settings icon (top right) to adjust:

- Font size
- Voice playback speed
- Show original text (on/off)
- Enable AI-powered translation (for higher-quality results)

[FAQs]

1. Why isn't the translation accurate?

- Check that the correct language settings have been selected, try to employ a standard accent when speaking, and check that the language for your partner has also been chosen correctly.
- Next, check that you are wearing the earbuds correctly, and the microphone (on the stem) is positioned toward the mouth. If the main unit is being used for recording, keep it as close to the sound source as possible and avoid excess noise interference.
- Speaking too low or too fast or slow may affect the quality of the translation. The corresponding parameters can be adjusted in Translation Settings;

2. Why is the translation function not working at all (or working very badly)?

- Check your WiFi connection. An unstable network will directly affect the translation speed and Accuracy. Try changing the WiFi network, connecting to the phone hotspot, or enabling the Offline Translation.
- The earbuds might not be connected properly and could be hindering the activation of the translation function. Try placing the earbuds back into their charging case and then taking them out to re-establish the connection.
- The earbud battery might be running low or may not have charged properly. Try putting them back in the charging case.

3. Why is the earbud volume too high or too low?

- The earbud volume setting might be abnormal. Try activating the pop-up window to adjust the earbud volume settings via the touch screen by clicking the Volume button on the main unit.

4. Why can't I connect my earbuds?

- It is possible for an earbud connection to fail. Put the earbuds back into the charging case and take them out again to reconnect.

5. Why is the main unit system stuck or abnormal?

- Press and hold the Power button for 3s to restart the X1 system;
- Press and hold the Power button for 20s to force the system to restart.

[FCC]

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
Note

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

[CE]

CE Maintenance

1. Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.
2. The product shall only be connected to a USB interface of version Type C.
3. EUT Operating temperature range: -10°C to 45°C.
4. The device complies with RF specifications when the device is used at 0mm from your body.

*Declaration of CE conformity:

<https://www.timekettle.co/pages/x1-pro-declaration>



Warranty Card

Name:

Location of purchase:

Time of purchase:

Contact number:

E-mail:

Address:

Postal code:



🌐 www.timekettle.co

✉ support@timekettle.co

☎ (+86) 400-808-8242 (简体中文)

+1(833) 491-1328 (English/Español)