



CONTENTS	
READ BEFORE USE	01
IN THE BOX	02
PRODUCT OVERVIEW	02
Projector	02
Remote Control	03
QUICK START	04
1. Projector Installation	04
2. Power On/Off	05
3. Remote Control Pairing	05
4. Setup Wizard	06
5. Image Adjustment	06
PROJECTOR CONNECTION AND INPUT SOURCE	09
WIFI CONNECTION	09
GOOGLE ASSISTANT	10
GOOGLE CAST™	10
BT SPEAKER MODE	11
MORE SETTINGS	12
PROJECTION DISTANCE AND SIZE	13
SPECIFICATION	13
TROUBLESHOOTING GUIDE	14

6. READ BEFORE USE

Please read the Product Instructions carefully.
Thank you for purchasing and using this product.
For your safety and interests, please read the Product Instructions carefully before using the product.

About the Product Instructions:
The trademarks and names mentioned in the Product Instructions are the property of their respective owners.
All Product Instructions shown are for illustration purposes only. The actual product may vary due to product enhancements.
We shall not be liable for any personal injury, property damage, or other damages caused by the failure of the user to comply with the Product Instructions or precautions.
VANKYO reserves the right to interpret and modify the Product Instructions.

4. IN THE BOX

PRODUCT OVERVIEW

Projector

6. Remote Control

- Power**
Press to power on / switch to standby mode / wake up / press and hold for 3s to power off
- Google Assistant**
Press and hold and talk
- User Profile**
Press to see profile page
- OK**
Press to see selection / pause / resume
- Back**
Return to previous page
- Focus Adjustment**
- Mute**

4. QUICK START

1. Projector Installation

Note:
Which ever installation option you select, please make sure:
*To go to **Homepage** > **Dashboard** (Ⓢ) > **All settings** (Ⓢ) > **Projector** > **Advanced Settings** > **Projection Mode** to select the corresponding projection mode, so the images can be projected correctly.
*Mounting Screw: M5*4 (not included)

6. 2. Power On/Off

Note:
Please use the power adapter provided in the box to prevent product damage.

4. Setup Wizard

Follow the setup wizard to choose your preferred language, select the correct region, sign in with your Google Account or set up basic TV.

6. 5. Image Adjustment

Focus

When the projector detects shaking/rapid movement, it will automatically adjust the image quality.

6. 2. Electric/Manual Focus

You can also press the Focus buttons on the remote or go to **Homepage** > **Dashboard** (Ⓢ) > **All settings** (Ⓢ) > **Projector** > **Focus** > **Manual Focus** to sharpen the image focus until the blurry image becomes clear.

4. Keystone Correction

1. Auto Keystone Correction

When the projector detects shaking/rapid movement, it will automatically correct the keystone distortion.

2. Manual Keystone Correction

Go to **Homepage** > **Dashboard** (Ⓢ) > **All settings** (Ⓢ) > **Projector** > **Image Correction** > **Manual Keystone Correction** to manually correct the image shape by four points.

6. PROJECTOR CONNECTION AND INPUT SOURCE

Connect your device to the projector correctly, then select the right input source.

USB Connection: Insert the disk. Then go to **Homepage** > **Apps** and select **IMPlayer** under **Your apps** tab to locate and play the file.

Tip:
For Basic TV, go to **Homepage** and select **IMPlayer** to locate and play the file.

HD Connection: Connect the device. Then press **Input** button on the remote control or go to **Homepage** > **Dashboard** (Ⓢ) > **Inputs** and select **HD**.

Wired Speaker and Headphones Connection: Not required to select any input source.

4. GOOGLE ASSISTANT

Your TV is more helpful than ever. Use your voice to find movies, streaming apps, play music and control the TV. Ask Google Assistant to find a specific title, search by genre, or get personalized recommendations. Even get answers on screen, control smart home devices, and more. Press the **Google Assistant** button on the remote to get started.

6. GOOGLE CAST™

Google Cast is a platform that lets you stream your favorite entertainment from your phone, tablet or laptop right to your projector. Easily control your TV with apps you already know and love from your iPhone®, iPad®, Android™ phone or tablet, Mac® or Windows® laptop, or Chromebook.

To use Google Cast, please ensure you are using a Google Cast-enabled app and follow the instructions below.

- Connect your device and the projector to the same wireless network.
- Open the streaming app on your device.
- Play a video and tap the casting icon (Ⓜ) on the video screen.
- Select "V702P" to connect. The projector will display the video from your device.

*Due to copyright restrictions, certain content cannot be cast to the projector. You can stream the content on the projector by installing some applications from the **Apps** tab.

6. How to use the AirScreen App

You can mirror the entire screen from your device onto the projector screen.

- Ensure that both your device and the projector are connected to the same wireless network.
- Install **AirScreen** - **AirPlay** is available on your projector.
- Open **AirScreen** app and follow the on-screen instructions to complete the process.

4. BT SPEAKER MODE

You can use this projector as a BT speaker by connecting your mobile device to it through a BT connection.

Step 1:
Go to **Homepage** > **Dashboard** (Ⓢ) > **All settings** (Ⓢ) > **Projector** > **BT Speaker Mode** to make the projector ready for a BT connection.

6. PROJECTION DISTANCE AND SIZE

*The recommended projection distance varies with different projection contents. Please adjust the distance between the wall/screen and the projector as needed.
*Ambient darkness will improve the clarity of the projected images.

Unit Dimension	11.9 x 9.3 x 4.0 inches (302 x 237 x 101 mm)	Net Weight	5.29 lbs/2.4 kg
Photo Format Supported	JPEG/BMP/GIF/PNG	Audio Format Supported	MPEG-1/2/3, mp3, aac, dca(HiFi3D-B)
Video Format Supported	HDR10, HLG, HEVC, PRIME HDR, AV1, MPEG-2/2-4, 1080i/20fps H.264/4-285-4K60fps	Ports	HD in x1 / USB x1 / Audio Out x1
Mounting Screws	M5	Screw Number	4(not included)

4. TROUBLESHOOTING GUIDE

1. The copyrighted content from Hulu, Netflix, and similar services can not be mirrored or cast.

*This projector offers a range of pre-installed streaming apps that are officially licensed. You can go to the **Homepage** > **Apps**, search for the app, and log in to your account to play the content. For casting, refer to the "Google Cast" section.

2. Fuzzy Image

*Adjust the focus or keystone correction of the projector.
*Make sure the projection distance is in the effective focal range of the projector.
*Remove the dust or dirt from the lens with a blower or soft-bristled brush.

6. 3. Non-rectangular Image

*Place the projector perpendicular to the screen/wall if keystone correction function is not used.
*Use the keystone correction function to adjust image shape.

4. Automatic keystone correction failure

*Make sure the adjustment sensor on the front of the projector is not blocked or smudged.
*Move the projector until it is perpendicular to the projection surface and try again.

5. Autofocus failure

*Make sure the adjustment sensor on the front of the projector is not blocked or smudged.
*Move the projector back and forth until the projector is in recommended projection distance.

6. Remote control unresponsive

*Make sure the batteries are installed correctly and not drained.
*Remove any obstructions between your projector and remote control.
*Ensure the remote control is successfully paired with projector via BT.
*Make sure no button is pressed or stuck and check if the power indicator is still on. If yes, please contact customer support or local service center.

7. Connect the BT devices

*Enter **Homepage** > **Dashboard** (Ⓢ) > **All settings** (Ⓢ) > **Remotes & Accessories** to check the BT device list, and connect the device.

8. Others

*Please feel free to contact us at support@vankyo.com.

4. Statement

Google TV is the name of this device's software experience and a trademark of Google LLC. Google, YouTube and Google Cast are trademarks of Google LLC.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

RF Exposure Information:
—The related output power of this device meets the limits of FCC radio frequency exposure limits. This device should be operated with a minimum separation distance of 20cm (8 inches) between the equipment and a person's body.
—The remote control has been evaluated to meet general RF exposure requirement. It can be used in portable exposure condition without restriction.

Canada compliance statement / Conformité réglementaire canadienne :
This device complies with Innovation, Science and Economic Development Canada license-exempt RSS standards. Operation is subject to the following two conditions:
(1) This device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.
Operation in the band 950-9250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems.
Exposure to radio frequency energy
—The related output power of this device meets the limits of IC radio frequency exposure limits.
—This device should be operated with a minimum separation distance of 20 cm (8 inches) between the equipment and a person's body.
—The remote control has been evaluated to meet general RF exposure requirement. It can be used in portable exposure condition without restriction.

Le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:
(1) L'appareil ne doit pas produire de brouillage, et (2) l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.
La bande 950-9250 MHz est réservée uniquement pour une utilisation à l'intérieur afin de réduire les risques de brouillage préjudiciable aux systèmes de satellites mobiles utilisant les mêmes ondes.

Exposition à l'énergie radiofréquence
—La puissance de sortie rayonnée de cet appareil est conforme aux limites de la IC limites d'exposition aux fréquences radio. Cet appareil doit être utilisé avec une distance minimale de séparation de 20 cm entre l'appareil et le corps d'une personne.
—La télécommande a été évaluée et répond aux exigences générales d'exposition aux RF. Il peut être utilisé dans des conditions d'exposition portables sans restrictions.

CAN ICES (B) / NMB (B)

The product label and certification information are located at the bottom of the product.

support@vankyo.com