



JIMMY CHOO

user manual



JIMMY CHOO

POWERED by
ZHORTech®

THANK YOU FOR PURCHASING
A JIMMY CHOO PRODUCT

JIMMY CHOO USES THE HIGHEST QUALITY OF LEATHERS AND MATERIALS. TO ENABLE YOU TO ENJOY YOUR JIMMY CHOO PRODUCT FOR A LONG TIME, WE RECOMMEND TO TAKE NOTE OF THE FOLLOWING CARE INFORMATION. IF YOU REQUIRE ANY FURTHER SPECIFIC CARE GUIDANCE FOR YOUR PRODUCT, PLEASE DO NOT HESITATE TO ASK FOR ADVICE IN YOUR JIMMY CHOO STORE OR AT JIMMYCHOO.COM

THIS PRODUCT IS THE RESULT OF EXTENSIVE RESEARCH, RESULTING IN THE FINE DETAILS SYNONYMOUS WITH HIGH QUALITY LUXURY.

ALL TYPES OF LEATHER AND OTHER DELICATE MATERIALS (INCLUDING METAL ACCESSORIES), SUFFER FROM HUMIDITY. HUMIDITY, SALT AND ATMOSPHERIC AGENTS IN GENERAL CAN CAUSE

PERMANENT AND IRREVERSIBLE WEAR AND TEAR. THEREFORE PLEASE TAKE CARE TO AVOID RAIN AND DIRECT CONTACT WITH HEATH, OIL, GREASE (MAKE UP), ALCOHOL (PERFUME, SOLVENTS) AND OTHER ABRASIVE PRODUCTS AS JIMMY CHOO CANNOT ASSUME RESPONSIBILITY FOR THE EVENTUAL DETERIORATION, MODIFICATION AND MISHANDLING OF THE PRODUCT. AVOID CONTACT WITH ANY MATERIALS WHICH MAY TRANSFER THEIR COLOUR PIGMENTS ONTO THE PRODUCTS.

ALL MATERIALS ARE SOURCED FOR THEIR EXCEPTIONAL QUALITY AND ARE TESTED EXTENSIVELY PRIOR TO SALE.

ALWAYS STORE YOUR PRODUCT IN THE DUST BAG PROVIDED WHEN NOT IN USE.

YOUR JIMMY CHOO PURCHASE INCLUDES:
BOOT, LIGHTNING TO USB CABLE WITH CABLE
STRAP, DUSTBAG.

INSTRUCTION OF USE

START BY DOWNLOADING THE JIMMY CHOO APP



APP AVAILABLE ON iOS AND ANDROID

CONNECT YOUR SHOES WITH THE USB CABLE
TO CHARGE THE BATTERIES OF YOUR SHOES.

THE CABLE TURNS RED WHILST CHARGING.



THE CABLE TURNS GREEN ONCE THE BATTERY IS
FULLY CHARGED.



**ONCE FULLY CHARGED, PLEASE FOLLOW FUR-
THER INSTRUCTIONS ON [NAME OF APP.]**

CHARGE BATTERIES IN TEMPERATURES
BETWEEN 1°C (34 °F) TO 45°C (113°F) TO BEST
PRESERVE THE BATTERY LIFE.



110V / 220V

RECOMMENDED USE OF POWER TO BE AT
LEAST 1.5A.

EU: DECLARATION OF CONFORMITY

HEREBY, J. CHOO LIMITED HEREBY DECLARES
THAT THIS RADIO EQUIPMENT IS IN COM-
PLIANCE WITH DIRECTIVE 2014/53/EU.

THE FULL TEXT OF THE EU DECLARATION OF
CONFORMITY IS AVAILABLE AT THE FOLLOWING
INTERNET ADDRESS: [\[WWW.JIMMYCHOO.COM\]](http://WWW.JIMMYCHOO.COM)

FREQUENCY BAND: 2400-2483.5 MHZ

POWER MAX: 10MW

MODEL REFERENCE: The Voyager Boot

FCC ID: 2AQ4H-001

IC: 24304-001

MODEL: Jimmy Choo Heated Shoe

LITHIUM BATTERY: 3.8V



USA: Federal Communications Commission (FCC) Statement. This device complies with FCC part 15 FCC Rules.

Operation is subject to the following two conditions:

«Changes or modifications not expressly approved by JIMMY CHOO could void the user's authority to operate the equipment.»

Note: This equipment has been tested and found to comply with the limits for the class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed, and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:

- . Reorient or relocate the receiving antenna.
- . Increase the separation between the equipment and receiver.
- . Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- . Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

This device complies with FCC and Industry Canada RF radiation exposure limits set forth for general population (uncontrolled exposure). This device must not be collocated or operating in conjunction with any other antenna or transmitter.

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

ATTENTION:

IL Y A RISQUE D'EXPLOSION SI LA BATTERIE EST REMPLACÉE PAR UNE BATTERIE DE TYPE INCORRECT.
METTRE AU REBUT LES BATTERIES USAGEES CONFORMEMENT AUX RÈGLEMENTS EN VIGUEUR.

CAUTION:

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

EU (European Union)



"Pour en savoir plus: quefairedemesdechets.fr"

FOR MORE INFORMATION GO TO JIMMYCHOO.COM



DO NOT SMOKE
NEAR SHOES



BATTERY
LEAKAGE RISK



DO NOT EXPOSE
TO EXTREME
TEMPERATURES



FLAMMABLE



KEEP AWAY
FROM FIRE



RISK OF EXPLOSION



KEEP AWAY
FROM CHILDREN



DO NOT BEND



DO NOT RUN



DO NOT HIT OR
PUNCTURE



DO NOT JUMP



DO NOT WASH

CAUTION: BE AWARE OF BURN.

USERS NEED TO BE AWARE OF EARLY SENSATIONS OF A BURN, INCLUDING WHEN AN AREA OF A FOOT BECOMES HOT. IF YOU FEEL THE EARLY WARNING OF A FOOT BURN, IMMEDIATELY DISCONTINUE USE OF THE SHOE AND MAKE CERTAIN YOUR FOOT IS NOT AT RISK OF BEING BURNED. SEE A PHYSICIAN IMMEDIATELY IF YOU THINK YOU HAVE A BURN

INSTRUCTIONS ON PRODUCT AND BATTERY DISPOSAL

END OF LIFE



THE CROSSED OUT WHEELED BIN SYMBOL MEANS THAT THE PRODUCT MUST NOT BE DISCARDED AS HOUSEHOLD WASTE, AND SHOULD BE DELIVERED TO AN APPROPRIATE COLLECTION FACILITY FOR RECYCLING. PROPER DISPOSAL AND RECYCLING HELPS PROTECT NATURAL RESOURCES, HUMAN HEALTH AND THE ENVIRONMENT. FOR MORE INFORMATION ON DISPOSAL AND RECYCLING OF THIS PRODUCT, CONTACT YOUR LOCAL MUNICIPALITY, DISPOSAL SERVICE, OR VISIT

JIMMYCHOO.COM



THIS SYMBOL MEANS THAT THE BATTERIES THAT CAME WITH THE PRODUCT, OR THAT YOU USE TO OPERATE THE PRODUCT, MUST NOT BE DISPOSED OF WITH NORMAL HOUSEHOLD WASTE. BATTERIES CONTAIN HARMFUL SUBSTANCES THAT CAN CAUSE HARM TO HUMAN HEALTH AND TO THE ENVIRONMENT. PLEASE HELP PREVENT HARM TO OUR ENVIRONMENT BY RECYCLING BATTERIES. FOR MORE INFORMATION ON DISPOSAL AND RECYCLING OF BATTERIES, CONTACT YOUR LOCAL MUNICIPALITY, DISPOSAL SERVICE, OR VISIT [JIMMYCHOO.COM](http://WWW.JIMMYCHOO.COM)

EN-
WARRANTY TERMS AND CONDITIONS
WWW.JIMMYCHOO.COM

-FR-
GARANTIE ET CONDITIONS GÉNÉRALES DE
VENTES
WWW.JIMMYCHOO.COM

-DE-
GARANTIE UND VERKAUFSBEDINGUNGEN
WWW.JIMMYCHOO.COM

-JP-
保証条項と条件
WWW.JIMMYCHOO.COM

CONTACT US

CUSTOMERSERVICES@JIMMYCHOO.COM

J. CHOO LIMITED

10 HOWICK PLACE

LONDON SW1P 1GW

UNITED KINGDOM

0044 207 368 5000