



DG501VZ

5G RedCap Dongle




Product Overview




Model Name	DG501VZ
Frequency Band	5G NR : n2/5/66/77 4G LTE : B2/4/5/13/66
Dimension	86.5x38.1x11.4mm
Weight	31g
Color	Black
Power input	5V=2.5W (via USB 2.0 Type-C port)
Accessory	USB Type-C cable (15cm)

Install SIM Card:

1. Open the back cover of the device.
2. Insert a Nano SIM card into the SIM slot.
3. Ensure the metal contacts face downward.
4. Push until the SIM card clicks into place.
5. Replace the back cover by snapping into place.



Insert Nano SIM card




Device Setup:

1. Plug the DG501 into a USB Type-C port on your computer.
2. The device will automatically power on.
3. Open browser and type <https://192.168.128.1/>
4. Enter default Username: admin & Password: password.



5. You must update your password upon first login.



6. Once LED shows Blue/Yellow/Green, your network is ready.

LED Indicator Description

LED Status	Description
Blue	4G network connected
Yellow	5G signal medium
Green	5G signal good, network usable
Red	5G signal weak

Safety Information:

- 1.Avoid humidity, water, or extreme temperatures.
- 2. Keep away from strong magnetic fields.
- 3.Use only with certified USB cable.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause

harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of the FCC RF Rules. This equipment must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provided with antenna installation instructions and consider removing the no-collocation statement. This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Caution!

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.