

展开尺寸：360x135mm 成品尺寸：90x135mm
105克铜版纸黑白正反面印刷 风琴页折叠

正面



Window Camera

Easy Guide



V1025

Description:



1. Reset button

2. Micro SD card slot

3. Microphone

4. Speaker

5. Indicator light

6. USB-C power connector

7. 1/4" Tripod

About the camera:

1. Power on the camera

To power on the camera, use a 5V (1A~2A) adapter to connect camera with supplied power cable. The indicator will turn on in blue color and blinking.

2. Micro SD card

To save the events into local storage, the camera needs a 8GB~256GB (Class 10 or higher) micro SD card. Please format the card before using.

3. Reset

If the device is not able to connect to the app, you may need to reset the camera. Hold and press the reset button for 5 seconds, the camera will be restarted and you will hear the "welcome" voice announcement, which means the reset is successful and the camera is ready to connect.

4. Installation the camera

Connect the camera with App to check the signal before mounting the camera.

Installation and Setup

1. Download and Install:

Download and install the InstaVision app by scanning the QR code for the Apple Store or Google Play Store.

iPhone



Android








InstaVision

反面

2. Account Registration:

Open the app and register a new account or log in to an existing account.




3. Add Camera:

Navigate to the Home Page within the app. Locate and select "Add Camera" then go through preparation instructions to power on your camera properly.



4. Bluetooth Access:

Follow the on-screen instructions to enable Bluetooth access, which is required for device discovery. Do not skip this step. Ensure Bluetooth access is enabled as instructed, allowing the app to discover the device via BLE.




5. Connect to Wi-Fi:

The app will automatically scan for nearby 2.4 GHz & 5 GHz Wi-Fi routers. Note: This camera only supports 2.4GHz Wi-Fi, if your smartphone connects to a 5GHz Wi-Fi please switch to 2.4GHz then connect with camera.




Installation the camera:

1. Check that you have a strong Wi-Fi signal (at least two bars) in the location where the smart camera is to be installed.



2. Wipe the window glass before sticking the window sticker.



FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.