



DTEN D7X 55"

Android Edition


Product Guide

Packing List

1. DTEN D7X 55" x 1
2. Wall Mount Brackets x 1
 - * The bracket pieces are stored at the bottom of the box (beneath the foam).
3. Stylus x 1
4. Power cord x 5 (Type B,D,F,G,I)
5. USB-C to USB-C Cable x 1
7. Antenna x 2

⚠ Do not disassemble the D7X without the supervision of a DTEN technician. Improper use may be subject to voiding the warranty.


What's Inside



Quick Setup


STEP 1

Install the AV bar.




STEP 2

Install the antennas.



STEP 3

Plug in the power cord to the outlet.
The display will turn on.



STEP 4


Follow the instructions on-screen to set up the network.
Ethernet connection is preferred.



* For more info about the product, please visit [dten.com](https://www.dten.com)

Smart Connect

You can utilize the DTEN D7X's touch, speaker, camera and microphone arrays as your computer's peripherals



Service Setup & Deployment

1. The DTEN may need to update to the latest version for the first-time startup. Please ensure the internet connection is stable during the startup process.
2. Active the DTEN on the DTEN Orbit Service Portal for services.
3. An ethernet connection is preferred for the best meeting experience.
4. Ensure the corporate network allows the DTEN to be connected. Check with your network and/ or security team for instructions. Please check the DTEN Network Whitelist Requirement.
5. You will need to sign in with a licensing account for licensed rooms.
6. To pair with a room controller, please follow the service provider controller application instructions.




Tips


1. An ethernet connection is preferred for the best meeting experience.
2. Please do not disconnect the power without properly shutting down the system.
3. Do not disassemble the DTEN product.

If you have any questions, feel free to contact us. ■ SUPPORT@DTEN.COM ☎ +1.866.936.3836

Port Diagram



Mounting Instructions



Model: DBR1455

