

WIRELESS STEREO EARPHONES

with Bluetooth® Wireless Technology

PLEASE READ BEFORE OPERATING THIS EQUIPMENT

MODEL: MBH552

OWNER'S MANUAL

FCC NOTICE:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to your radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC STATEMENT:
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.

Caution: The user is responsible for the proper use of this equipment. Improper use or compliance could void the user's authority to operate this equipment.

LOCATION OF CONTROLS:

Charging Station:

1. Charging ON/OFF Button
2. Charging port for L (Left) Earbud
3. Charging port for R (Right) Earbud
4. LED Indicators
5. Cover
6. Micro USB Port (For charger only)

Earbuds:

1. (B) Button
2. Built-in Microphone
3. Controls for Touching
4. LED Indicators

POWER SOURCE:
The Charging station and Earbuds support fast 1.5-hour rechargeable battery; recharge it before use or when it is drained as below.

Notes:

1. When charging the Charging Station, you can also charge the Earbuds through it at the same time.
2. Your battery will last longer if you're following these simple guidelines for caring and storing.
 - A. Before first use, use, charge the Charging Station and Earbuds approximately 1 hour until they are fully charged.
 - B. Recharge and store the Charger and Earphones within the temperature range of 32°C-35°C (90°F-95°F).
 - C. Do not charge longer than 24 hours. Excessive charging or running the Charger until Earphones until battery fully drains will damage battery. Battery life will be extended if you keep the battery fully charged.
 - D. Battery life naturally declines slowly over time.
 - E. The rechargeable battery incorporated in this product is not user replaceable.

Charging Station:

1. Connect the Micro USB Plug from the supplied USB Connection Cable to the Micro USB Port on the rear of Charging Station.
2. Connect the full sized USB Plug from the supplied USB Connection Cable to the USB Port on the Computer or USB Charger (Computer and USB Charger NOT supplied).
3. During charging, the Red LED Charging Indicator on the top of Charging Station will blink. When finished charging, it will stop blinking.

Earbuds:

1. Open the Cover of the Charging Station. Place the L (Left) Earbud into the L (Left) Charging Port. Place the R (Right) Earbud into the R (Right) Charging Port as illustrated below:

2. Pressing the Charging ON/OFF Button on the Charging Station to power on. The Blue LED Indicator will illuminate.
3. Close the cover to start charging, the Red Indicator on each Earbud will illuminate. When finished charging, the Red indicator on each Earbud will turn off. (The charging time per earbud can be slightly different, please note this is normal.)

OPERATION:

STEREO MODE:
BT (Bluetooth) pairing:
To pair the R & L Earbuds to the BT Device is more needs for the first time (or repeat to new BT Device), follow the steps below:

1. Power on the R & L Earbuds by pressing the (B) Button on each Earbud at the same time. Then
 - The Red & Blue Indicators on the R Earbud will illuminate and blink.
 - The Blue Indicator on the L Earbud will illuminate and blink.
2. Power on the external BT Device and enter to BT searching mode. Start pairing following the on screen instructions from the external BT Device.
3. After being paired, the Red Indicator on the R Earpods will no longer light up, the Blinking Frequency of Blue Indicator on the L Earpods will slow down.
4. If pairing is complete you may now play music and answer calls with your external BT Device.
5. During playback, use the controls on the paired BT Device to adjust sound level, skip tracks, pausing playback or mute the sound as usual.
6. If the Earbuds is paired to a Call Phone and call is incoming during an active music session. Ringar sound will hearing from R Earbud. Pressing the (B) Button on the R Earbud then speak on the built-in microphone to answer the call. When your call is complete, pressing the (B) Button again to disconnect or end the call and resume to music playback.
7. When finished listening, pressing and holding the (B) Button on either Earbud until Red Indicator is illuminate then release the button to shut off both Earbuds.

Notes:

- When the external BT Device searched the unit, our model number "MBH552" will appear on the display of external BT Device.
- If while pairing you are asked for a code please try "0000" or "123456".

Normal operation after pairing:

1. Power on the R & L Earbuds by pressing the (B) Button on each Earpods at the same time. The Red & Blue Indicators on the R Earpods will illuminate and blink, the Blue Indicator on the L Earbud will illuminate and blink.
2. Power on the external BT Device and enter to BT searching mode. Wait a few seconds until the Earbuds automatically paired to the external BT Device. Then:

- 6

?



9

Printed in China MBH530_WC_E0S12_B0US