

IM Size 67 x 96mm, Open size: 402 x 192mm

正面

MAGNAVOX

2 IN 1 WIRELESS COMBO PACK

OWNER'S MANUAL

PLEASE READ BEFORE OPERATING THIS EQUIPMENT.

FCC INFORMATION:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide residential protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on the circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC NOTICE:

To assure continued compliance, follow the attached installation instructions and use only shielded cables when connecting to other devices. Modifications not authorized by the manufacturer may void user's authority to operate this device.

LOCATION OF CONTROLS (HEADPHONE)

Model Name: MBH571H



1. Play/Pause Button
2. Volume Up/Down Button
3. Volume Up/Down Button
4. Microphone
5. Indicators
6. AUX IN Jack
7. Micro USB Port (For Charging only)

POWER SOURCE

The unit has a built-in Li-ion rechargeable battery, charge it before first time use or when it is drained as follows:

1. Connect the small plug from the supplied USB Connection Cable to the Micro USB Port on the unit.
2. Connect the full size USB Plug from the supplied USB Connection Cable to the USB Port on the Personal Computer or USB Charger (Computer and USB Charger not included).
3. When charging, the Red Charging Indicator on the unit will illuminate. When charging is complete, it will turn off.

NOTES:

- Your battery will last longer if you following these simple guidelines for caring and storing.
- A. Before first time use, recharge the unit approximately 4 hours until the unit is fully charged.
 - B. Charge and store the unit within the temperature range of 5°C - 35°C (40°F - 95°F).
 - C. Do not overcharge (longer than 24 hours). Excessive charging or running the unit completely flat will damage battery. Battery life will be extended if you keep the battery fully charged.
 - D. Battery life naturally shortens slowly over time.
 - E. The rechargeable battery incorporated in this product is not user replaceable.

OPERATION (HEADPHONE)

BT (BLUETOOTH) PAIRING:

For first time use or re-pairing the unit to a new BT Device, pair as follows:

1. Press and hold the Play/Pause Button on the unit approximately 2 seconds to power on the unit. The Red & Blue indicators will illuminate and blink.
2. Power on the external BT Device and enter to BT searching mode. Start pairing following the on screen instructions from the external BT Device. When paired, the Blue Indicator will stop blinking and Red Indicator will turn off.
3. If pairing is complete you may now play music or answer the phone with your external BT Device.
4. During playback:
 - Press the Play/Pause Button to pause; press again to resume normal playback.
 - Press and release the + or - buttons to adjust volume level as desired.
 - Press and hold the + or - buttons repeatedly to skip tracks.
5. If the unit is paired to a Cell Phone:
 - When a call is incoming during an active music session:
 - Press the Play/Pause Button then speak to the Microphone to answer the call. When your call is complete, press the Play/Pause Button to disconnect or end the phone call and resume to music playback.
 - Or, press and hold the Play/Pause Button approximately 1 second to decline the incoming phone call then resume to music playback.
 - Quick press the Play/Pause Button twice to redial the last telephone number your cell phone called.
6. To shut off the unit, press and hold the Play/Pause Button on the unit until the Red Indicator is illuminate then release the button.

Notes:

- When the external BT Device searches for the unit, our model number "MBH571H" will appear on the display of external BT Device.
- If while pairing you are asked for a code please try "0000" or "1234".

Normal operation after paired:

1. Power on the external BT Device and enter to BT playback mode.
2. Press and hold the Play/Pause Button on the unit to power on the unit. The Red & Blue Indicators will illuminate and blink.
3. Wait a few seconds until the unit automatically pairs to the external BT Device. (The Blue Indicator will stop blinking and Red Indicator will turn off).
4. If pairing is complete you may now play music or answer the phone with your external BT Device.

AUX IN:

Listen from an external Audio Player such as MP3 Player, Discman...etc. as a traditions headphone:

1. In power off mode, connect one end of the supplied Audio Connection Cable to the AUX Out/Line Out/Phone Jack on the external Audio Player.
2. Connect the other end to the AUX IN Jack on the unit as illustrated on right.
3. Play the music on the connected Player as usual. (Make sure the volume level of the connected Audio Player is turned to high level.)
4. Using the controls on the connected external Audio Player to adjust volume; skip tracks Etc.

NOTE: When the Audio Connection Cable inserted into the AUX IN Jack, the unit will automatically shut off. Unplug the cable from the unit before use BT (Bluetooth).

SPECIFICATIONS (HEADPHONE):

Power Source: Built-in DC $\approx$ 3.7V; 200mAh (0.74WH) rechargeable Li-ion battery, recharge by DC $\approx$ 5V through Micro USB Port

Impedance of the Earbuds: 32 ohm, 15 mW per Channel

Audio power: 15mW per Channel (Total 30mW)

BT Version: 4.2

BT Operation Distance: Up to 32 Feet in open area


PACKAGE INCLUDES:

- 1 x Owner's Manual
- 1 x USB Connection Cable (For Charging Only)
- 1 x Audio connection Cable with 3.5mm Stereo Plugs

SPECIFICATIONS AND ACCESSORIES ARE SUBJECT TO CHANGE WITHOUT NOTICE

LOCATION OF CONTROLS (EARPHONE)

Model Name: MBH571E



1. + Button
2. O Button
3. - Button
4. Indicators
5. Micro USB Port (For Charging only)
6. Microphone

POWER SOURCE (EARPHONE)

The unit has a built-in Li-ion rechargeable battery, charge it before first time use or when it is drained as follows:

1. Connect the small plug from the supplied USB Connection Cable to the Micro USB Port on the unit.
2. Connect the full size USB Plug from the supplied USB Connection Cable to the USB Port on the Personal Computer or USB Charger (Computer and USB Charger not included).
3. When charging, the Red Charging Indicator on the unit will illuminate. When charging is complete, it will turn off.

NOTES:

- Your battery will last longer if you following these simple guidelines for caring and storing.
- A. Before first time use, recharge the unit approximately 4 hours until the unit is fully charged.
 - B. Charge and store the unit within the temperature range of 5°C - 35°C (40°F - 95°F).
 - C. Do not overcharge (longer than 24 hours). Excessive charging or running the unit completely flat will damage battery. Battery life will be extended if you keep the battery fully charged.
 - D. Battery life naturally shortens slowly over time.
 - E. The rechargeable battery incorporated in this product is not user replaceable.

OPERATION (EARPHONE)

BT (BLUETOOTH) PAIRING:

For first time use or re-pairing the unit to a new BT Device, pair as follows:

1. Press and hold the O Button on the unit approximately 2 seconds to power on the unit. The Red & Blue indicators will illuminate and blink.
2. Power on the external BT Device and enter to BT searching mode. Start pairing following the on screen instructions from the external BT Device. When paired, the Blue Indicator will stop blinking and Red Indicator will turn off.
3. If pairing is complete you may now play music or answer the phone with your external BT Device.
4. During playback:
 - Press the O Button to pause; press again to resume normal playback.
 - Press and release the + or - buttons to adjust volume level as desired.
 - Press and hold the + or - buttons repeatedly to skip tracks.
5. If the unit is paired to a Cell Phone:
 - When a call is incoming during an active music session:
 - Press the O Button then speak to the Microphone to answer the call. When your call is complete, press the O Button to disconnect or end the phone call and resume to music playback.
 - Or, press and hold the O Button approximately 1 second to decline the incoming phone call then resume to music playback.
 - Quick press the O Button twice to redial the last telephone number your cell phone called.
6. To shut off the unit, press and hold the O Button on the unit until the Red Indicator is illuminate then release the button.

Notes:

- When the external BT Device searches for the unit, our model number "MBH571E" will appear on the display of external BT Device.
- If while pairing you are asked for a code please try "0000" or "1234".

SPECIFICATIONS (EARPHONE):

Power Source: Built-in DC $\approx$ 3.7V; 55mAh (0.2035WH) rechargeable Li-ion battery, recharge by DC $\approx$ 5V through Micro USB Port

Impedance of the Earbuds: 32 ohm, 5 mW per Channel

Audio power: 5 mW per Channel (Total 10mW)

BT Version: 4.2

BT Operation Distance: Up to 32 Feet in open area

PACKAGE INCLUDES:

- 1 x Owner's Manual
- 1 x USB Connection Cable (For Charging Only)

SPECIFICATIONS AND ACCESSORIES ARE SUBJECT TO CHANGE WITHOUT NOTICE

TROUBLESHOOTING

Check the following before requesting service:

SYMPTOM	POSSIBLE CAUSE	POSSIBLE SOLUTION
Can't power on	Built-in battery drained	Recharge the battery
No sound or sound weak	Volume of the unit was set to minimum position	Increase the volume level of the unit
	Volume level of paired BT device is in low level	Rise the volume level of the paired BT device
Sound distortion	Volume level too high	Reduce the volume level of the unit
	Volume level of the paired BT device too high	Reduce the volume level of the paired BT device
BT not Functioning	The external BT device had NOT paired to the unit	Pair the external BT device
	The external BT device too far from the unit	Place the external BT device close to the unit

LIMITED WARRANTY

Craig Electronics Inc. warrants this product to be free from manufacturing defects in material and workmanship under normal use for a period of 180 days from date of purchase. If service is required, please return the product to the store where it was purchased for exchange; or, pack the unit in the original packing material with all accessories if applicable, a copy of your sales receipt and a Cashier's check or Money Order for \$3 (to cover shipping and handling costs) payable to Craig Electronics Inc. For consumers in Canada, please make sure that the cashier check or money order is redeemable through a U.S. bank. Ship your product freight pre-paid. Your unit will be repaired, replaced or if the unit can not be repaired or replaced, a refund will be forwarded to you within four weeks of receipt of your unit. Please ship your unit to:

Craig Electronics Inc.
1160 NW 163 Drive
Miami, FL 33169

This warranty is void if the product has been: a) Used in a commercial application or rental, b) Damaged through misuse, negligence, or abuse, c) Modified or repaired by anyone other than an authorized Craig Electronics Inc. service center, d) Damaged because it is improperly connected to any other equipment. Note: This warranty does not cover: a) Ordinary adjustments as outlined in the Owner's Manual which can be performed by the customer, b) Damage to equipment not properly connected to the product, c) Any cost incurred in shipping the product for repair, d) Damage to the product not used in the USA.

This warranty is not transferable and only applies to the original purchase. Any implied warranties, including the warranty of merchantability, are limited in duration to the period of this expressed warranty and no warranty whether expressed or implied shall apply to the product thereafter.

Under no circumstance shall Craig Electronics Inc. be liable for any loss or consequential damage arising out of the use of this product. This warranty gives specific legal rights. However, you may have other rights which may vary from state to state. Some states do not allow limitations on implied warranties or exclusion of consequential damage. Therefore, these restrictions may not apply to you.

This product has been manufactured by and is sold under the responsibility of Craig Electronics Inc., and Craig Electronics Inc. is the warrantor in relation to this product. MAGNAVOX and SMART, VERY SMART are registered trademarks of Koninklijke Philips N.V. and are used under license from Koninklijke Philips N.V.

To Obtain Service on your Product
email: magnavox@craigelectronics.com

Printed in China

MBH571_WC_E0511_B0US

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.