

Contents
 1. Headphones
 2. USB-C to 3.5mm Audio Cable
 3. User Manual
 4. Warranty Card

Important Information
 Please read the user manual carefully before using the headphones.

Wear and Adjustment
 1. Adjust the headband to fit your head.
 2. Adjust the ear cups to fit your ears.

Pairing
 1. Turn on the headphones.
 2. Press and hold the power button for 5 seconds.

Volume Button & Power Button Controls
 1. Press the volume button to adjust the volume.
 2. Press the power button to turn the headphones on or off.

Factory Reset
 1. Press and hold the power button for 10 seconds.

Contents
 1. Headphones
 2. USB-C to 3.5mm Audio Cable
 3. User Manual
 4. Warranty Card

Important Information
 Please read the user manual carefully before using the headphones.

Wear and Adjustment
 1. Adjust the headband to fit your head.
 2. Adjust the ear cups to fit your ears.

Pairing
 1. Turn on the headphones.
 2. Press and hold the power button for 5 seconds.

Volume Button & Power Button Controls
 1. Press the volume button to adjust the volume.
 2. Press the power button to turn the headphones on or off.

Factory Reset
 1. Press and hold the power button for 10 seconds.

