

裁切线	辅助线
压痕线	牙 刀
V槽线	画 线
半穿刀	
■ 外表面视图	□ 内表面视图

4

3

2

1

- 备注：
- 材质：70g书写纸
 - 印刷颜色：1C+1专 ■ PANTONE 3415
 - 成型尺寸：70x105mm
 - 展开尺寸：350x210mm
 - 尺寸公差：±1 mm
 - 印刷偏位：<=0.5 mm
 - 套印偏位：<=0.35 mm
 - 成型工艺：风琴折
 - 所有成品及辅料符合欧盟包装指令94/62/EC，美国TPCH，欧盟REACH
 - 印刷油墨（成品）矿物油含量需满足MOSH(C15-C36)小于0.1%；MOAH（1-7芳香环）小于0.1%；MOAH（3-7芳香环）小于0.0001%

C

C

版本	变更描述	变更日期	包装结构	包装平面
A01	初始发行	2024/5/28	尹华红	刘琪

UGREEN 绿联 深圳市绿联科技股份有限公司

物料名称: W705 35970 说明书

产品名称	料号	产品工程师	核准
车载磁吸无线充电器	/	张泽明	袁蓉辉

SELECT			V							
Dim	TOL.	A	B	C	EPS	EPE	EPP	BAG	CTN	LABEL
0~6	0.05	0.05	0.10							0.20
6~30	0.10	0.15	0.20	0.50	0.50	0.50	3.00			0.20
30~120	0.15	0.20	0.30	0.50	0.50	0.50	5.00	1.00		0.25
120~300	0.20	0.30	0.40	1.00	1.00	1.00	10.00	1.00		0.30
300~450	0.25	0.40	0.50	2.00	2.00	2.00	15.00	2.00		0.50
450~600	0.30	0.50	0.60	3.00	3.00	3.00	20.00	3.00		0.80
DRAFT TOLERANCE				± 0.20°		CRITICAL DIM. MARK				*

UGREEN		Product Overview		Installation	
DE: Produktübersicht FR: Détail du Produit ES: Detalles del producto IT: Panoramica del Prodotto RU: Обзор Характеристики JP: 製品紹介 CN: 产品概述 AR: تفاصيل المنتج SE: Produktoversikt TR: Ürün Açıklaması PT: Visão geral do produto		DE: Wireless Charging Area DE: Wireless Label/patch FR: Zone de Charge sans Fil ES: Zona de Carga inalámbrica IT: Area di carica wireless RU: Зона беспроводной зарядки JP: ワイヤレス充電エリア CN: 无线充电区 AR: منطقة الشحن اللاسلكي SE: Trådlös laddningsområde TR: Kablosuz Şarj Alanı PT: Zona de carregamento sem fio		DE: Indicator DE: Indicator FR: Indicateur ES: Indicador IT: Sema RU: Индикатор JP: インジケータランプ CN: 指示灯 AR: مؤشر SE: Indikator TR: Gözgeci PT: Luz indicadora	
DE: Air Vent Hook Clip DE: Air Vent Hook Clip FR: Crochet de la grille d'aération ES: Clip de la rejilla de ventilación IT: Clip del griglia per la ventilazione dell'aria RU: Крепежная скоба для решетки радиатора JP: ヘッドファンフッククリップ CN: 头网夹 AR: مقبض الفتحة للهواء SE: Luftventhållare TR: Hava Alınma Klipsi PT: Clip de grelha de respiração de ar		DE: Air Vent Hook Clip DE: Air Vent Hook Clip FR: Crochet de la grille d'aération ES: Clip de la rejilla de ventilación IT: Clip del griglia per la ventilazione dell'aria RU: Крепежная скоба для решетки радиатора JP: ヘッドファンフッククリップ CN: 头网夹 AR: مقبض الفتحة للهواء SE: Luftventhållare TR: Hava Alınma Klipsi PT: Clip de grelha de respiração de ar		DE: Step 1 DE: Step 1 FR: Step 1 ES: Step 1 IT: Step 1 RU: Шаг 1 JP: ステップ 1 CN: 步骤 1 AR: خطوة 1 SE: Steg 1 TR: Adım 1 PT: Passo 1	
DE: Step 2 DE: Step 2 FR: Step 2 ES: Step 2 IT: Step 2 RU: Шаг 2 JP: ステップ 2 CN: 步骤 2 AR: خطوة 2 SE: Steg 2 TR: Adım 2 PT: Passo 2		DE: Step 2 DE: Step 2 FR: Step 2 ES: Step 2 IT: Step 2 RU: Шаг 2 JP: ステップ 2 CN: 步骤 2 AR: خطوة 2 SE: Steg 2 TR: Adım 2 PT: Passo 2		DE: Step 2 DE: Step 2 FR: Step 2 ES: Step 2 IT: Step 2 RU: Шаг 2 JP: ステップ 2 CN: 步骤 2 AR: خطوة 2 SE: Steg 2 TR: Adım 2 PT: Passo 2	

STEP 3		STEP 4		STEP 5	
DE: Step 3 DE: Step 3 FR: Step 3 ES: Step 3 IT: Step 3 RU: Шаг 3 JP: ステップ 3 CN: 步骤 3 AR: خطوة 3 SE: Steg 3 TR: Adım 3 PT: Passo 3		DE: Step 4 DE: Step 4 FR: Step 4 ES: Step 4 IT: Step 4 RU: Шаг 4 JP: ステップ 4 CN: 步骤 4 AR: خطوة 4 SE: Steg 4 TR: Adım 4 PT: Passo 4		DE: Step 5 DE: Step 5 FR: Step 5 ES: Step 5 IT: Step 5 RU: Шаг 5 JP: ステップ 5 CN: 步骤 5 AR: خطوة 5 SE: Steg 5 TR: Adım 5 PT: Passo 5	
DE: Step 5 DE: Step 5 FR: Step 5 ES: Step 5 IT: Step 5 RU: Шаг 5 JP: ステップ 5 CN: 步骤 5 AR: خطوة 5 SE: Steg 5 TR: Adım 5 PT: Passo 5		DE: Step 5 DE: Step 5 FR: Step 5 ES: Step 5 IT: Step 5 RU: Шаг 5 JP: ステップ 5 CN: 步骤 5 AR: خطوة 5 SE: Steg 5 TR: Adım 5 PT: Passo 5		DE: Step 5 DE: Step 5 FR: Step 5 ES: Step 5 IT: Step 5 RU: Шаг 5 JP: ステップ 5 CN: 步骤 5 AR: خطوة 5 SE: Steg 5 TR: Adım 5 PT: Passo 5	
DE: Step 5 DE: Step 5 FR: Step 5 ES: Step 5 IT: Step 5 RU: Шаг 5 JP: ステップ 5 CN: 步骤 5 AR: خطوة 5 SE: Steg 5 TR: Adım 5 PT: Passo 5		DE: Step 5 DE: Step 5 FR: Step 5 ES: Step 5 IT: Step 5 RU: Шаг 5 JP: ステップ 5 CN: 步骤 5 AR: خطوة 5 SE: Steg 5 TR: Adım 5 PT: Passo 5		DE: Step 5 DE: Step 5 FR: Step 5 ES: Step 5 IT: Step 5 RU: Шаг 5 JP: ステップ 5 CN: 步骤 5 AR: خطوة 5 SE: Steg 5 TR: Adım 5 PT: Passo 5	



IC Statement
EN
This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference;
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
FR
Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage;
- (2) l'utilisateur de l'appareil doit accepter tout brouillage subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

CAN ICES-003(B) / NMB-003(B)
Cet équipement est conforme aux limites d'exposition aux rayonnements de la IC établies pour un environnement non contrôlé. Cet équipement doit être installé et fonctionner à au moins 20cm de distance d'un radiateur ou de votre corps. Cet émetteur ne doit pas être co-localisé ni fonctionner en conjonction avec une autre antenne ou un autre émetteur.

FCC Warning
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.