


400mm

## MAGIC SOUND ZOMBIESCAT SPEAKER

使用说明(Instructions)  
音魔音箱  
ZOMBIESCAT MAGIC SOUND SPEAKER

产品使用说明  
Instruction



| 功能(Function)          | 操作说明(Instruction)                                                                                                                                                                                                                                                                                                                                |
|-----------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ①PLAY (播放暂停)          | 轻触,播放与暂停<br>(Tap ,play and pause)                                                                                                                                                                                                                                                                                                                |
| ②VOL+/NEXT (音量增加/下一曲) | 1.每次触摸,下一曲 2.长按触摸“音量增加”<br>(1. Tap once for next music 2. Long touch for volume up)                                                                                                                                                                                                                                                              |
| ③VOL-/PREV (音量减少/上一曲) | 1.每次触摸,上一曲 2.长按触摸“音量减少”<br>(1. Tap once for previous music 2. Long touch for volume down)                                                                                                                                                                                                                                                        |
| ④button (开关键)         | 长按,开机与关机(Long touch for on and off)                                                                                                                                                                                                                                                                                                              |
| ⑤USB (充电接口)           | 充电接口(AUX/Charging port/ AUX)                                                                                                                                                                                                                                                                                                                     |
| ⑥RST (复位键)            | 轻扎复位键,重新启动功能<br>(Pin the resetting key lightly to restart)                                                                                                                                                                                                                                                                                       |
| ⑦LED (指示灯)            | 开灯后,指示灯为常亮,灯罩进入睡眠模式。<br>蓝牙设备“ZOMBIESCAT”,配对成功时蓝色指示灯长亮,<br>充电时指示灯为闪烁红色,无电指示灯灭。<br>Switch on: Ready pairing mode starts when the indicator light goes blue and flashing. Bluetooth equipment "ZOMBIESCAT"<br>The blue indicate light shows when pairing.<br>The red indicate light shows when charging.<br>Indicator light gone when full-charged. |

按键接口说明:  
Touch Instruction:

### 基本规格参数

Basic specification

|                               |                       |
|-------------------------------|-----------------------|
| 蓝牙版本(Bluetooth)               | V4.1                  |
| 喇叭口径(Speaker Size)            | Φ50mm                 |
| 喇叭输出功率 (Output Power Speaker) | 2.0Wx2 Max (RMS 2.0W) |
| 频率响应(Frequency response)      | 80Hz-16000Hz          |
| 接收范围和距离 (Receiver distance)   | 10M/meters            |
| 电池容量 (Battery Capacity)       | 3.7V 2000mAh          |
| 音乐播放时长 (Music play time)      | 4-5h                  |
| 充电连接 (Charge Connector)       | Micro 5PIN USB        |

## ZOMBIESCAT

DEVOURS NEGATIVE ENERGY

## ZOMBIESCAT

DEVOURS NEGATIVE ENERGY

### 安全注意事项 Warning

- 1、应防止剧烈震动、冲击或挤压,防止日晒雨淋。
- 2、应贮存于环境为-10℃~45℃,相对湿度不大于75%的清洁、干燥、通风的室内,应避免与腐蚀性物质接触,远离火源。
- 3、本产品不可当家庭垃圾丢弃,必须将此废弃设备送至适当的废弃电池回收点处理。
- 4、本产品中包含锂电池,严禁私自拆开产品外壳,避免可燃液体电池或其他危险。
- 5、严禁任意拆解、挤压、穿刺本产品或投入火、水中或置于温度高于60℃的环境中。

⚠ 如设备在使用过程中发生起火或爆炸,应立即停止使用,并通知当地消防部门。本产品在使用过程中,应严格按照说明书操作。

1. Avoid this device from accidental drops, physical shocks, and any long exposure to the sun or rain.
2. Keep this device in the clean/dry environment of 40° C~45° C in temperature. The ambient humidity of the device should not exceed 75% so as to avoid corrosion damage. Do not expose the device to a heat source such as fire.
3. Never dispose of any electrical or electronic waste in general circulation, collect and dispose of such waste safely and separately.
4. The External battery contains Lithium-ion batteries, to avoid the dangerous caused by the battery, please do not take apart the shell of the product.
5. Never disassemble, press, rip, or drop the product into water, fire or exposure the product in the environment that the temperature is higher than 60° C.

⚠ The customer will bear all the consequences if he damage the product caused by the improper use of the consumer in violation of the above warning, the company will not have any legal liability.

### 保修及售后服务 Warranty

本产品自购买之日起,在正常使用情况下,保修期为一年。在保修期内,如产品出现质量问题,经本公司确认后,将免费更换或修理。保修期内的产品可以凭购买凭证或发票到本公司售后服务部办理。

- 1、非本公司生产的产品。
- 2、非本公司代理销售的产品。
- 3、因使用不当(如短路、火灾等)而造成损坏的产品。
- 4、因人为原因(如摔落、浸水、火灾等)而造成损坏的产品。
- 5、因不可抗力(如地震、火灾等)而造成损坏的产品。
- 6、因不可抗力(如地震、火灾等)而造成损坏的产品。

⚠ 本保修服务解释权归本公司所有,并保留最终解释权。

The warranty is valid for a year starting from the date of purchase. Within the warranty period, your External battery can get the post-purchase maintenance service for free when it is used and maintained properly.

- Warranty is not provided if:
- 1 This product is not from the company.
  - 2 It is not the agent for the sale of products of the company.
  - 3 Damaged by natural disasters, such as earthquake, fire, etc.) causes of product failure or damage.
  - 4 Damage caused by improper use, abuse, alteration, faulty installation, modification, and disassembly of the product.
  - 5 Users do not follow the product bar code.
  - 6 Equipment, components is beyond warranty.

⚠ 每盒产品只含一个音箱,如出现质量问题,请与本公司售后服务部联系。如出现质量问题,请与本公司售后服务部联系。如出现质量问题,请与本公司售后服务部联系。

⚠ Each packing box contains one Speaker, one user manual, one USB cable. Anything in the packing left out or damaged, please contact the distributor.

### 保修卡 (Warranty Card)

型 号(Model): \_\_\_\_\_ 用户名称(Customer Name): \_\_\_\_\_

销售商(Distributor): \_\_\_\_\_ 联系电话(Tel): \_\_\_\_\_

故障说明(Return Reason): \_\_\_\_\_

用户地址(Address): \_\_\_\_\_

※ 保修时,需把音箱以及所有配件,并连同保修卡一同寄出。

※ When the Speaker is returned to repair, all the accessories in the packing should be returned together with the warranty card.



魔鬼猫音魔音箱官方公众号

魔鬼猫 ZOMBIESCAT × 萌奇 Meki

品牌方: 魔奇动文化传播(深圳)有限公司  
出品方: 深圳市萌奇文化发展有限公司  
地址: 深圳市福田区侨城东路的101号  
电话: 0755-23889312  
网址: www.mekiculture.com

Brand: MOREMOON Cultural Diffusion Co., Ltd.  
Producer: Meki Culture Development Co., Ltd.  
Add: Room 101, Qiaocheng East Rd No.99, Nanshan, Shenzhen, China, 518000  
Web: www.mekiculture.com  
Tel: 0755-23889312

100mm

100mm

**FCC Caution****§ 15.19 Labeling requirements.**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**§ 15.105 Information to the user.**

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**§ 15.21 Information to user.**

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.