


User Manual
wifi digital picture frame P100



- 1. POWER
After connecting power adapter, please press and hold power button for approximately 5 seconds (until screen turns on).
When it is on, press and hold power button for approximately 3 seconds to access reboot or power off menu. Short press on power button will turn off/onscreen (but leave the photo frame in on position).
- 2. USB
Connect a USB flash drive. USB is for service use only.
- 3. RESET
Use a needle or paper clip to reset unit.
- 4. MicroSD card
Load external max 32Gb microSD memory card here.
- 5. DC
Connect DC adapter to power on the device.

ENG-1

Contents

Gettingstarted.....3
frameo app.....3
frameo quick setup.....4
Start using frameo.....4
Navigating your frameo.....5
Settings.....5
My frame.....5
Manage photos.....6
My Friends.....6
Display and slideshow.....7
Wi-Fi.....7
Backup and Restore.....7
About.....8
Privacy.....8
Warranty, Compliance, Support and Safety information.....8

ENG-2

Getting started

Thank you for purchasing your very own frameo.
First, to set up your frame follow the 'Quick start guide' included in the package. If you are new to using frameo then start by following the frameo quick setup on page or follow the on screen guide when powering it on for the first time.
Once you have set up your Frameo frame, start connecting it to your friends and family.
Frameo app
To send photos to your frame, use the frameo app for iOS or Android



Find the frameo app on:
Google play by searching for "frameo" or scan this QR code



App Store by searching for frameo or scan this QR code



ENG-3

Frameo quick setup

- When starting your frame for the first time, you will need to setup the frame.
- First you start by selecting a language. This will be the language used throughout frameo.
 - Connect your frame to the internet by connecting it to a Wi-Fi. If a newer version of the frameo software is available, then you will be prompted with an update dialog. It is recommended to update your frame immediately if prompted.
 - Enter your name, and the location where you have placed your frame e.g. "Living room", "Kitchen" or "Office" and finally set the timezone if not correct.

Start using frameo

Start by connecting with your friends and family by providing them with a unique code from your frame.
If you want to be able to send photos to the frame yourself, start by downloading the app for iOS or Android on App Store or Google Play. Then use the code to connect your frame and app as described below.

Connecting a new friend:

- Make sure that your friend has downloaded and installed the frameo app
- Click the add friend icon on your frame. A dialog will appear showing a unique code which is valid for 12 hours.
- Now share this code in whatever fashion you prefer e.g. SMS, E-Mail, IM, phone call, to your friend.
- Once your friends have added the code in their frameo app, they will automatically appear on your frame and be able to send you photos.



ENG-4

ENG-8
20cm between the radiator & your body.
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.
undecided operation.
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
FCC Statement
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
undecided operation.
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

ENG-7
Any existing backup on the SD card will be overridden!
Backup frame to max 32Gb microSD card.
Automatic backup
If checked, your frame will automatically take a backup within 30 hours of you receiving new photos or making changes on your frame.
Restore from backup
Before you attempt to restore your frame, start by confirming that your backup is up-to-date.
To restore from a backup, you must first reset the frame. It is important to note that you cannot restore to a new Frameo frame and keep the old frame operational at the same time.
Reset frame
Removes all data from your frame. This will permanently remove all your photos, friends/connections and settings.

ENG-6
My Friends
This list contains all the people that are allowed to send photos to your frame.
Remove person
To remove a person from this list, thereby removing their permission to send you photos, tap the delete icon X. You will then be asked to confirm the removal and if you would like to remove all photos received from this person.
Add person
To allow a new person to send you photos, simply tap the add friend button and share the presented code in whatever way you prefer.

ENG-5
Your frame is not powered down or in standby, so you will still be able to receive photos during sleep mode.
Sleep mode:
Frameo offers a sleep mode which turns off the screen to reduce power consumption while you are sleeping. Its default setting is to turn off the screen at 23:00 and turn on the screen again at 07:00. To change this just set the sleep mode start/end time.
Set time zone
Sets the timezone that should be used on your frame.
Set language:
Sets the language throughout your frame.
Frame location:
Changes the location of your frame. This is the location displayed on your friends' and family's list of connected frames which can help to distinguish frames from each other.
My frame
Changes the name of your frame. This is also the name the connected friends and family will see in their list of connected frames.
Settings
Through settings, you can personalize your frame to your needs.
Delete photos:
Select photos that you want to permanently delete from your frame by tapping the photo. Use to select or deselect all and to delete the selected photos.
Show/hide photos:
Select which photos to hide by tapping the particular photos you wish to hide. Hidden photos will NOT be deleted from your frame, you can always select them to be shown again.
Manage photos
Display and slideshow
Timer
Show caption
Sets whether or not to display the captions that your friends have sent with the photo. Check to display captions. Uncheck to hide captions.
Brightness level
Adjust the brightness level of the screen.
Wi-Fi
Set which Wi-Fi the frame should be connected to. If you are connecting to a network with a captive portal a web browser icon should appear in top right corner of the screen. Use this to open a browser where you can enter credentials to access the network.
Backup frame to max 32Gb microSD card.
Automatic backup
If checked, your frame will automatically take a backup within 30 hours of you receiving new photos or making changes on your frame.
Restore from backup
Before you attempt to restore your frame, start by confirming that your backup is up-to-date.
To restore from a backup, you must first reset the frame. It is important to note that you cannot restore to a new Frameo frame and keep the old frame operational at the same time.
Reset frame
Removes all data from your frame. This will permanently remove all your photos, friends/connections and settings.