


尺寸: 80*110mm,
材质: 105g铜版纸,
工艺: 正反面四色印刷,



Pan right	pan (device) camera right turn (device) camera right Alexa, ask GOSCAM to pan (device) camera right Alexa, ask GOSCAM to turn (device) camera right Pan (device) camera to the right
Tilt up	tilt (device) camera up move (device) camera up Alexa, ask GOSCAM to tilt (device) camera up Alexa, ask GOSCAM to move (device) camera up Point (device) camera up
Tilt down	tilt (device) camera down move (device) camera to tilt (device) camera down Alexa, ask GOSCAM to tilt (device) camera down Alexa, ask GOSCAM to move (device) camera down Point (device) camera down
Take photo	take a picture with (device) camera Alexa, ask GOSCAM (device) camera take a picture Alexa, ask GOSCAM to take a picture with (device) camera

[illegible]

3. Movement detection: when camera is detected with the scope of camera, the camera will record video and take photos automatically. Videos and photos will be saved on the hard disk.

4. Sharing with friends: Stream two-dimensional code to be saved on the hard disk.

5. Camera sharing with friends: Delete the camera and cancel sharing with friends. (You have to re-add the camera to start again)

6. Alarm function: When a movement is detected, alarm message can be sent to server and pushed to your mobile phone.

7. Remote monitoring: after the camera is connected to the server, you can view the camera monitor via internet, anytime, anywhere.

8. 360° panoramic view: According to 32GB movie file, you can watch.

Why this machine has a crash fault after some continuous influencing the space, it is recommended to restart the router and press RESET button for 10 seconds, which can restore factory settings, and then please connect the router.

10 Troubleshooting

- 1. Wi-Fi cannot be connected
- 2. Cannot connect to the camera to find well
- 3. Ensure that camera is in range of router. Keep the camera within 100 meters of the router.
- 4. Camera, less than 65° for outdoor camera

- 1. Ensure that SSID and password of Wi-Fi are correct on special characters. Modify the SSID and password of Wi-Fi.
- 2. Ensure that SSID and password are no longer than 10 characters.
- 3. Ensure that SSID is broadcasted.
- 4. Ensure that the camera is in the range of Wi-Fi signal.
- 5. WPA-PSK/AES, WPA2-PSK/AES.
- 6. WPA-PSK/AES, WPA2-PSK/AES.
- 7. WPA-PSK/AES, WPA2-PSK/AES.
- 8. Ensure that there is no MAC filter on router or add MAC filter on router whitelists.
- 9. We suggest reboots the router, and the "security" and "encryption" method must be "WPA2-PSK/AES" never choose "auto-select".
- 10. Ensure that there is no IP connection again.
- 11. Reboot the router and set IP for 10 seconds.

2. Red light

- 1. Ensure that the network connection is correct.
- 2. Ensure that the password of Wi-Fi is correct.
- 3. Ensure that the camera is in the range of Wi-Fi signal.
- 4. Ensure that the camera is in range of Wi-Fi hotspot.
- 5. Ensure that the camera is in the range of Wi-Fi signal.
- 6. Ensure that Wi-Fi is strong enough and the camera is in the range of Wi-Fi signal.
- 7. Ensure that the camera is not under the influence of other 2.4GHz signal.

NOTE:

1. FCC/CE Certification Information

2. The camera is designed and developed according to FCC/CE certification standards.

3. The camera is designed and developed according to FCC/CE certification standards.

5	Camera Indicator Instruction
Red indicator constant flashes	Indicates that power failure or network not successes. The camera is connecting to network.
Red indicator flashes continuously	Indicates that network connecting successfully (no internet).
Red indicator continuously	Indicates the camera is connecting to server and waiting mail.

6	Product Specifications
New version	
Camera resolution	1080P/30FPS
Image sensor	1/2.8" CMOS
Camera resolution range	320 (horizontal) 50 (vertical)
Night vision range	< 5m
Audio sensitivity	< 0.1dB
Operation voltage	DC=4V2A
Operation temperature	-10℃ ~ +55℃
Operation humidity	15% ~ 85% RH
Size (L*W*H)	81*41*33mm

Start recording	start recording with (device), camera (device), also GOSCAM (device) camera to start recording Also, use GOSCAM to start recording video with (device), camera	Check the last motion detection time Check the last motion detected by (device), camera Also, use GOSCAM to check the last motion detected on (device), camera
Stop recording	Also, use GOSCAM to stop recording video with (device), camera	Check the last sound detected by (device), camera When was the last sound detected by (device), camera Also, use GOSCAM to check the last sound detected by (device), camera
Turn on/off motion detection	Turn on/off (device), camera motion detection Also, use GOSCAM to turn on/off (device), camera motion detection	Check the temperature at (device), camera When was the last temperature at (device), camera Also, use GOSCAM to check the temperature at (device), camera
Turn on/off sound detection	Turn on/off (device), camera sound detection Also, use GOSCAM to turn on/off (device), camera sound detection	Check the status Update Also, use GOSCAM to check the status update on (device), camera
Turn on/off temperature alert	Turn on/off (device), camera temperature alert Also, use GOSCAM to turn on/off (device), camera temperature alert	
Turn on/off status flag	Turn on/off (device), camera status flag Also, use GOSCAM to turn on/off (device), camera status flag	
Play/Stop motion	Play/Stop motion on (device), camera Also, use GOSCAM to play/stop motion on (device), camera	

王梅林	审核	张景辉	型号	GLJH-1外贸	品名	外箱	单位	mm	深圳市格朗电器有限公司	产品部
2018/04/09	日期	2018/04/09	料号		材质		比例	1: 1		

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

The equipment complies with FCC Radiation exposure limits set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

.