

INSTRUCTIONS
说明书

PD-S100
哇味TWS无线音箱
WAKA TWS WIRELESS SPEAKER

哇味TWS无线音箱示意图

喇叭

多功能按键

micro充电口

挂绳孔

硅胶挂绳

特征

立体浮雕彩绘工艺。
PD-S100有TWS功能，
两个音箱可以相互连接使用。
迷你尺寸，惊人的音效。
内置大容量电池。

[1]

使用说明

功能	灯光和提示音
开机	白灯闪烁，直接进入配对状态
关机	电源关闭，白灯熄灭并发出提示音
无线连接	白灯闪烁并发出提示音
连接成功	白灯常亮并发出提示音
电量低	红灯闪烁并发出提示音
充电中	红灯常亮
TWS连接	两个音箱配对成功，白灯都常亮并发出提示音

基本按钮操作

开机：按电源按钮3秒，白灯闪烁，直接进入配对状态。

关机：按电源按钮3秒钟，白灯熄灭。

播放/暂停：短按电源按钮

[2]

两个音箱TWS互联

两个音箱都开机进入配对状态，分别双击开关键即可相互连接，然后用手机搜索连接一个即可。

对音箱进行充电：

用micro 充电口充电，充满需要两小时，充电过程中红灯常亮，充满电后自动熄灭。

蓝牙连接：

将PD-S100放置距离手机10米范围内，音箱为关机状态。按下电源按钮3秒钟，准备配对，在白色交替闪光后，会有语音提示进入配对模式。激活手机上的蓝牙功能并搜索PD-S100，从在您的手机蓝牙上找到的设备列表中，选择PD-S100连接它，然后会有语音提示连接。

包装内容

1. PD-S100音箱
2. 充电线
3. 说明书、合格证、保修卡
4. 硅胶挂绳

[3]

参数

蓝牙版本	4.2	电池容量	400mAh
频率响应	90~15kHz	播放时间	4h
信噪比	-68dB	充电时间	1h
失真度	<2%	产品重量	70g
扬声器规格	4Ω3W	传输距离	10m
输入电压	DC5V	工作温度	-20℃~60℃

保修条例

本产品有效保修期为自出售之日起一年内，在保修期限内正常使用和维护的情况下，机器本身机件材料及功能出现问题，发生故障，经属实，本公司将提供免费修理及更换零件。

[4]

本产品的保修不适用于：

A. 音箱已超出保修期；
B. 用户未按照说明指南要求，造成 音箱 破损
C. 未经本公司授权自行拆装，修理，改动结构；
D. 无法提供保修卡及消费凭证；
E. 因自然灾害等不可抗力（如地震、火灾）原因造成的产品故障或损害；
注：保修服务不包含产品运输费用及不提供上门维修服务

[5]

保修卡

一、产品资料填写

用户名称 _____ 电 话 _____

地 址 _____

产品名称	机身型号	
经销商名称	电 话	
经销商地址	邮 编	经销商盖章
发票编号	购买日期	

一、产品维修记录

故障现象		更换材料	
维修方式		维修日期	
维修单位	是否维修	☐ 是 ☐ 否	
备 注			

*在接受服务时必须提供此保修卡，请妥善保管！

Warranty card

Product information

User name _____ Telephone _____

Address _____

Product name	Fullsize model	
Dealer name	Telephone	
Dealer address	Zip code	Dealer seal
Invoice number	Date of purchase	

Product maintenance record

Failure phenomenon	Replacement material	
Maintenance mode	Maintenance date	
Maintenance unit	Repair	☐ Yes ☐ No
Remarks		

* Please provide this warranty card when receiving the service. Please keep it properly!

Sketch map of speaker

speaker

Multi-Function Buttons

micro charging port

Gift lanyard

Hanging rope hole

[1]

General Function

Operation	LED Status
Power On	White LED flashes with power on tone, and waiting for pairing
Power Off	Power off tone, with white LED light off
Pairing	White LED flashes with tone reminder, and remind 3 times
Standby	White LED on
Low battery	Red LED flashes with tone reminder, and remind 3 times
Charging	Red LED keeps lighting during charging
TWS	One speaker White LED keeps on, for another speaker White LED flashes

Basic Buttons Operation

Power on: Press power button for 3 seconds, White LED flashes, speaker turns on with the tone.

Power off: Press power button for 3 seconds, light off, speaker turns off with the tone.

Play/Pause: Short press power button, music pauses, press again, music continues.

[2]

Two speakers interconnections

Turn on both speakers and enter the pairing state. Double-click the on-off button to connect them to each other and then use your phone to search and pair with one of the two speakers.

Charging the speaker: Using micro connector for power charging, it usually takes about 2 hours, Red LED keeps on during charging process, when charging finished, the Red LED turns off automatically.

Two TWS speakers interconnecting: Double-click the key button in two devices on the pairing state then connecting successfully, and you can search it in your phone

Pairing:

Place speaker and your Bluetooth device within one meter, make sure the speaker is power OFF, Press and hold the power button for 5 seconds and the white LED flash alternately, there will be a voice prompt for entering to pairing mode. Activate the Bluetooth function on your phone or devices then search for PD-S100 from the list, select PD-S100 to connect it, then there will hear a voice prompt of connected.

[3]

Kit Contents

1. PD-S100 WAKA TWS wireless Speaker
2. Charging Micro USB cable
3. User manual
4. Gift lanyard

Specifications

Bluetooth Version	4.2	Battery capacity	400mAh
Frequency response	90~15KHz	Duration	4h
Signal to noise ratio	-68dB	Charge time	1h
Distortion	<2%	Product weight	70g
Speaker specification	4Ω3W	Distance	10m
Input voltage	DC5V	Working temperature	20℃~60℃

[4]

WARRANTY

This product is covered under warranty for a period of one year from the date of sale limited to normal use and maintenance of the machine parts, materials and functions. Problems and failures verified upon further identification, will be provided free repair and replacement parts.

LIMITED TO THE FOLLOWING:

A. Speaker is beyond the warranty period;
B. User does not follow the instructions so that the speaker broken;
C. Without the authorization to dismount, repair, alteration structures;
D. Can not provide warranty card and consumer certificate;
Note: The warranty does not include product transport costs and does not provide on-site maintenance services.

[5]

产品合格证
(Product qualification certificate)

品牌 (Brand) _____

产品名称 (Product Name) _____ 哇味TWS无线音箱
WAKA TWS WIRELESS SPEAKER

产品型号 (Product Type) _____ PD-S100

产品标准 (Product Standards) _____ Q/RMM 002-2017

生产日期 (Production Date) _____ 2018-10

检 验 (Test) _____ 合格 PASSED

检验员 (Inspector) _____

QC
PASSED

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.