

80g铜版纸
黑色印刷
95x62mm 骑马钉
V1.2

Tronsmart

Element T2 Plus
Wireless Speaker

USER MANUAL




Thank you for purchasing the Tronsmart Element T2 Plus Wireless Speaker. Please read the user manual before use and keep it handy for future reference. If you have trouble understanding or following the instructions in this manual, please contact our customer support team directly at support@tronsmart.com

Package Content

- 1 x Element T2 Plus wireless speaker
- 1 x USB charging cable
- 1 x 3.5mm audio cable
- 1 x Warranty card
- 1 x User manual
- 1 x Lanyard


Overview



- ① Power ON/OFF; Voice assistant
- ② Music playing mode; TWS pairing
- ③ Play/Pause; Hands-free phone call; Bluetooth disconnect; Reset
- ④ Volume +; Next track
- ⑤ Volume -; Previous track
- ⑥ LED indicator
- ⑦ TF/Micro SD card slot
- ⑧ USB-C charging port
- ⑨ AUX-IN port

How To Use

1. Turn ON/OFF



2. Bluetooth Connection


Turn on the speaker, turn on your device's Bluetooth setting, search for 'Tronsmart Element T2 Plus' and click to connect.




Flashing blue	Bluetooth pairing mode
Stable blue	Connected to a device successfully

3. Pair Two T2 Plus

- Turn on both speakers and they will automatically enter True Wireless Stereo pairing mode.




- If two speakers do not pair with each other automatically, you can hold 'M' button for 3 seconds of one speaker and then they will enter True Wireless Stereo pairing mode.



- After two speakers have paired with each other successfully, you'll hear a sound prompt and the blue indicator of one speaker will flash while the other one will stay blue.


Flashing blue	True Wireless Stereo pairing mode
Stable & flashing blue	Connected to True Wireless Stereo mode

Pair the speaker with your device.



Stable blue	Connected to a device
-------------	-----------------------

Enjoy stereo surround music with two Element T2 Plus.



4. Disconnect Two T2 Plus

Hold 'M' button for 3 seconds to disconnect two T2 Plus from each other.

5. AUX-IN Mode

Simply connect the speaker with your non-Bluetooth device and the 3.5mm audio jack cable.

Note: Plugging in an audio cable will automatically switch to AUX mode. When using AUX mode, control audio playback via the connected device.

6. TF/Micro SD Card Mode

The speaker will play audio from your TF/Micro SD card when plugging the card into the slot.

7. Auto-power Off

The speaker will power off automatically after 10 minutes if it does not pair with any device via Bluetooth. When in low battery, the speaker will power off automatically as well.

8. Charging

Use the included USB cable to charge your T2 Plus and make sure it is fully charged before its first use.

Stable blue	Charging under Bluetooth connected condition
Red & blue flash alternately	Turn on & disconnect to any device
Stable red	Charging under turn on condition
	Fully charged

Note: It's recommended to charge the speaker after turning it off as to maintain the battery life.

Power button	Power ON/OFF: Hold for 3 seconds. Voice Assistant: Tap once to access your personal assistant from your mobile device. Hold for 8 seconds to power off forcibly if the speaker malfunctions.
Bluetooth/AUX-IN/TF button	Tap to switch music playing mode between Bluetooth, AUX-IN and Micro SD card. TWS pairing Play/Pause: Tap to play and pause the music. Answer/End a phone call: During an incoming call, tap to answer or hang up a phone call. Reject a phone call: During an incoming call, hold for 3 seconds to reject a phone call. Redial: During Bluetooth connected mode, double tap twice to redial the last dialed-out number. Bluetooth disconnect: Hold for 3 seconds to disconnect Bluetooth. Reset: Hold for 8 seconds to reset to factory default settings.
Volume + button	Volume +: Tap to increase the volume. Next track: Hold to choose next track.
Volume - button	Volume -: Tap to decrease the volume. Previous track: Hold to choose previous track.

Specifications

Model	Element T2 Plus
Bluetooth	5.0
Bluetooth compatibility	A2DP / AVRCP / HFP
Output (watt)	2 x 10W max.
Transmission distance	Up to 30m/100ft (open area)
Waterproof	IPX7
Playtime	Up to 24 hours (50% volume level)
Battery	3600mAh
Charge input	DC 5V/2.0A
Charging time	3 hours
TF card music format	WAV / FLAC / APE / MP3
Dimension	175 x 69 x 53 mm / 6.89 x 2.72 x 2.09 inches
Weight	470 ± 5g / 16.6 ± 0.2oz

Care & Maintenance

Do not use any form of detergents or cleaning material to clean the product as any type of chemical may make this device unusable. Do not disassemble this product. It contains no user serviceable parts. Do not drop or jump on it and treat it with care for the best performance. Keep the product in a dry location. Dust, dirt & moisture from humidity can accumulate on the body of the product if kept at an unfriendly place. Do not dispose this product in fire or batteries may explode or leak.

Warranty Information

Your 'Tronsmart Element T2 Plus', is warranted to the original owner for 12 months from the date of purchase against defects in material and workmanship under normal use and service. Tronsmart is not responsible for

the accidental use of this product and its liability will not exceed the purchase price of the product. If you have any problems while using the product, please do not hesitate to contact our customer support team at support@tronsmart.com.

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Tronsmart

SHENZHEN VALUE IN ACTION TECHNOLOGY CO., LTD.
A3 Hekan Industrial Building, 41# Wuhe Str.
Bantian, Longgang District, 518129 Shenzhen, China
Email: support@tronsmart.com
800-270-1082 (USA & Canada)
+86-755-23603740 (Global)



www.tronsmart.com FCC ID: 2ARRDELEMENT2PLUS Made in China