标准文件栏：

规格：92x78mm 80g 铜版纸，单黑双面

Tronsmart

USER MANUAL



Spunky Pro
Wireless Headphones


Thank you for purchasing Tronsmart Spunky Pro Wireless Headphones. Please read the user manual before use and keep it handy for future reference. If you have trouble understanding or following the instructions in this manual, please contact our customer support team directly at **support@tronsmart.com**.

Package Content


1 x Spunky Pro wireless earbuds with charging case
3 x Eartip Pairs
1 x Charging cable
1 x Warranty card
1 x User manual

Product Overview

① Multifunction Button
② LED Indicator / Mic
③ USB-C Charging Port
④ LED Indicator
⑤ Push to Open
⑥ Charging Contact



First Use of Earbuds



1.Remove the transparent film on the earbuds when taking them out of the charging case.



2.Fully charge the charging case before first use of earbuds and place the earbuds in the charging case before you start charging.

Turn ON/OFF



1.The earbuds will automatically turn on when taken out of the charging case.
To manually turn on the earbuds, hold the multifunction button for 3 seconds.



2.The earbuds will automatically turn off when placed back into the charging case. To manually turn off the earbuds, hold the multifunction button for 5 seconds until the LED indicator goes off.

Pairing

1.Single Earbud Pairing
Hold the multifunction button of either the Left or Right earbud for 5 seconds until the red and blue indicator light flashes alternately.
Then turn on your device's Bluetooth setting and search for 'Tronsmart Spunky Pro' to pair. Keep your device close while pairing (recommended distance ≤1m).



Red & blue light flashes alternately	Pairing mode
Goes off	Connected to the device

2.True Wireless Stereo Pairing
The earbuds automatically enter True Wireless Stereo pairing mode when two earbuds are taken out of the charging case.
When both earbuds are turned off, hold the multifunction button for 3 seconds on both to turn them on manually and then the two earbuds will enter to pairing mode automatically.
Then turn on your device's Bluetooth setting and search for 'Tronsmart Spunky Pro' to pair. Keep your device close while pairing (recommended distance ≤1m).



Red & blue light flashes alternately (Left earbud) Goes off (Right earbud)	The Left earbud is paired with the Right earbud successfully, but still not paired with your device.
Goes off	Two earbuds are paired with your device.

Failed to TWS Pair

1.Turn off both earbuds.
2.Hold the multifunction button for 5 seconds on both earbuds until the red and blue light flashes alternately and then tap the button on both earbuds for four times until the indicator light goes off.
3.Hold the button on both earbuds for 3 seconds until the blue light goes on and then the two earbuds will automatically enter True Wireless Stereo pairing mode.

Charging



1.USB-C Cable Charging



2.Wireless Charging:
Supports Qi wireless charging.

Multifunction Button - Gesture Control

L/R	Turn On	Hold for 3 seconds.
L/R	Turn Off	Hold for 5 seconds.
L/R	Voice Assistant	Hold for 2 seconds to activate voice assistant including Siri, Google and other local Android voice assistants that run on Samsung, Huawei, Xiaomi and other devices.
L/R	Answer/End Call	Tap once.
L/R	Reject Call	Hold for 2 seconds.
L/R	Play/Pause	Tap once.
R	Next Track	Tap twice.
R	Previous Track	Tap three times.
L	Volume Up	Tap twice.
L	Volume Down	Tap three times.

Specifications

Model	Spunky Pro
Bluetooth	5.0
Bluetooth working frequency	2.402GHz - 2.480GHz
Bluetooth compatibility	HSP, HFP, A2DP, AVRCP
Transmission distance	Up to 10m/33ft (open area)
Driver	6mm x 2
Frequency response	20Hz - 20KHz
Playtime	Up to 3.5 hours (80% volume level)
Talk time	Up to 3.5 hours (80% volume level)
Standby	With charging case: 2 months
Battery	Earbud: 35mAh Charging case: 400mAh (earbuds can be charged four times)
Charging connector	Qi wireless charge; USB-C
Charging time	1.5 - 2 hours
Dimension	Earbud: 19 x 15.5 x 21mm / 0.75 x 0.61 x 0.83in Charging case: 60 x 34.5mm / 2.36 x 1.36in

Care and Maintenance

1.If this product is not used for a long period of time, it's recommended to recharge it at least once a month to extend its life and maintain the normal use performance.
2.Keep the product in a dry location.
3.Do not dispose this product in fire as batteries may explode or leak.
4.To clean the product, use a lightly dampened cloth in water to clean the exterior in-case it gets dirty.
5.Do not disassemble this product. It contains no user serviceable parts.

Warranty Information

Your 'Tronsmart Spunky Pro Wireless Headphones', is warranted to the original owner for 1 year from the date of purchase against defects in material and workmanship under normal use and service. Tronsmart is not responsible for the accidental use of this product and its liability will not exceed the purchase price of the product. If you have any problems while using the product, please do not hesitate to contact our customer support team at **support@tronsmart.com**.

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Tronsmart

SHENZHEN VALUE IN ACTION TECHNOLOGY CO., LTD.
A3 Hekan Industrial Building, 41# Wuhe Str,
Bantian, Longgang District, 518129 Shenzhen, China
Email:support@tronsmart.com
800-270-1082 (USA & Canada)
+86-755-23603740 (Global)

www.tronsmart.com Made in China