

Warranty Card

Applicable for:

- * Since buying date, the user enjoys one year free repair service under normal use
- * After one year, will be charged some cost (according to our company's component part repair price list)
- * When return to factory for repair,the user should make sure the LED lamp packed properly,to avoid any damage during transportation
- * Factory is not responsible for the damages caused by the user's improper disassemble
- * The repair service is not free of the following situations in warranty period:
 1. Damage caused by natural earthquake, rat disaster, and unnormal use
 2. Damage caused in transportation, fall, and improper storage
 3. Consumable component, such as spare parts, batteries, light bulbs, etc.
 4. Warranty information record is not complete (no purchase date, no buying shop seal).
 5. Stored and used in special environment (such as humidity, sulfur area, high salty area and easy-corrosive area in the ship, etc).
 6. Used not according to the instructions.
 7. Special offer.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help
- This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The distance between user and products should be no less than 20cm

Important
Thank you for purchasing our products.
To guarantee your rights, please fill in this from properly, Thank you.

Name
Address
Telephone
Invoice number
Purchase date
Item number
Dealers

⚠ Note: this field requires the dealers seal!

⚠ Warning: please keep this warranty paper for repair presentation


Attention:

- * Please don't disassemble and refit the product to avoid any electric shock.
- * Please don't over-adjust the joint activity parts to avoid any damage.
- * Please don't put the lamp on the unstable table to avoid dropping out.
- * Please don't put the lamp in high temperature or high humidity environment.
- * Please don't look at the LED light source straightly to protect your eyes.
- * Please use the supplier given adapter. The adapter should be unplugged from the power socket for safety when not use the lamp for long time.
- * Please unplug the power cord and stop using in the following situations:
 - *The power cord or plug is damaged
 - *The lamp base gets wet in the rain or water
 - *The shell and joint activity parts of the lamp base is damaged
 - *The lamp base smokes or sparks
 - *LED bulb flashes erratically or damaged
- * Children over 8 years old and the disabled in body or mentally can use the lamp with the adult's guidance and supervision in the situations of knowing clearly the functions & operations and operating attention matters.
- * Children should not operate, clean and maintain the lamp alone.

U8Q10A

LED table lamp


User manual




Please read it carefully before use

Functions

- * High quality imitated leather design is durable enough to be used for a long period. Advanced precision etching technology makes the imitation leather effect of plastic material more realistic.
- * Smart wireless charger can charge cell phones which meet Qi wireless charging standard.
- * HD VA display with clock, alarm and snooze function makes you control your own time and never worry about oversleeping.
- * 3-grade brightness meets various lighting requirements.
- * Night light function bring more convenience to your life.




Instruction




- * Plug the power adapter into the power jack behind the lamp base.

⚠ Notice: please use the special adapter, do not use any others.


- * Battery mount



Instruction



- * Lamp operation: Plug in the power adapter, touch the lamp switch to turn on the lamp. The lamp has 3 grade brightness, with dim light, medium light and strong light cycling in sequence.
- * Night light operation: Touch the button to turn on the night light, which also has 3 grade brightness, with dim light, medium light and strong light cycling in sequence.
- * Tap the icon on the back to adjust the clock brightness.



Wireless operating instruction

- * Put the product which support for Qi standard on the middle of slide-proof pad, the instruct light will turn red when it is charging, turn green when full charged. While if there is any metal object on the wireless charger, the red light flickering means malfunction signal.

Instruction



Clock operation:

- * Press "S" key in clock mode to enter time setting mode, press it again to select time, with the sequence of hour, minute, year, day, exit mode.
- * Press "A" to increase the time, and press "v" to decrease.
- * In the setting state, if there is no operation for 1 minute, the setting will be automatically quit and display the time.

Snooze & alarm clock setting:

- * Press "M" in clock mode to enter the alarm setting.
- * Press "S" to enter alarm setting, with the sequence of hour, minute, snooze, music choosing, then press "M" to quit.
- * Press "A" to increase the time, and press "v" to decrease.
- * In alarm modes, press either "A" or "v" key to turn on/off the alarm and snooze function. Press it again to start next function, with the sequence of turning on alarm clock, turning on snooze, turning off alarm clock, and turning off snooze function.
- * When rings, it will ring for 1 minute if no operation. If the snooze function is turned on, it automatically works, and press "S" or any key to stop it.
- * Temperature conversion: press "v" in clock mode to switch between Fahrenheit and Centigrade, and press "A" to switch between 12 and 24 hours mode.

Specifications

Input	12V/ 2A
Max power	24W
Night light power	1W
Wireless output	10W
Color temperature	4000K±250K
Luminous flux	>400LM
CRI	>80
LED quantity	24PCS