

156 mm

70 mm



Model No.: PS-325M+PS-325A
3 in 1 MAGNETIC WIRELESS CHARGER & PORTABLE POWER BANK

Product Manual

Thank you for purchasing the XWIN product. Please read this manual carefully before using and keep it for future reference.


Package Contents
1* Wireless charger
1* Power Bank
1* Product Manual
1* USB-A to USB-C cable

Product icon



- ① Wireless Charging Indicator
- ② USB-C1 Input
- ③ Power Indicators
- ④ Wireless2 Output
- ⑤ USB-C2 Output
- ⑥ Pogo Pins Contacts
- ⑦ Button
- ⑧ Portable Power Bank
- ⑨ USB-C3 Output/Input
- ⑩ Wireless1 Output

Instructions



1. How to use 325M

a). Power up the PS-325M by the USB-C charging cable. Place the mobile phone with wireless charging function on the wireless1 output for wireless charging. (Indicator light is always on when charging.)

b). When the PS-325M is adjusted to a certain angle, it can charge the mobile Phone and earphone at the same time. Indicator light is always on when charging)
Use the charging cable connecting with the built-in USB-C output port and the device, it can achieve charging for the devices.

c). The brackets can be turned out for supporting the wireless charging mobile phones which are without magnetic suction.

70 mm

Model No.: PS-325M+PS-325A
3 in 1 MAGNETIC WIRELESS CHARGER
& PORTABLE POWER BANK

Product Manual

Package Contents
1* Wireless charger
1* Power Bank
1* Product Manual
1* USB-A to USB-C cable

-

The diagram illustrates the connection of a mobile phone to a USB-C output. On the left, a mobile phone is shown with a cable connected to its bottom port. An arrow labeled "Mobile Phone" points to the device. On the right, the cable is connected to a USB-C output port. An arrow labeled "USB-C Output" points to the port. The cable is also labeled "Cable" and "USB-C" near the output port.



Phone

The diagram shows the back of the device with a power button and four power indicators. The power button is a small, rectangular button. The power indicators are four small, circular LEDs. Below the indicators are labels for their respective power levels: 25%, 50%, 75%, and 100%.



Model No.	PS-325M
USB-C1 Input	PD 18W(Compatible with QC3.0)
Wireless1 Output	5W/7.5W/10W
Wireless2 Output	5W
USB-C2 Output	5V/1A
Total Output	15W Max
Dimension	90*90*20mm
Net Weight	452g

Model No.	PS-325A
USB-C3 In/Out	PD 18W,5V/3A,9V/2A,12V/1.5A
Capacity	3.7V/5,500mAh/20.35Wh
Size	90*90*14mm
Net Weight	442g

1. The wireless charging indicator will be off when wireless charging is not working. The indicator will be in white when wireless charging is working. The indicator will be in red at FOD status.
2. When we use the P25-32SM alone or use P25-32SA supply power to P2-32SA, the max output of the wireless charge P2 is 15W, and the max output of wireless charge P2 is 5W.
3. When connecting P25-32SA with P25-32SM, and use P2-32SM when charging to the P2-32SA, the output of the two wireless charge is 5W.
4. When P25-32SA is working for a long time, the Pogo pins will be hot, please do not touch the Pogo pins directly.
5. Please protect the Pogo pins, do not damage, to ensure the function will not be affected.
6. Do not pour from liquids.
7. Do not disassemble.
8. Avoid falling.
9. Keep out of reach of children.
10. Keep away from extreme temperatures.

Manufacturer : Power System Electronic Technology Co., Ltd.
Address : No. 1 Shangbian Road, Puxin Industrial District,
Shipai Town, Dongguan City, Guangdong

52 mm

Manufacturer : Power System Electronic Technology Co., Ltd.
Address : No. 1 Shangbian Road, Puxin Industrial District,
Shipai Town, Dongguan City, Guangdong

FCC Statements:

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF Exposure Statement:

This device has been evaluated to meet general RF exposure requirement. The device must be used in fixed/mobile(equal to or greater than 20cm) exposure condition while the wireless charging.