



Group Control: Group your products and control them together. Beacon products can only be grouped with other Beacon products of the same type.

The diagram illustrates the interface of the Globe Suite™ app, showing various controls and settings. The interface is divided into several sections:

- Hardware settings:** Indicated by a gear icon at the top.
- Globe Suite™ app features:** Indicated by a menu icon (three horizontal lines) at the top.
- Light mode:** Includes buttons for 'Color', 'Mood', and 'Music'.
- Color spectrum and selector:** A large circular area with a smaller circle inside, used for selecting colors.
- Color presets:** A row of colored dots (black, dark grey, light grey, white) with the hex code #FF0000 below them.
- Brightness:** A horizontal slider with a circular knob, currently set at 75%.
- Routines:** A button with a play icon and the text 'On | off'.
- Power ON / OFF:** A button with a power icon.
- Control panel:** The overall area containing the controls.

Stay off

If power is cut, your light will stay OFF when reconnected to a power source.

On the app's home screen, select the in the top-right corner and select "Add a device". If your strip light is flashing, the app will detect it within a few seconds. When discovered, select the strip light icon, and select "Next."

Routines must be created within a 65 feet range of the strip light. When your phone is not in range, they will continue running but cannot be modified.

50798 12-035-22

50798 12-035-22



Diagramme de l'interface utilisateur de l'application Globe Suite, montrant les paramètres du matériel, les fonctions de l'application, le mode d'éclairage, la gamme de couleurs et sélecteur, les présélections de couleurs, la luminosité, les programmes, la mise en MARCHÉ / ARRÊT, et le contrôle.

* Les programmes doivent être créés dans un rayon de 20 mètres de l'ampoule. Lorsque votre téléphone n'est pas à portée, elles continueront à être exécutées mais ne pourront pas être modifiées.

PARTIE RESPONSABLE FCC : Globe Électrique, 2264 East 6th Street, San Bernardino, CA 92410, www.globe-electric.com

50798 12-035-22