

eClip - Quick Setup Guide



1. First Things First

First - and above all else - is the health, safety, and well-being of your baby. We believe that you will benefit from the eClip - but nothing can replace responsible parenting.

Reminder! After every journey, always check that you have removed your child from the car.


2. In the Box

- A. eClip (battery included)
- B. eClip Accessory Strap
- C. eClip Setup Guide.

The eClip Full User Guide can be downloaded (or viewed) from this address:



elepho.com/eclip/full-user-guide.pdf



3. Set it Up

First, download and install the eClip app that is suitable for your device.




elepho.com/apps

Note: Make sure that you give the eClip app permission to use your smartphone's Bluetooth and GPS. Without these services the eClip cannot monitor your baby.

Preparing the eClip Battery

The eClip includes a battery that should give you 500 hours of continuous use. It is shipped at full strength, and is protected against discharge by a plastic tab.



So, first, let's pull the plastic tab out.

1. Remove the eClip from the box and turn it over.
2. Take a coin and rotate the battery cover counter-clockwise until it comes off.
3. Lift up the battery, take the plastic tab out, and dispose of it.
4. Put the battery back in place, with the flat side, marked with a plus sign (+), facing up.
5. Replace the battery cover, turning it clockwise with a coin, until the coin is in line with the two H-clips.

Note: The battery cover is tight to prevent young children from opening it.

Once you close the battery cover the eClip's red LED flashes quickly three times to indicate that it is on. It will then continue to flash about once every second.

Note: If the eClip is disconnected from the eClip app for more than three minutes it will automatically turn off.

4. Installing the eClip in Your Car

As you can see from the eClip packaging, you have your choice of four convenient options to secure the eClip.




Baby car seat strap



Standard adult seat belt




Diaper bag strap



Included strap accessory

Warning: Always check manufacturers' recommendations before attaching the eClip to the strap of your baby's car seat or your vehicle's adult seat belt.


Once you've chosen a location for the eClip set it in place, as follows:




1. Slide one edge of the strap under one side of the H-clip on the back of the eClip.
2. Push the other edge of the strap under the second side of the clip. It should fit snugly.

Warning: Always make sure that the eClip stays out of your baby's mouth and that no liquids are spilled on or into the eClip.

5. Now it's time to get your smartphone to communicate with the eClip.



1. Launch the eClip app. Read and accept the terms and conditions on the Welcome screen.
2. On the Did You Know? screen tap GO TO SETTINGS to personalize your eClip with your child's name and picture, and to modify your sound alerts. See the Full User Guide * to do this now, or click the settings gear icon, at any time, to do it later.
3. Turn on your eClip by pressing the On/Off switch continuously for three seconds. The red LED flashes three times quickly, then once a second until pairing has been completed. When it is paired it flashes blue about once a second.



Note: To prevent accidentally turning the eClip off, you have to press the On/Off switch continuously for three seconds, to activate or deactivate the eClip

4. For ideal pairing setup, ensure that the eClip and app are less than 6 ft (2m) apart.
5. On the Did You Know screen tap CONNECT to eClip NOW.
6. The app displays the Connecting in progress screen.

Note: If you see the Cannot connect with eClip screen first check that the eClip is on and that your Bluetooth and GPS are activated on your smartphone then click Try to connect again.

7. After a successful pairing the app displays the App is now connected with eClip screen and the eClip red LED switches to a blue LED that flashes about once a second.

Note: After your first successful set up and pairing of the app, when you launch the app it should go straight through to the connecting screen.

6. Time to Start Monitoring

Once your baby is in the car seat and the eClip is securely in place, it's time to start monitoring.


1. Tap START MONITORING NOW.

Note: Monitoring will automatically begin a few seconds after the eClip has paired with the app even if you don't tap the Start Monitoring Now button

7. eClip feature overview

As you drive your smartphone will display the eClip monitoring screen.

Note: The eClip automatically turns off three minutes after you shut down the app.



A. Your Baby. The main function of the eClip is giving you a visible and audible alert if you move too far away from your child when you have parked your car.

A1. If you take your baby out of the car, but didn't turn off the eClip, just tap **SHUTDOWN APP** and confirm by tapping **YES**. The eClip automatically turns off three minutes later.

A2. Just in case you forget your baby you should receive a visual and audible alert when you go beyond about 25 feet (8 meters) from the car. Go back to your car and get your baby.

Note: The eClip alert should sound at full volume even if you have muted your phone. Once you have dismissed the alarm the volume returns to its previous setting.

B. Settings. Of course, our baby icon has much less personality than your baby. See the Full User Guide (see *) for more information about how to access Settings, upload a picture and type in your baby's name to add another reminder that your baby is onboard with you.

C. Battery Level. The battery is good for 500 hours of continuous use. Good battery health is very important, so we recommend that you replace it at least twice a year: at the start of summer and the start of winter. Always replace the battery when the battery level on the eClip Monitoring screen shows fewer than two bars. See the Full User Guide (see *) for more information about how to change the battery.

D. Bluetooth Signal. This shows the strength of your communication signal by the number of green waves. If the signal is lost the waves disappear, the icon turns red and the color of your eClip LED changes from blue to red. Correct the Bluetooth settings on your smartphone and tap CONTINUE MONITORING to renew the connection.

E. Temperature. The eClip app checks the eClip temperature every few seconds. By default temperature alerts are disabled. See the Full User Guide (see *) for information about how to enable alerts, change the measurement unit, modify the checking frequency, or define your temperature thresholds.

Note: Some iOS and Android devices attempt to override visual alerts. However, you should still hear the audible alert

Caution: If your smartphone goes into sleep mode, or if the screen turns off, the eClip app may also go into sleep mode and you will not receive any alerts.



* elepho.com/eclip/full-user-guide.pdf

Limited End User Warranty & FCC Warning



Limited End User Warranty

Elepho Inc (the "Company") warrants that their products (the "Product") are free of defects in material and workmanship for a period of one year (the "Warranty Period") from the date of purchase by end user. In the event that the Product qualifies for coverage under this warranty, the Company at its option and at no charge may either repair or replace the Product (not including, shipping, handling, delivery or installation) with an identical product or product having similar features and functionality as determined by the Company.

The Company does not warranty the installation, maintenance, or service of its Product. The Company is not responsible for ancillary equipment not supplied by the Company, which is attached to or used in connection with the Company's Product, or for the operation of the Product with any ancillary equipment, and all such equipment and operation of such equipment with the Product, is expressly excluded from this limited warranty. Furthermore, the Company shall not be responsible for any damage to the Product resulting from the use or operation of the ancillary equipment not furnished by the Company for use with the Product.

The Company extends this limited warranty only to the original end-user. This limited warranty and the remedies hereunder are limited to Products properly used, maintained, stored, installed and used for their intended purpose and use only, in accordance with the Company instructions. This warranty shall not apply to Product installed, operated or maintained in or under abnormal conditions. This warranty is not applicable to any Product, which is not operated and/or installed in accordance with the Company's specifications and or industry practices and standards. This warranty does not extend to any battery power supply included in/with the Product.

This warranty also does not extend to the purchase of opened, used, repaired, repackaged and/or resealed products, including but not limited to sale of such products on Internet auctions sites and/or sales of such products by surplus or bulk resellers. Any and all warranties or guarantees shall immediately cease and terminate as to any products or parts thereof which are repaired, replaced, altered, or modified, without the prior express and written permission of Elepho Inc.

This warranty sets forth all of the Company's responsibilities for the Product.

THIS WARRANTY IS GIVEN IN LIEU OF ALL OTHER EXPRESS WARRANTIES, IMPLIED WARRANTIES, STATUTORY OR OTHERWISE, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY. IN NO EVENT, INCLUDING WITHOUT LIMITATION, IN CONTRACT, TORT, STRICT LIABILITY OR WARRANTY, SHALL THE COMPANY BE LIABLE TO THE PURCHASER OR TO ANY THIRD PARTY, FOR ANY DAMAGES OR FOR ANY LOSS OF USE, LOSS OF TIME, INCONVENIENCE, COMMERCIAL LOSS, LOST PROFITS OR SAVINGS OR INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE SUCH PRODUCT. TO THE FULL EXTENT THAT SUCH MAY BE DISCLAIMED BY LAW, COMPANY'S SOLE LIABILITY SHALL BE TO REPLACE OR REPAIR THE PRODUCT..

FCC WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

