

USER MANUAL

Thank you for your purchase power bank, please read the manual carefully before the use. Enjoy your experience.

Features

- 1.Meeting your emergency and mobile charging needs;
- 2. Suitable for nearly all kinds of mobile phones and digital products with USB connector;
- 3. Built-in protection ICs to avoid over-charge, over-discharge, over-current and short circuit;
- 4. Intelligent power management solution for steadiness and high efficiency.

Executive Standard: GB31241-2014

Operate introductions

To charge your device:


Connect your device to the output of power bank, using a micro USB cable (see picture below).




To charge power bank

Method I: connect input of power bank to power adapter, using a micro USB cable (see picture 1)

Method II: connect input of power bank to the computer, using a micro USB cable (see picture 2)



picture1



picture2

Trouble shooting

Q: Unable to charge power bank.

A1: Check if power adapter is right one, and if connecting cable and connector works well.

A2: other brand power adapters are recommended for charging.

Q: Power bank unable to charge your device.

A1: Power bank voltage is too low, please charge it first.

A2: Your device voltage not compatible with power bank output voltage, please check your device voltage.

A3: Wrong connection between your device and power bank, or unqualified connecting cable and connector, please check them and use qualified ones.

A4: Power bank failure, please contact your local distributor.

Tips

- 1.Please charge power bank once at least every 3 months if no use for a long time.
- 2.When use, power bank gets a bit hot. It is normal if the heat is not over 60 degrees Celsius.
- 3.Keep power bank dry, no wipe with chemical cleansers.
- 4.Take care of environment, please recycle power bank at a designated place, do not dispose of randomly.

Important

- 1.Keep children and unqualified users out of reach of power bank, unless they are accompanied and guided by qualified people.
- 2.Do not crash, self-dismantle, stab, wet, dampen and squeeze power bank.
- 3.Do not place power bank in high temperature conditions, which may lead to its failure or fire.
- 4.Do not charge your device which is not compatible with power bank, otherwise it might cause failure or fire.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.