

Usage Notes

This product has been engineered with the utmost safety in mind, but please use common sense when using it.

1. Please double check the voltage of your electronic device before charging.
2. Keep the product away from extreme heat and cold as well as flammable objects or damp places. Avoid dropping, hitting or throwing the product.
3. Please use and fully charge your power bank at least once every 3 months to avoid shortening it's lifespan.
4. Do not attempt to charge your device at the same time as charging the power bank as this is harmful to the battery.
5. Do not attempt to open or disassemble the unit as the battery may explode or catch fire.

Warranty Information

All power banks are covered by a 1 year warranty.
Please retain your receipt as proof of purchase. The warranty does not cover:

- 1)Misuse or abuse of the product
- 2)Unauthorised service or modification.

Please contact us to obtain service, repair or a refund under warranty.

Magnetic Power Bank
15,000mAh
User Manual

Model number: BNY-50GW

- 4 -

Operation Instructions for Power Bank

1)Check the power remaining

Press the power button to illuminate the LED indicator lights. Each light indicates 25% of the total capacity remaining as shown below:

LIGHTING NUMBER	• • • •	• • •	• •	•
REMAINING POWER	100%	75%	50%	25%

The 4 LED lights show a capacity status of 25%, 50%, 75% and 100%.
The LED in green means the power bank is fast charging or discharging or in wireless charging.
Press the power button once to turn on the LED light to check the power status, and press the power button twice to turn off the LEDs. The LEDs will turn off automatically after several seconds of inactivity.

2)Illustration

1. Power button

2. USB-C input: PD-18W DC 5V/3A, 9V/2A

3. USB-C output: PD-20W DC 5V/3A, 9V/2.22A, 12V/1.67A

4. Wireless output: 5W/7.5W/10W/15W

5. LED indicator

3)Pack Contents

1X Magnetic Power Bank 15,000mAh

1X USB-C to USB-C Charge Cable

1X User Manual

Usage

1) Charge your power bank

The power bank can be charged via the USB-C port. Simply connect the power bank to a wall charger or laptop etc using the included USB-C cable or a certified USB cable. Once connected the LED indicators will light up to show that the power bank is being charged. When the power bank is fully charged it will turn off automatically.

2) Charge your mobile device with the power bank

A. Charge with cable

Connect your mobile device to the power bank with the appropriate certified or original USB cable. Once connected, the power bank indicator light will show up to indicate the remaining power level and charging will commence.

B. Magnetic wireless charging

Press the power button, the power bank is ready for wireless charging when the green light turn on. Simply place your iPhone 12/13/14/15 on top of the circle on the power bank so that it's aligned and secured in place with the magnets. Please note that a MagSafe compatible phone case (or a non-compatible phone case will need to be removed) for this to function as intended.

C. Standard wireless charging

Press the power button, the power bank is ready for wireless charging when the green light turn on. Place your Qi wireless cahrging compatible device on the top of the circle area on the power bank, the charging would start. The positioning of your device on the power bank may need to be adjusted to commence the wireless charging. Most devices will charge when centered on the power bank circle area.

- 2 -

- 3 -

备注：
型号：BNY-150GWB
材质：105g铜版纸，正反面印刷，中间折线
尺寸：60x100mm
要求：线稿为1:1，请按照文件比例输出

产品名称 Product	BNY-150GWB	订单号 PI No.		设计时间 Creating Date	2023-11-01
设计 Designer	KAY	确认 Checked by		联系方式 Contact No.	
业务 Sales	Shirley	审核 Approved by		BNY CONNECT & CHARGE 深圳柏宁远实业有限公司 Shenzhen BNY Industrial Co.,Ltd	

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.