0 mm

40 mm

LH98

LUMA XL

Design by Manuela Simonelli & Andrea Quaglio



ENGLISH

IN THE BOX No LUMA XL | No USB Type-C charging cable | No User manual

PRODUCT OVERVIEW
1. Touch area (glowing function)
2. Lamp
3. Base (with illuminating ring)
4. Wand fin

FEATURES
- LED technology with 9 colors (warm white, cold white, blue, yellow, green, red, purple, light pink & light blue)
- Dimmable LED lights with memory system
- Rechargeable battery (3.7V 2600mAh 9.6Wh)
- Suitable for outdoor use (IP54)
- Rechargeable via wireless charging or USB-Type-C

CHARGING
We recommend you to fully charge the battery before using LUMA XL for the first time.
Charging time: approx. 4 hours (it should take approximately 2 hours USB charging and 4 hours via wireless charging).

LED information

Operation mode	LED status (Red LED)
Charging	LED solid red
Fully charged	LED turns off
Low battery	LED blinks red

Charge with USB cable
1. Plug the provided USB Type-C cable into the charging port of LUMA XL.
2. Plug the USB port end of the cable into any computer or any 5V 2A power supply charger.

Charge with Wireless Charger
1. Place LUMA XL at the center of the charging receiver. You can charge the battery by using a wireless charger.
2. Place LUMA XL at the center of the wireless charger.
3. Disconnect the device once the battery has been fully charged

OPERATING INSTRUCTIONS
Switching on your LUMA XL lamp
- Touch the sensor area on the top of LUMA XL.
- There are 9 color options you can select by simply touching the top of the lamp.
- To adjust brightness, touch the top area until you reached the desired brightness then release.
- LUMA XL will save the last color and brightness selection then touch again.
- The last color will be activated the next time.

Note: If you want to set LUMA XL in cool and warm light mode only, quickly tap 3 times on the top lamp. To return to full all lighting mode, repeat the process.

Syncing several LUMA XL lamps (Interconnection network)
Each LUMA XL lamp has a built-in BT 5.0 chip. You do not require any third-party software/device.
To enjoy the multiple LUMA synchronization feature, follow below instructions:

1. Repeat #2 mentioned at bottom of the button of each lamp for 5 seconds to turn ON the communication mode.
The Blue LED will flash rapidly for 30 seconds.
2. Select one of the lamps and press the BT button twice to initiate the multi-pairing procedure.
The Blue LED will flash slowly for 30 seconds during pairing.
3. The lamp connectivity is successful once recorded a MASTER in the system, its LED will keep flashing while others are turned OFF.

You can now interact from any lamp the color change, adjust brightness or turn ON & OFF all lamps at once.

Important note: Bluetooth connectivity is limited to 10 meters max. It is strongly recommended to always keep the MASTER device in charge or fully charged to get the best experience and avoid loss of control of the entire network.

Other technology user's guides
- Touch control: Touch the sensor area on the top of the device. Double tap for the key of the MASTER device. You'll need to tap on the MASTER again to turn all lamps back ON.
- Timer setting: Press the BT button for 3 seconds to enter the timer mode, the BT button from then 10 seconds until the lamp turns OFF. (The default timer setting is 30 minutes. You can change the timer setting to 1 hour or 2 hours as needed)
- To adjust the lamp, insert a thin object into the hole (2) under the lamp and press the key inside.
- A manual reset allows you to disconnect and cancel miscellaneous logs (unrecognized device, unstable Bluetooth connection...)

LED information

Operation mode	LED status (Blue LED)
Pairing	LED flashes rapidly
Setup device	LED flashes every 3 seconds
Battery low	LED flashes every 3 seconds

SAFETY PRECAUTIONS
- IP54 water resistant device, resistant to rain, splash, and spray water.
- Do not use this device in any manner contrary to its intended purpose, modifying, fire, deformation or even explosion of the battery.
- Do not store your device in very hot or cold areas. It is recommended to use your device between 0°C and 40°C.
- Do not attempt to service, repair or disassemble the device yourself.
- Do not use the device if the battery is damaged or leaking. Do not continue to use it power adapter/ dimming mode/ voltage output that the one indicated to avoid any irreversible damage to the internal circuit (DC Input 5V).