




Wireless Video Doorbell

Front of Doorbell




Get support visit [support.goabode.com](https://support.goabode.com)


For setup instructions, download the Abode App on:




Back of Doorbell




Top of Chime



Left Side of Chime



Back of Chime



Pairing Process

- 

Remove the Doorbell, Chime, Ethernet cable, USB charging cable, and Chime power adapter from the box.
- 

Open the rubber flap on the back of your Doorbell and turn on the switch located beneath the charging port. Close the flap.
- 

Plug the supplied Chime power adapter into a wall outlet and the Chime.
- 

Connect the Chime to an available port on your router with the provided Ethernet cable. The Chime's LED lights will turn blue.
- 

Download the Abode App and go to the Devices tab or Settings menu to add a new device.

**FCC Warning:**

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**FCC Radiation Exposure Statement:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**ISED RSS Warning:**

This device complies with ISED licence-exempt RSS standard (s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'ISED applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

(1) l'appareil ne doit pas produire d'interférence, et (2) l'appareil doit accepter toute interférence radioélectrique subie, même si l'interférence est susceptible d'en compromettre le fonctionnement.

**ISED Radiation Exposure Statement:**

This equipment complies with ISED RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Cet appareil est conforme aux limites d'exposition de rayonnement RF ISED établies pour un environnement non contrôlé. Cet émetteur ne doit pas être co-implanté ou fonctionner en conjonction avec toute autre antenne ou transmetteur.

Cet équipement doit être installé et utilisé avec une

distance minimale de 20cm entre le radiateur & votre corps.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Tous changements ou modifications non expressément approuvés par la partie responsable de la conformité peut annuler l'autorité de l'utilisateur à opérer l'équipement.

For detailed mounting and operating instructions go to [support.goabode.com/docs/doorbell](https://support.goabode.com/docs/doorbell)

Abode Systems, Inc., 2625 Middlefield Road #900, Palo Alto, California 94306, United States  
© 2022 Abode Systems, Inc. All rights reserved.

Model :WVD  
Specifications :WVD-KSZ  
P01 V1.0  
Material code :  
040600600216