

说明书尺寸:540 x 76mm

MINISO

PRODUCT MANUAL

使用說明書

WIRELESS SPEAKER

格爾內戶外隨身藍牙音箱

MODEL: BT323

使用產品前請仔細閱讀本使用說明書，並請妥善保管。
PLEASE READ THIS MANUAL CAREFULLY BEFORE USING THE
PRODUCT AND KEEP IT IN A SAFE PLACE.

尊敬的客戶

非常感謝你選用BT323隨身聽藍牙音箱。請在使用前，詳細閱讀本說明書，正確操作使用，更好的發揮產品優越性能。本產品外觀設計時尚鉅麗，小巧便攜，音質純美，多功能一體化設計，全系列擁有外觀專利系統上採用行業領先電聲技術，使你在居家使用、戶外旅行、商務工作中隨時隨地享受到卓越的音響效果，為你的平板電腦、手機、數碼音樂播放機等廣泛視聽產品提供超值完美的音質，炫彩隨身聽炫彩精靈，驚艷之美！

注意事項

請在常溫環境中存放以及使用本產品；
請勿將本產品暴露在中或潮濕環境中；
請勿丟擲，避免因跌落造成產品損壞；
請勿自行拆解、修理和改造本產品；
產品內置鋰電池，請勿隨意丟棄或置以火中，以免引起危險！

溫馨提示

1. 為有利於延長音箱使用壽命和你的身心健康，請不要在長時間大音量的環境下聽音，以免損害你的聽力。
2. 出現故障時，請立即關斷電源開關，拔掉USB插頭，防止揚聲器及其它元件損壞。
3. 電量不足會影響藍牙距離或藍牙容易斷開，請及時充電。

外型及功能按鍵

電源鍵

音量+/下一曲

音量-/上一曲

Micro USB充電介面

AUX位置

產品參數

產品型號: BT323 藍牙規格: Bluetooth V5.0
傳輸距離: ≤10M (因環境因素及連接的藍牙設備不同而不同)
USB充電電源: DC 5V--500mA
內置電池: 鋰電池
輸出功率: 3W
有效頻寬: 180Hz-15KHz
靈敏度: 78db±3db
信噪比: ≥76dB

系統組成

1. 音箱×1台
2. USB電源線×1條
3. 說明書/保修卡×1份

常用功能說明

開機狀態: 長按“▲”2秒打開音箱，音箱會發出“哪-哪”的提示音，同時藍燈閃爍。
再次長按“▲”2秒关闭音箱。

藍牙連接: 電源打開後，音箱自動進入藍牙搜索狀態，藍燈閃爍；搜索配對，配對名為MINISO BT323藍牙設備會提示是否配對？點擊配對，連接成功後，藍燈長亮，音箱會發出哪一聲提示音。在電源打開後5分鐘內藍牙音箱找不到任何設備藍牙將自動關閉，要再次連接需要重新開關上電。本機具有回聯功能，成功連接後的設備再次打開藍牙時會自動連接。
溫馨提示: 如果連接失敗請開機重啟或有可能電池電量不足，請充電。

藍牙音樂播放: 藍牙連接成功後，打開藍牙設備播放音樂，在播放過程中，短按“▲”，暫停。在暫停中短按“▲”，播放。

音量+/-和上下曲: 在播放時，短按“-”鍵為音量-功能；短按“+”鍵為音量+功能。長按1S“-”鍵為上一曲功能；長按1S“+”鍵為下一曲功能；

AUX模式: 開機後，音箱端插AUX線，進入AUX模式。拔出AUX線音箱回到藍牙模式。

免提通話: 藍牙音響與手機連接成功後，當有來電時，音箱會發出“嘟嘟”提示音；按“▲”接聽電話，可以代替手機與對方通話，再按“▲”掛斷電話結束通話。來電長按“▲”鍵拒接。

智慧自動快充: 待機或開機狀態下充電。將附件提供的USB電源線Mini USB端插入音箱USB電源插口，另一端連接電腦USB埠或USB充電器，開始充電，待機充電時，指示燈紅藍交替閃，充滿紅燈滅；開機充電，紅燈常亮，充滿紅燈滅。

藍牙協議及兼容性

BLUETOOTH V5.0 包括如下協定: A2DP, AVCTP, AVRCP, SPP, SMP, ATT, GAP, SDP, RFCOMM, GATT, L2CAP、支援手機、平板PC及絕大多數藍牙設備。

常見問題解決方法

問題	現象	解決方法
多次連接配對不成功		1. 檢查音響是否處於搜索狀態，或重新開機。 2. 周邊藍牙設備太多，造成搜索困難，關閉其他藍牙設備。
聲音小或失真		1. 檢測藍牙設備音量，調節其音量至合適位置。 2. 電池電壓低請充電。
音樂出現斷音		是否超出音響有效連接距離，或音箱與藍牙設備有障礙物。
藍牙狀態指示等不亮		1. 表示電池電量不足，請充滿再試。 2. 重新開機

MADE IN CHINA
FABRIQUE EN CHINE
صنع في الصين
HECHO EN CHINA
www.miniso.jp

CEFCRoHSFCC ID: XXXX

Dear Customer Thank you for purchasing our BT323 Wireless Speaker. Please read this manual carefully prior using the product and save it for future reference. Its appearance is stylish and beautiful, small and compact, multifunctional design. Integrate with industry-leading electroacoustic technology, can be used at home and for business trips, so you can enjoy excellent sound effects anywhere and anytime. Compatible with a wide range of audiovisual products, like tablets, cellphones, and music players, providing an exceptional sound quality. Attention Please store and use at room temperature. Do not expose the product to humidity. Do not throw or crash the appliance to avoid damaging it. Do not disassemble, repair or modify the product by yourself. Contains built-in lithium battery. Do not put the product into fire to avoid the risk of explosion. Tips 1. To extend the lifespan of your speaker and to improve your physical and mental health, please do not play at high volume for a prolonged time otherwise it may affect your hearing.		2. When the speaker gets damaged, please turn off the power switch and unplug the USB plug to prevent damage. 3. When the speaker is running on low power, it might affect the BT transmission distance or the BT suddenly turned off, please charge in time. Functions Power button Volume + / next song Volume - / previous song Micro USB charging port AUX location		Specifications Model: BT323 BT version: BT V5.0 Transmission range: ≤10M (depending on the environmental factors and if is connected to wireless devices) USB power supply: DC 5V--500mA Built-in battery: lithium battery Output power: 3W The effective bandwidth: 180Hz-15KHz Sensitivity: 78db±3db Signal-to-noise ratio(SNR): ≥76dB Product and accessories 1. Speaker × 1 2. USB power cable × 1 3. User Manual/Warranty Card × 1 Instructions Turning on: Long press "▲" for two seconds, voice prompt can be heard and the blue light will flash. Press "▲" again for 2 seconds and the speaker will turn off.		BT pairing: After being turned on, the speaker automatically gets into pairing mode and blue light will flash. Search for the device with name MINISO BT323, prompt will be heard when connected. Press pair, blue light will stay on, voice prompt can be heard. If the speaker does not get paired within 5 minutes after turning on, it will turn off automatically. It needs to be turned on and connected again. The speaker will automatically connect to the last device it has been connected before. Note: If the pairing was unsuccessful, restart the speaker or charge it in case of low power. Music playing: After being connected successfully, choose the song on your device and play it. During playing, short press "▲" to pause. Press "▲" to play. Adjusting volumes & choosing songs: When playing, short press "-" to decrease the volume or short press "+" to increase the volume. Long press "-" for one second to go back to previous track. Long press "+" for one second to skip to next track. AUX mode: Plug the AUX cable after turning the speaker on. Plug the AUX cable out and the speaker will go back to BT mode. Calls: When the speaker is successfully connected to the cellphone and there is an incoming call, the voice prompt can be heard. Press "▲" to answer the call and the speaker can be used for communication. Press "▲" to hang up the call. Long press "▲" to reject the call. Intelligent quick charging: Charge the speaker when it is in standby mode or turned off. Connect one end of provided Mini USB cable to power source and the other end to USB port on the speaker. When charging in standby mode, red and blue light will flash alternatively. After being fully charged, red light will dim out; When charging while being turned off, red light will be on. After being fully charged, red light will dim out.		Troubleshooting <table><tr><th>Manifest</th><th>Solution</th></tr><tr><td>Pairing fails repeatedly</td><td>1. Check if the speaker is in searching state or restart the device. 2. Many wireless devices in surroundings, which makes searching difficult, it is recommended to disable other wireless devices.</td></tr><tr><td>Low or distorted sound</td><td>1. Check the device volume, adjust to the moderate volume. 2. Low power, please charge the battery.</td></tr><tr><td>Cracking noise</td><td>Check whether the maximum distance for sound connection was surpassed or if there are obstacles between the speaker and the connected device.</td></tr><tr><td>LED is not working</td><td>1. Low battery. Please charge the battery and try to again. 2. Restart the speaker</td></tr></table>		Manifest	Solution	Pairing fails repeatedly	1. Check if the speaker is in searching state or restart the device. 2. Many wireless devices in surroundings, which makes searching difficult, it is recommended to disable other wireless devices.	Low or distorted sound	1. Check the device volume, adjust to the moderate volume. 2. Low power, please charge the battery.	Cracking noise	Check whether the maximum distance for sound connection was surpassed or if there are obstacles between the speaker and the connected device.	LED is not working	1. Low battery. Please charge the battery and try to again. 2. Restart the speaker	FCC information This device complies with Part 15 of the FCC Rules, Operation is subject to the following two conditions: (1) This device may not cause harmful interference (2) This device must accept any interference received, including interference that may cause undesired operation. Please note that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: --Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -- Consult the dealer or an experienced radio/TV technician for help.	
Manifest	Solution																				
Pairing fails repeatedly	1. Check if the speaker is in searching state or restart the device. 2. Many wireless devices in surroundings, which makes searching difficult, it is recommended to disable other wireless devices.																				
Low or distorted sound	1. Check the device volume, adjust to the moderate volume. 2. Low power, please charge the battery.																				
Cracking noise	Check whether the maximum distance for sound connection was surpassed or if there are obstacles between the speaker and the connected device.																				
LED is not working	1. Low battery. Please charge the battery and try to again. 2. Restart the speaker																				