

DEAR CUSTOMER

Thank you for choosing BT295 wireless charger with BT speaker, please read this manual carefully for correct use, it helps to better perform this product. It is stylish, compact and portable with pure sound quality in an integrated multifunctional design. The full range of patented systems with industry-leading electro-acoustic technology enables you to use at home, outdoor and travel, enjoy great sound effects anytime and anywhere. Provides great sounds value for your wide range of audiovisual products such as tablets, mobile phones, digital music players, etc.


PRECAUTIONS

Please store and use this product in a normal temperature;
Do not expose this product to rain or humidity;
Do not throw this product to prevent damage caused by falling;
Do not disassemble, repair or modify this product by yourself;
This product has built-in lithium battery. Do not throw it away or put it into fire to avoid dange!

HELPFUL TIPS

1.To help extend the lifespan of speakers and maintain your physical and mental health, please do not listen at high volume for a long time to avoid damaging your hearing.
2.In case of failure,turn off the power switch and unplug the USB immediately, prevent damage to speaker and other components.
3.Insufficient power will affect the BT distance or even disconnection, please charge in time.

APPEARANCE AND BUTTONS



PARAMETER

Model: BT295
BT standard: V4.2
Transmission distance: ≤10M (vary depends on environmental factor and connected device)
USB charging power supply: DC 5V—400mA
Built-in battery: 500mAh
Output battery: 2W
Wireless charging power: 5W
Frequency response: 90Hz-20KHz
Sensitivity: 80db±2db
S/N ratio: ≥76dB
Size: 62X90mm
Net weight: 232.5g

COMPONENTS

1. Speaker	1 pc
2. USB cable	1 pc
3. User manual/Warranty card	1 pc

COMMON FUNCTIONS

Different status of speaker are:
1.1 STANDBY
1.2 BT PAIRING
1.3 BT RECONNECT
1.4 BT CONNECTED (STREAMING)
1.5 BT CALLING

Operation as below:
Buttons:
2.1 When the speaker is off, long press the POWER button for two seconds to turn on (other operations are invalid). When the speaker is on, long press POWER button for two seconds to turn on (standby power consumption is less than 100uA)
2.2 Automatically starts for pairing after turned on, it also has reconnection function.
2.3 Connected status, click PLAY button to play/pause.
2.4 Connected status, long press BT button for three seconds to disconnect the current connection and enter to pairing status,
2.5 Incoming call status, click the PLAY button to answer, long press PLAY button to reject.
2.6 During the call, click PLAY button to hang up, long press PLAY button to switch between mobile phone and speaker.
2.7 Long press PLAY button for 10 seconds to restore to default setting.
2.8 Third party calls are not supported.

LED light:

3.1 In standby mode, all LED lights are off.
3.2 Blue LED light flashes quickly in pairing mode or reconnection status.
3.3 Blue LED light is on while BT is connected.
3.4 Blue LED light flashes slowly in BT playing status.
3.5 When the speaker is charging, its red light will turn on, and the red light will go off if charging completed .
3.5 The wireless charging part is illuminated by red light when plugged into USB, when it detects that there is no chargeable device, the power automatically switches to charge the speaker. When an external chargeable device is detected, it lights up in green and automatically starts charging.

CHARGING EXPLANATION

1. You need to plug in the USB to wirelessly charge mobile phone
2. After plugging in USB, if no chargeable device is detected, it will automatically charge to the speaker

HINT TONE

1. They are: power on, power off, disconnected, connected, incoming call ringtone etc.
2. The incoming call ringtone volume defaults to 80%

BT PROTOCOL AND COMPATIBILITY

BT V4.2 includes: A2DP、HFP、AVRCP. Support mobile phones, tablet PCs and most of the BT devices.

COMMON PROBLEMS AND SOLUTIONS

PHENOMENON PROBLEM	SOLUTIONS
Fail to connect for several times	1. Check if the speaker is in search status, or reboot 2. Many BT devices is around causing search difficulties, turn off the other BT devices.
Low sound or distorted sound	1. Check the volume of BT device, then adjust it to appropriate place 2. Low battery, please charge in time.
Intermittent sound	Check whether beyond the effective connection distance of speaker, or obstacles between speaker and BT device.
BT status light does not work	1. Indicates low battery, please fully charge then try again. 2. Reboot the speaker.

FCC information

This device complies with Part 15 of the FCC Rules, Operation is subject to the following two conditions:
(1)This device may not cause harmful interference
(2)This device must accept any interference received, including interference that may cause undesired operation.
Please note that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: --Reorient or relocate the receiving antenna. --Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

RF exposure warning :
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment shall be installed and operated with minimum distance 20cm between the radiator & body.
www.miniso.jp

MINISO JAPAN

株式会社 名創優品産業
〒104-0061東京都中央区銀座3-10-7
銀座京屋大厦7楼
MINISO INDUSTRIES CO.,LTD.
GINZA KYOYA BLDG. 7F
3-10-7 GINZA, CHUO-KU, TOKYO 104-0061, JAPAN

CE

FCC ID: XXXXX

RoHS

Designed by Japan. Made in China