




EN

Model:
HK500,
HK500+

AT A GLANCE

the important bits, quick and easy



EN1



2EN

CHARGE IT

let's get you up and running

To charge your headset, plug the Type C cable into the headset's Type C port and connect to Type C power source.

Note: Fully charge the headset before you use it.

Tip: To save battery power, turn off the headset when you're not using it.


Caution: Your battery is designed to last the life of your device. It should only be removed by a recycling facility. Any attempt to remove or replace your battery will damage the device, void your warranty, and could cause injury.

3EN

CONNECT & GO

let's get you connected

EASYPAIR™METHOD



4EN

COMFORT

what feels best on you

Choose your most comfortable fit ear tip.



5EN

BASICS

standard features, advanced quality

To:		
answer a call	short press MPB	
reject a call	press volume down 2 seconds	
end a call	short press MPB (on)	
off	boom close (off)	
change call volume	press the volume up and volume down button	
mute or unmute a call	press volume down 2 seconds during the call and press volume up 2s to unmute	
last track	press volume down 2 seconds when headset is in music state	
next track	press volume up 2 seconds	

6EN

To:

pause/play	press MPB once to pause and press again to play.
pairing mode	press MPB 5 seconds to enter into pairing mode when headset is in on mode
reset	press MPB and volume down 5 seconds
5-way call ongoing	
pick incoming call, put ongoing call on hold	press MPB once
reject incoming call, continue ongoing	press and hold volume down
end ongoing, resume waiting call	double press MPB
switch calls	press MPB once
end current call	double press MPB

7EN

Notes:

• Some features are phone/network dependent

• Using a mobile device or accessory while driving may cause distraction and may be illegal. Always obey the laws and drive safely.

STATUS LIGHT

If light shows:	your headset is...
power on	blue flashes 1 second
power off	red flashes 2 seconds
pairing	red & blue flashes alternately
on standby	blue flashes once every 5 seconds
charging	steady red
fully-charged	steady blue
low battery	red flashes once every 5 seconds

8EN

Note:

After one minute on a call or 20 minutes of inactivity, the light stops flashing to conserve power, but the headset remains on. Closing the Boom also saves battery life.

ADVANCED

More clever stuff

SECOND DEVICE

Do you use two phones? Or maybe a phone and a tablet? Connect with both of them.

- Pair the first device with your headset as normal (see "CONNECT & GO" on page 4).
- Turn off the Bluetooth feature on the first device.
- Now pair the second device with your headset as normal.
- Once paired, to connect with both devices simply turn them on.

9EN

SETTINGS

Restore Factory Settings:
Reset default factory settings on your headset.

Caution:
This feature erases all device pairing information stored on the headset.

MultiPoint:
Connect your headset to two devices.

10EN

Safety Instructions for use

To avoid hearing damage, keep the volume at a moderate level. Avoid listening to music at loud volume levels for prolonged periods of time as this may cause permanent hearing damage or hearing loss. Your hearing is delicate and highly sensitive so please listen to your music responsibly. For more information visit the Deafness Research Foundation www.drf.org.

Don't use HK500/HK500+ when it is unsafe to do so. For example, while operating a vehicle, cycling, crossing a road, or any activity which requires your attention and ability to hear.

You should be aware of your surroundings and use HK500/HK500+ responsibly.

11EN

Help & more

Note: If you're watching video while using our earbuds, your audio may be slightly out of sync with your video.

Manufactured, distributed or sold by Meichuo Guo Wei Electronics Co. LTD, official licensee for this product. MOTOROLA and the Stylized M Logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC and are used under license. All other trademarks are the property of their respective owners.

© 2021 Motorola Mobility LLC. All rights reserved.



12EN

General Information

Consumer Products and Accessories Limited Warranty

Thank you for purchasing this Motorola branded product manufactured under license by Meichuo Guo Wei Electronics Co. LTD ("MGW").

What Does this Warranty Cover?

Subject to the exclusive contractual terms, MGW warrants that this Motorola branded product ("Product") is certified accuracy ("Accuracy") sold for use with this product that is manufactured to be free from defects in material and workmanship under normal consumer usage for the period outlined below. This Warranty is your exclusive warranty and is not transferable.

Who is covered?

This warranty extends only to the first consumer purchaser, and must be transferred.

What will MGW do?

MGW or its authorized distributor at its option and within a commercially reasonable time, will at its charge repair or replace any Products or Accessories that do not conform to this Warranty. We may use functionally

13EN

equivalent reconditioned/ refurbished/ pre-owned or new Products, Accessories or parts.

What Other Limitations Are There?

ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY, OTHERWISE THE REPAIR OR REPLACEMENT PROVIDED UNDER THIS EXPRESS LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER, AND IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, IN NO EVENT SHALL MOTOROLA OR MGW BE LIABLE WHETHER IN CONTRACT OR TORT (INCLUDING NEGLIGENCE) FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT OR ACCESSORY, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL, OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE ABILITY OR INABILITY TO USE THE PRODUCTS OR ACCESSORIES. TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW.

14EN

Some jurisdictions do not allow the limitation or exclusion of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you. This Warranty gives you specific legal rights, and you may also have other rights that vary from one jurisdiction to another.

Product Covered	Length of Coverage
Consumer Products	One (1) year from the date of the product's original purchase by the first consumer purchaser of the product.
Consumer Accessories	Ninety (90) days from the date of the accessory's original purchase by the first consumer purchaser of the product.
Consumer Products and Accessories that are Repaired or Replaced	The balance of the original warranty or for Ninety (90) days from the date returned to the Consumer, whichever is longer.

15EN

Exclusions

Normal Wear and Tear: Periodic maintenance, repair and replacement of parts due to normal wear and tear are excluded from coverage.

Absent & Misuse: Defects or damage that result from: (a) improper operation, storage, misuse or abuse, accident or neglect, such as physical damage (cracks, scratches, etc.) to the surface of the product resulting from misuse; (b) contact with liquid, water, rain, extreme humidity or heavy perspiration, sand, dirt or the like, extreme heat, or food; (c) use of the Product or Accessories for commercial purposes or subjecting the Product or Accessory to abnormal usage or conditions; or (d) other acts which are not the fault of MOTOROLA or MGW, are excluded from coverage.

Use of Non-Motorola branded Products and Accessories: Defects or damage that result from the use of Non-Motorola branded or certified Products or Accessories or other peripheral equipment are excluded from coverage.

Unauthorized Service or Modification: Defects or damages resulting from service, testing, adjustment, restoration, maintenance, alteration or modification in any way by someone other than MOTOROLA, MGW or its authorized service centers, are excluded from coverage.

16EN

Altered Products: Products or Accessories with (a) serial numbers or data tags that have been removed, altered or obliterated; (b) broken seals or that show evidence of tampering; (c) mismatched board serial numbers; or (d) nonconforming or non-Motorola branded housings, or parts, are excluded from coverage.

Communication Services: Defects, damages, or the failure of Products or Accessories due to any communication service or signal you may subscribe to or use with the Products or Accessories is excluded from coverage.

How to Obtain Warranty Service or Other Information?

To obtain service or information, please visit: motorola.com/support

You will receive instructions on how to ship the Products or Accessories at your expense and risk, to a MGW Authorized Repair Center.

To obtain service, you must include: (a) the Product or Accessory; (b) the original proof of purchase (receipt) which includes the date, place and seller of the Product; (c) if a warranty card was included in your box, a completed warranty card showing the serial number of the Product; (d) a written description of the problem; and, most importantly, (e) your address and telephone number.

17EN

Disposal of the Device (environment)

At the end of the product life cycle, you should not dispose of this product with normal household waste. Take this product to a collection point for the recycling of electrical and electronic equipment. The symbol on the product, user's guide and/or box indicates this.

Some of the product materials can be re-used if you take them to a recycling point. By mixing some parts or raw materials from used products you make an important contribution to the protection of the environment. Please contact your local authorities in case you need more information on the collection points in your area.

European Union Directive Compliance Statement

The following CE compliance information is applicable to Motorola products that carry one of the following CE marks:

Hereby, MGW declares that this product is in compliance with:









Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

• Reorient or relocate the receiving antenna.

• Increase the separation between the equipment and receiver.

• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

• Consult the dealer or an experienced radio/TV technician for help.

18EN

Disposal of the Device (environment)

At the end of the product life cycle, you should not dispose of this product with normal household waste. Take this product to a collection point for the recycling of electrical and electronic equipment. The symbol on the product, user's guide and/or box indicates this.

Some of the product materials can be re-used if you take them to a recycling point. By mixing some parts or raw materials from used products you make an important contribution to the protection of the environment. Please contact your local authorities in case you need more information on the collection points in your area.

European Union Directive Compliance Statement

The following CE compliance information is applicable to Motorola products that carry one of the following CE marks:

Hereby, MGW declares that this product is in compliance with:









Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation of the device.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

• Reorient or relocate the receiving antenna.

• Increase the separation between the equipment and receiver.

• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

• Consult the dealer or an experienced radio/TV technician for help.

19EN

SIZE:65X80MM