



the wall.

11. Insert the supplied screws into the wall anchors.
12. Fix and tighten the screws on the wall.
13. Hang the Sound Bar on the screws.




5 Connect your Sound Bar system

After you have fixed the position of the Sound Bar, you can start connecting it to your TV or other devices and listen to the audio through your Sound Bar. Make sure you have muted the audio of your TV or device. For information, check the user manual of your TV or device.

Connect with the AC power adaptors

Connect the supplied AC power adaptors to the sound bar and subwoofer.



Connect with the HDMI cable

Note:


Make sure your TV or device supports the HDMI ARC feature. For information, check the user manual of your TV or device.

Connect one end of the HDMI cable to the HDMI ARC input connector on your Sound Bar and another end to the HDMI ARC output connector of your TV or device.

To get the best possible audio experience using the HDMI cable, follow below given steps:


For TCL TV:

- Connect HDMI cable from the HDMI (ARC) interface on the sound bar to the HDMI (ARC/eARC) interface on the TV. Connect power cord.
- Enable the CEC function in the settings of the TCL TV.



Connect with the optical cable

1. Remove the protective caps from the optical cable when necessary.
2. Connect one end of the optical cable to the optical input connector on your Sound Bar and another end to the optical output connector of your TV or device.



Note


- If there is no sound output from the Sound Bar, try to activate the PCM signal output on your TV or device. PCM is used to convert analog audio signals into digital audio

signals in most devices. For more information of how to activate the PCM signal output, check the user manual of your TV or device.

Direction for setting up your Sound Bar using an optical cable



Do not bend or kink the optical cable (SPDIF) as it is fragile and can easily get damaged and broken.



To get the best possible audio experience using the optical cable:

- 1 Press the Home button on your TCL TV Remote.
- 2 Navigate to **Audio option** under **Settings**.
- 3 Uncheck the “**TV speaker enabled**” option.
- 4 Under **S/PDIF** and **ARC**, select **PCM-Stereo**.

Notes

- *Different devices may have different menu options.*
- *Devices such as Blu-ray players, set-top boxes, etc. are also applicable.*

Connect with USB disk

- Press ►|| on the remote control to listen to/pause/ resume the music.
- Press ◀| or ▶| on the remote control to skip to the previous or next track.
- Press + or - to increase or decrease the volume level.

6 Use your Sound Bar system

Get Started:

1. Make sure you have made all the necessary cable connections before connecting the Sound bar to a wall outlet, the sound bar will enter to standby mode, the indicator will light up in red.
2. Make sure the subwoofer is connected to the power, and turn the button to "ON"
3. Press "⏻" on unit or remote control to turn on the sound bar. The Bluetooth indicator will light up.
4. Press "⏻" on unit or on remote control to choose various source.

Operation instruction

⌘ Bluetooth Mode

After power on, the machine directly enters Bluetooth mode, along with voice prompt and white light slow flash; long press "⌘" on Sound bar, Bluetooth enters the pairing status,

with voice prompts and white light fast flash.

1. Put the phone within 9.8' in distance;
2. Activate the Bluetooth function of the phone, so that the phone starts to search for the Bluetooth device (please refer to the phone instructions for details);
3. Select "TCL S21BW" from the device that has been searched for, click connection, with voice prompt;
4. If the phone remind you to enter password, enter "0000" and press confirm button to match sound bar to the phone;
5. Press the back button of the phone to exit the phone menu. Make sure the distance between sound bar and phone is within 32.8' and there is no obstacles. At this time, music can be played on the sound bar;
6. Short press "▶||" to play and pause music. Short press "◀◄" or "▶▶" button to previous or next song;
7. To disconnect, short press or long press the "📶" button on the sound bar, At this time, another mobile phone device can be used to connect Bluetooth playing; If the connection is not selected, the machine will be on waiting for connection status.

⌘ AUX Mode

After power on, connect the external audio sources to the AUX jack of sound bar by using the 3.5mm audio cable, and then Press the "🔊" button on the sound bar or the "AUX" button on the remote control to switch to "AUX" mode. At this time, music from the external audio sources such as MP3/CD can be played. (please adjust the volume of the external audio sources accordingly at a comfortable level.)