



CoolR Group



CoolR
Vista

Contents

1.Pre-install Checklist.....	2
2. Physical Installation.....	3
Initiate	3
Identify install position.....	3
Install	3
Provisioning	3
Login	3
3.Device Monitor	4
1.From Home screen Expand main menu ()	4
2.Select “Device Monitor” from the list.....	4
Configuration & Install	4
Settings: WIFI Vista Mode Enable/Disable	5
Troubleshooting	6

Pre-install Checklist

1. Hardware installation items
 - a. Vista
 - b. Paper or lint free cloth to clean the glass surface
2. For software configuration
 - a. Android phone with Android 4.4 or above and Bluetooth 4.1 or above
 - b. Bluetooth and internet connectivity on the phone
 - c. Ideally GPS should also be on
 - d. Login credentials for the application

Physical Installation

Initiate

1. Note down the serial# & MAC address of the vista.
2. Note down the asset (cooler serial/name) & outlet (location/store) details

Identify install position

1. Coolr Smart Vista should be placed on inner wall of the Door of the cooler.
2. Ideally, Vista should be placed vertically at center of cooler door on handle side.



Install



1. Clean the glass to remove any moisture
2. Stick the device in vertical position inside Cooler with camera facing towards the hinge/inside & Push the device and hold for about 5 seconds.



Provisioning


Login

1. Login to the “Coolr Smart Device” Application from Playstore/App store




Device Monitor

1. From Home screen Expand main menu (☰)
2. Select "Device Monitor" from the list.
3. In device monitor screen, expand options menu on top right (⋮) & Select "Start Scan" & wait for scan to show you vista device.



Configuration & Install




1. Once you see you vista serial you can connect to it by selecting blue circle next to the serial number.
2. After connecting with vista, expand options menu on top right (⋮) & Select "Install"



3. After successful Install the pop-up will appear “Device Installed successfully”
4. You can select the back (Arrow) button to return back to device monitor screen.

Settings: WIFI Vista Mode Enable/Disable

1. Navigate to Device Monitor Screen & Reconnect with the Vista device, expand options menu on top right (⋮) & Select “Start Scan” & wait for scan to show you vista device.
2. Select the appropriate Device Serial by Selecting the “V” icon to enter onto the Device Details screen.



3. Scroll down till where “Wifi Settings” details have mentioned.

- Enable the WIFI Vista Mode
- Enter SSID and Password
- Select “Send”
- Select Save icon.


NOTE:

- If success, the device sends a ping data to the server and the events data (if any).
- After that you can leave the commands from CoolR Portal. Device will connect and send data to server.

Troubleshooting

Issue: Can't find application PlayStore/App store

You can alternatively download the application from



a. <https://itunes.apple.com/us/app/coolr-smart-device/id1374366398?ls=1&mt=8>

b. https://play.google.com/store/apps/details?id=com.CoolrSmartDevices&hl=en_US

Issue: Can't find the Device during Install

1. Make sure that phone has BLE 4.1 or higher
2. Make sure your Phone OS is Android 4.4 or higher
3. Make sure Bluetooth and Location Services are ON

Issue: Can't Connect with Device In “Device Monitor

1. From Device Monitor Select “Sync” & wait till scan finishes.
2. Re-attempt to connect again.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.